

References

30

US Customary to Metric Conversion Factors

International System of Units (SI)—Metric Units

<i>Prefix</i>	<i>Symbol</i>	<i>Multiplication Factor</i>
exa	E	$10^{18} = 1,000,000,000,000,000,000$
peta	P	$10^{15} = 1,000,000,000,000,000$
tera	T	$10^{12} = 1,000,000,000,000$
giga	G	$10^9 = 1,000,000,000$
mega	M	$10^6 = 1,000,000$
kilo	k	$10^3 = 1,000$
hecto	h	$10^2 = 100$
deca	da	$10^1 = 10$
(unit)		$10^0 = 1$
deci	d	$10^{-1} = 0.1$
centi	c	$10^{-2} = 0.01$
milli	m	$10^{-3} = 0.001$
micro	μ	$10^{-6} = 0.000001$
nano	n	$10^{-9} = 0.000000001$
pico	p	$10^{-12} = 0.000000000001$
femto	f	$10^{-15} = 0.000000000000001$
atto	a	$10^{-18} = 0.000000000000000001$

Linear

1 meter (m) = 100 centimeters (cm) = 1000 millimeters (mm)

Area

$1 \text{ m}^2 = 1 \times 10^4 \text{ cm}^2 = 1 \times 10^6 \text{ mm}^2$

Volume

$1 \text{ m}^3 = 1 \times 10^6 \text{ cm}^3 = 1 \times 10^9 \text{ mm}^3$

1 liter (l) = 1000 cm³ = 1 × 10⁶ mm³

Mass

1 kilogram (kg) = 1000 grams (g)

(Approximately the mass of 1 liter of water)

1 metric ton (or tonne) = 1000 kg

Continued on [next page](#).

US Customary to Metric Conversion Factors

Continued from [previous page](#).

US Customary Units

Linear Units

12 inches (in) = 1 foot (ft)
 36 inches = 3 feet = 1 yard (yd)
 1 rod = 5¹/₂ yards = 16¹/₂ feet
 1 statute mile = 1760 yards
 = 5280 feet
 1 nautical mile = 6076.11549 feet

Area

1 ft² = 144 in²
 1 yd² = 9 ft² = 1296 in²
 1 rod² = 30¹/₄ yd²
 1 acre = 4840 yd² = 43,560 ft²
 1 acre = 160 rod²
 1 mile² = 640 acres

Volume

1 ft³ = 1728 in³
 1 yd³ = 27 ft³

Liquid Volume Measure

1 fluid ounce (fl oz) = 8 fluid
 drams = 1.804 in
 1 pint (pt) = 16 fl oz
 1 quart (qt) = 2 pt = 32 fl oz
 = 57³/₄ in³
 1 gallon (gal) = 4 qt = 231 in³
 1 barrel = 31¹/₂ gal

Dry Volume Measure

1 quart (qt) = 2 pints (pt)
 = 67.2 in³
 1 peck = 8 qt
 1 bushel = 4 pecks = 2150.42 in³

Avoirdupois Weight

1 dram (dr) = 27.343 grains (gr) or
 (gr a)
 1 ounce (oz) = 437.5 gr
 1 pound (lb) = 16 oz = 7000 gr
 1 short ton = 2000 lb, 1 long ton
 = 2240 lb

Troy Weight

1 grain troy (gr t) = 1 grain
 avoirdupois
 1 pennyweight (dwt) or (pwt)
 = 24 gr t
 1 ounce troy (oz t) = 480 grains
 1 lb t = 12 oz t = 5760 grains

Apothecaries' Weight

1 grain apothecaries' (gr ap)
 = 1 gr t = 1 gr
 1 dram ap (dr ap) = 60 gr
 1 oz ap = 1 oz t = 8 dr ap = 480 gr
 1 lb ap = 1 lb t = 12 oz ap
 = 5760 gr

Multiply →

Metric Unit = Conversion Factor × US Customary Unit

← Divide

Metric Unit ÷ Conversion Factor = US Customary Unit

Metric Unit = Conversion
 Factor × US Unit

(Length)

mm	25.4	inch
cm	2.54	inch
cm	30.48	foot
m	0.3048	foot
m	0.9144	yard
km	1.609	mile
km	1.852	nautical mile

(Area)

mm ²	645.16	inch ²
cm ²	6.4516	in ²
cm ²	929.03	ft ²
m ²	0.0929	ft ²
cm ²	8361.3	yd ²
m ²	0.83613	yd ²
m ²	4047	acre
km ²	2.59	mi ²

(Mass) (Avoirdupois Weight)

grams	0.0648	grains
g	28.349	oz
g	453.59	lb
kg	0.45359	lb
tonne	0.907	short ton
tonne	1.016	long ton

Metric Unit = Conversion
 Factor × US Unit

(Volume)

mm ³	16387.064	in ³
cm ³	16.387	in ³
m ³	0.028316	ft ³
m ³	0.764555	yd ³
ml	16.387	in ³
ml	29.57	fl oz
ml	473	pint
ml	946.333	quart
l	28.32	ft ³
l	0.9463	quart
l	3.785	gallon
l	1.101	dry quart
l	8.809	peck
l	35.238	bushel

(Mass) (Troy Weight)

g	31.103	oz t
g	373.248	lb t

(Mass) (Apothecaries' Weight)

g	3.387	dr ap
g	31.103	oz ap
g	373.248	lb ap

Abbreviations List

A

a—atto (prefix for 10^{-18})
A—ampere (unit of electrical current)
ac—alternating current
ACC—Affiliated Club Coordinator
ACSSB—amplitude-compandored single sideband
A/D—analog-to-digital
ADC—analog-to-digital converter
AF—audio frequency
AFC—automatic frequency control
AFSK—audio frequency-shift keying
AGC—automatic gain control
A/h—ampere hour
ALC—automatic level control
AM—amplitude modulation
AMRAD—Amateur Radio Research and Development Corp
AMSAT—Radio Amateur Satellite Corp
AMTOR—Amateur Teleprinting Over Radio
ANT—antenna
ARA—Amateur Radio Association
ARC—Amateur Radio Club
ARES—Amateur Radio Emergency Service
ARQ—Automatic repeat request
ARRL—American Radio Relay League
ARS—Amateur Radio Society (station)
ASCII—American National Standard Code for Information Interchange
ATV—amateur television
AVC—automatic volume control
AWG—American wire gauge
az-el—azimuth-elevation

B

B—bel; blower; susceptance; flux density, (inductors)
balun—balanced to unbalanced (transformer)
BC—broadcast
BCD—binary coded decimal
BCI—broadcast interference
Bd—baud (bits in single-channel binary data transmission)
BER—bit error rate
BFO—beat-frequency oscillator
bit—binary digit
bit/s—bits per second
BM—Bulletin Manager
BPF—band-pass filter
BPL—Brass Pounders League
BT—battery
BW—bandwidth

C

c—centi (prefix for 10^{-2})
C—coulomb (quantity of electric charge); capacitor
CAC—Contest Advisory Committee
CATVI—cable television interference
CB—Citizens Band (radio)
CBBS—computer bulletin-board service
CBMS—computer-based message system
CCITT—International Telegraph and Telephone Consultative Committee
CCTV—closed-circuit television
CCW—coherent CW
ccw—counterclockwise

Continued on [next page](#).

Abbreviations List

Continued from [previous page](#).

CD—civil defense
cm—centimeter
CMOS—complimentary-symmetry metal-oxide semiconductor
coax—coaxial cable
COR—carrier-operated relay
CP—code proficiency (award)
CPU—central processing unit
CRT—cathode ray tube
CT—center tap
CTCSS—continuous tone-coded squelch system
cw—clockwise
CW—continuous wave

D

d—deci (prefix for 10^{-1})
D—diode
da—deca (prefix for 10)
D/A—digital-to-analog
DAC—digital-to-analog converter
dB—decibel (0.1 bel)
dBi—decibels above (or below) isotropic antenna
dBm—decibels above (or below) 1 milliwatt
DBM—doubly balanced mixer
dBV—decibels above/below 1 V (in video, relative to 1 V P-P)
dBW—decibels above/below 1 W
dc—direct current
D-C—direct conversion
DDS—direct digital synthesis
DEC—District Emergency Coordinator
deg—degree
DET—detector
DF—direction finding; direction finder
DIP—dual in-line package
DMM—digital multimeter
DPDT—double-pole double-throw (switch)
DPSK—differential phase-shift keying
DPST—double-pole single-throw (switch)
DS—direct sequence (spread spectrum); display
DSB—double sideband
DSP—digital signal processing
DTMF—dual-tone multifrequency
DVM—digital voltmeter
DX—long distance; duplex
DXAC—DX Advisory Committee
DXCC—DX Century Club

E

e—base of natural logarithms (2.71828)
E—voltage
EA—ARRL Educational Advisor
EC—Emergency Coordinator
ECL—emitter-coupled logic
EHF—extremely high frequency (30-300 GHz)
EIA—Electronic Industries Assn
EIRP—effective isotropic radiated power
ELF—extremely low frequency
ELT—emergency locator transmitter
EMC—electromagnetic compatibility
EME—earth-moon-earth (moonbounce)

Continued on [next page](#).

Abbreviations List

Continued from [previous page](#).

EMF—electromotive force
EMI—electromagnetic interference
EMP—electromagnetic pulse
EOC—emergency operations center
EPROM—erasable programmable read only memory

F

f—femto (prefix for 10^{-5}); frequency
F—farad (capacitance unit); fuse
fax—facsimile
FCC—Federal Communications Commission
FD—Field Day
FEMA—Federal Emergency Management Agency
FET—field-effect transistor
FFT—fast Fourier transform
FL—filter
FM—frequency modulation
FMTV—frequency-modulated television
FSK—frequency-shift keying
FSTV—fast-scan (real-time) television
ft—foot (unit of length)

G

g—gram (unit of mass)
G—giga (prefix for 10^9); conductance
GaAs—gallium arsenide
GDO—grid- or gate-dip oscillator
GHz—gigahertz (10^9 Hz)
GND—ground

H

h—hecto (prefix for 10^2)
H—henry (unit of inductance)
HF—high frequency (3-30 MHz)
HFO—high-frequency oscillator; heterodyne frequency oscillator
HPF—highest probable frequency; high-pass filter
Hz—hertz (unit of frequency, 1 cycle/s)

I

I—current, indicating lamp
IARU—International Amateur Radio Union
IC—integrated circuit
ID—identification; inside diameter
IEEE—Institute of Electrical and Electronics Engineers
IF—intermediate frequency
IMD—intermodulation distortion
in.—inch (unit of length)
in./s—inch per second (unit of velocity)
I/O—input/output
IRC—international reply coupon
ISB—independent sideband
ITF—Interference Task Force
ITU—International Telecommunication Union

J

j —operator for complex notation, as for reactive component of an impedance ($+j$ inductive; $-j$ capacitive)
J—joule ($\text{kg m}^2/\text{s}^2$) (energy or work unit); jack
JFET—junction field-effect transistor

Continued on [next page](#).

Abbreviations List

Continued from [previous page](#).

K

k—kilo (prefix for 10^3); Boltzmann's constant (1.38×10^{-23} J/K)
K—kelvin (used without degree symbol) absolute temperature scale; relay
kBd—1000 bauds
kbit—1024 bits
kbit/s—1024 bits per second
kbyte—1024 bytes
kg—kilogram
kHz—kilohertz
km—kilometer
kV—kilovolt
kW—kilowatt
k Ω —kilohm

L

l—liter (liquid volume)
L—lambert; inductor
lb—pound (force unit)
LC—inductance-capacitance
LCD—liquid crystal display
LED—light-emitting diode
LF—low frequency (30-300 kHz)
LHC—left-hand circular (polarization)
LO—local oscillator; Leadership Official
LP—log periodic
LS—loudspeaker
lsb—least significant bit
LSB—lower sideband
LSI—large-scale integration
LUF—lowest usable frequency

M

m—meter (length); milli (prefix for 10^{-3})
M—mega (prefix for 10^6); meter (instrument)
mA—milliampere
mAh—milliampere hour
MCP—multimode communications processor
MDS—Multipoint Distribution Service; minimum discernible (or detectable) signal
MF—medium frequency (300-3000 kHz)
mH—millihenry
MHz—megahertz
mi—mile, statute (unit of length)
mi/h—mile per hour
mi/s—mile per second
mic—microphone
min—minute (time)
MIX—mixer
mm—millimeter
MOD—modulator
modem—modulator/demodulator
MOS—metal-oxide semiconductor
MOSFET—metal-oxide semiconductor field-effect transistor
MS—meteor scatter
ms—millisecond
m/s—meters per second
msb—most-significant bit
MSI—medium-scale integration
MSK—minimum-shift keying

Continued on [next page](#).

Abbreviations List

Continued from [previous page](#).

MSO—message storage operation
MUF—maximum usable frequency
mV—millivolt
mW—milliwatt
MΩ—megohm

N

n—nano (prefix for 10^{-9}); number of turns (inductors)
NBFM—narrow-band frequency modulation
NC—no connection; normally closed
NCS—net-control station; National Communications System
nF—nanofarad
NF—noise figure
nH—nanohenry
NiCd—nickel cadmium
NM—Net Manager
NMOS—N-channel metal-oxide silicon
NO—normally open
NPN—negative-positive-negative (transistor)
NPRM—Notice of Proposed Rule Making (FCC)
ns—nanosecond
NTIA—National Telecommunications and Information Administration
NTS—National Traffic System

O

OBS—Official Bulletin Station
OD—outside diameter
OES—Official Emergency Station
OO—Official Observer
op amp—operational amplifier
ORS—Official Relay Station
OSC—oscillator
OSCAR—Orbiting Satellite Carrying Amateur Radio
OTC—Old Timer's Club
oz—ounce (force unit, $\frac{1}{16}$ pound)

P

p—pico (prefix for 10^{-12})
P—power; plug
PA—power amplifier
PACTOR—digital mode combining aspects of packet and AMTOR
PAM—pulse-amplitude modulation
PBS—packet bulletin-board system
PC—printed circuit
 P_D —power dissipation
PEP—peak envelope power
PEV—peak envelope voltage
pF—picofarad
pH—picohenry
PIC—Public Information Coordinator
PIN—positive-intrinsic-negative (semiconductor)
PIO—Public Information Officer
PIV—peak inverse voltage
PLL—phase-locked loop
PM—phase modulation
PMOS—P-channel (metal-oxide semiconductor)
PNP—positive negative positive (transistor)
pot—potentiometer

Continued on [next page](#).

Abbreviations List

Continued from [previous page](#).

P-P—peak to peak
ppd—postpaid
PROM—programmable read-only memory
PSAC—Public Service Advisory Committee
PSHR—Public Service Honor Roll
PTO—permeability-tuned oscillator
PTT—push to talk

Q-R

Q—figure of merit (tuned circuit); transistor
QRP—low power (less than 5-W output)
R—resistor
RACES—Radio Amateur Civil Emergency Service
RAM—random-access memory
RC—resistance-capacitance
R/C—radio control
RCC—Rag Chewer's Club
RDF—radio direction finding
RF—radio frequency
RFC—radio-frequency choke
RFI—radio-frequency interference
RHC—right-hand circular (polarization)
RIT—receiver incremental tuning
RLC—resistance-inductance-capacitance
RM—rule making (number assigned to petition)
r/min—revolutions per minute
RMS—root mean square
ROM—read-only memory
r/s—revolutions per second
RS—Radio Sputnik, Russian ham satellite
RST—readability-strength-tone (CW signal report)
RTTY—radioteletype
RX—receiver, receiving

S

s—second (time)
S—siemens (unit of conductance); switch
SASE—self-addressed stamped envelope
SCF—switched capacitor filter
SCR—silicon controlled rectifier
SEC—Section Emergency Coordinator
SET—Simulated Emergency Test
SGL—State Government Liaison
SHF—super-high frequency (3-30 GHz)
SM—Section Manager; silver mica (capacitor)
S/N—signal-to-noise ratio
SPDT—single pole double-throw (switch)
SPST—single-pole single-throw (switch)
SS—Sweepstakes; spread spectrum
SSB—single sideband
SSC—Special Service Club
SSI—small-scale integration
SSTV—slow-scan television
STM—Section Traffic Manager
SX—simplex
sync—synchronous, synchronizing
SWL—shortwave listener
SWR—standing-wave ratio

Continued on [next page](#).

Abbreviations List

Continued from [previous page](#).

T

T—tera (prefix for 10^{12}); transformer
TA—ARRL Technical Advisor
TC—Technical Coordinator
TCC—Transcontinental Corps (NTS)
TCP/IP—Transmission Control Protocol/ Internet Protocol
tfc—traffic
TNC—terminal node controller (packet radio)
TR—transmit/receive
TS—Technical Specialist
TTL—transistor-transistor logic
TTY—teletypewriter
TU—terminal unit
TV—television
TVI—television interference
TX—transmitter, transmitting

U

U—integrated circuit
UHF—ultra-high frequency (300 MHz to 3 GHz)
USB—upper sideband
UTC—Coordinated Universal Time (also abbreviated Z)
UV—ultraviolet

V

V—volt; vacuum tube
VCO—voltage-controlled oscillator
VCR—video cassette recorder
VDT—video-display terminal
VE—Volunteer Examiner
VEC—Volunteer Examiner Coordinator
VFO—variable-frequency oscillator
VHF—very-high frequency (30-300 MHz)
VLF—very-low frequency (3-30 kHz)
VLSI—very-large-scale integration
VMOS—V-topology metal-oxide semiconductor
VOM—volt-ohmmeter
VOX—voice-operated switch
VR—voltage regulator
VSWR—voltage standing-wave ratio
VTVM—vacuum-tube voltmeter
VUCC—VHF/UHF Century Club
VXO—variable-frequency crystal oscillator

W

W—watt ($\text{kg m}^2\text{s}^{-3}$), unit of power
WAC—Worked All Continents
WAS—Worked All States
WBFM—wide-band frequency modulation
WEFAX—weather facsimile
Wh—watthour
WPM—words per minute
WRC—World Radio Conference
WVDC—working voltage, direct current

X

X—reactance

Continued on [next page](#).

Abbreviations List

Continued from [previous page](#).

XCVR—transceiver
XFMR—transformer
XIT—transmitter incremental tuning
XO—crystal oscillator
XTAL—crystal
XVTR—transverter

Y-Z

Y—crystal; admittance
YIG—yttrium iron garnet
Z—impedance; also see [UTC](#)

Numbers/Symbols

5BDXCC—Five-Band DXCC
5BWAC—Five-Band WAC
5BWAS—Five-Band WAS
6BWAC—Six-Band WAC
°—degree (plane angle)
°C—degree Celsius (temperature)
°F—degree Fahrenheit (temperature)
 α —(alpha) angles; coefficients, attenuation constant, absorption factor, area, common-base forward current-transfer ratio of a bipolar transistor
 β —(beta) angles; coefficients, phase constant current gain of common-emitter transistor amplifiers
 γ —(gamma) specific gravity, angles, electrical conductivity, propagation constant
 Γ —(gamma) complex propagation constant
 δ —(delta) increment or decrement; density; angles
 Δ —(delta) increment or decrement determinant, permittivity
 ϵ —(epsilon) dielectric constant; permittivity; electric intensity
 ζ —(zeta) coordinates; coefficients
 η —(eta) intrinsic impedance; efficiency; surface charge density; hysteresis; coordinate
 θ —(theta) angular phase displacement; time constant; reluctance; angles
 \mathbf{i} —(iota) unit vector
K—(kappa) susceptibility; coupling coefficient
 λ —(lambda) wavelength; attenuation constant
 Λ —(lambda) permeance
 μ —(mu) permeability; amplification factor; micro (prefix for 10^{-6})
 μC —microcomputer
 μF —microfarad
 μH —microhenry
 μP —microprocessor
 ξ —(xi) coordinates
 π —(pi) 3.14159
 ρ —(rho) resistivity; volume charge density; coordinates; reflection coefficient
 σ —(sigma) surface charge density; complex propagation constant; electrical conductivity; leakage coefficient; deviation
 Σ —(sigma) summation
 τ —(tau) time constant; volume resistivity; time-phase displacement; transmission factor; density
 ϕ —(phi) magnetic flux angles
 Φ —(phi) summation
 χ —(chi) electric susceptibility; angles
 Ψ —(psi) dielectric flux; phase difference; coordinates; angles
 ω —(omega) angular velocity $2\pi f$
 Ω —(omega) resistance in ohms; solid angle

ARRL Handbook Address List

These companies or individuals are cited in this edition of the *ARRL Handbook*. Please send updates to the ARRL Handbook Editor at ARRL Headquarters.

A & A Engineering
2521 West La Palma, Unit K
Anaheim, CA 92801
714-952-2114
fax 714-952-3280
e-mail w6ucm@aol.com

Advanced Receiver Research
Box 1242
Burlington, CT 06013
860-485-0310

AEA, Division of Tempo Research
Corp
1221 Liberty Way
Vista CA 92083
760-598-9677
fax 760-598-4898
[Also see [Timewave](#)]

Aero/Marine Beacon Guide
2856-G W Touhy Ave
Chicago, IL 60645

Alexander Aeroplane Co
PO Box 909
Griffin, GA 30224
800-831-2949
fax 404-229-2329

Alinco Electronics
438 Amapola Ave, #130
Torrance, CA 90501
310-618-8616
fax 310-618-8758
e-mail alinco@alinco.com
web www.alinco.com

All Electronics Corp
14928 Oxnard St
PO Box 567
Van Nuys, CA 91411
800-826-5432
818-904-0524
fax 818-781-2653
e-mail allcorp@callcorp.com
web www.allcorp.com/

Allied Electronics
7410 Pebble Dr
Fort Worth, TX 76118
800-433-5700
web www.allied.avnet.com/

Allstar Magnetics
7206 NE 37 Ave
Vancouver, WA 98665
206-693-0213
fax 206-693-0639
web www.allstarmagnetics.com/

Alpha-Delta Communications
PO Box 620
Manchester KY 40962
606-598-2029
fax 606-598-4413

Alpha/Power, Inc
14440 Mead Ct, Unit B
Longmont, CO 80504
970-535-4173
fax 970-535-0281
e-mail sales@alpha-power-inc.com
web www.alpha-power-inc.com/

Aluma Tower Company, Inc
PO Box 2806-AL
Vero Beach, FL 32961-2806
561-567-3423
fax 561-567-3432
e-mail atc@alumatower.com
web www.alumatower.com/

AM Press/Exchange
2116 Old Dover Rd
Woodlawn, TN 37191

Amateur Television Quarterly
(ATVQ)
5931 Alma Dr
Rockford, IL 61108
815-398-2683
fax 815-398-2688
e-mail atvq@aol.com
web www.cris.com/Gharlan/

AMECO Publishing Corp
224 E 2nd St
Mineola, NY 11501
516-741-5030
fax 516-741-5031
e-mail sales@amecocorp.com
web www.amecocorp.com/

American Design Components
400 County Ave
Secaucus, NJ 07094
201-601-8999
fax 201-601-8990

American National Standards
Institute (ANSI)
11 W 42nd St
New York, NY 10036
212-642-4900
web www.ansi.org/

Ameritron
116 Willow Rd
Starkville, MS 39759
601-323-8211
fax 601-323-6551
e-mail ameritron@ameritron.com
web www.ameritron.com/

Amidon, Inc
250 & 250 Briggs Ave
Costa Mesa, CA 92626
714-850-4660
fax 714-850-1163
e-mail sales@amidoncorp.com
web www.amidoncorp.com/

AMRAD
Post Box 6148
McLean, VA 22106

AMSAT (Radio Amateur Satellite
Corp)
PO Box 27
Washington, DC 20044
301-589-6062
fax 301-608-3410
e-mail martha@amsat.org
web www.amsat.org/

ANARC
PO Box 11201
Shawnee Mission, KS 66207-0201
913-345-1978 (BBS)

Anchor Electronics
2040 Walsh Ave
Santa Clara, CA 95050
408-727-3693
fax 408-727-4424

Angle Linear
PO Box 35
Lomita, CA 90717
310-539-5395
fax 310-539-8738
e-mail cangle@anglelinear.com
web www.anglelinear.com/

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

antenneX Magazine
web www.antennex.com/

Antique Electronic Supply
6221 South Maple Ave
PO Box 27468
Tempe AZ 85285-7468
602-820-5411
fax 602-820-4643
web www.tubesandmore.com/

Antique Radio Classified
PO Box 802-B14
Carlisle, MA 01741
978-371-0512
fax 978-371-7129
web www.antiqueradio.com/

Array Solutions
350 Gloria Rd
Sunnyvale, TX 75182
972-203-8810
fax 972-203-8811
e-mail wx0b@arraysolutions.com
web www.arraysolutions.com/

ARRL—the national association
for Amateur Radio
225 Main St
Newington, CT 06111-1494
860-594-0200
fax 860-594-0259
e-mail tis@arrl.org
web www.arrl.org/

Arrow Electronics
25 Hub Dr
Melville, NY 11747
800-932-7769
516-694-6800
fax 516-585-0878

ARS Electronics
7110 De Celis Pl
PO Box 7323
Van Nuys, CA 91409
818-997-6200
800-422-4250
fax 818-997-6158

Atlantic Surplus Sales
3730 Nautilus Ave
Brooklyn, NY 11224
718-372-0349

ATV Research, Inc
1301 Broadway
PO Box 620
Dakota City, NE 68731
402-987-3771
800-392-3922 (orders)
fax 402-987-3709
e-mail atv@pionet.net
web www.atvresearch.com/

Avantek
3175 Bowers Ave
Santa Clara, CA 95054-3292
408-727-0700

Avatar Magnetics
240 Tamara Trail
Indianapolis, IN 46217

Barker and Williamson Corp
(B&W)
603 Cidco Rd
Cocoa, FL 32926
407-639-1510
fax 407-639-2545
e-mail custsrvc@bwantennas.com
web bwantennas.com/

Brian Beezley, K6STI
3532 Linda Vista
San Marcos, CA 92069
760-599-8662 (product support)
e-mail k6sti@n2.net

Bencher, Inc
831 N Central Ave
Wood Dale, IL 60191
630-238-1183
fax 630-238-1186
e-mail bencher@bencher.com
web www.bencher.com/

Bird Electronics Corp
30303 Aurora Rd
Cleveland, OH 44139
440-248-1200

British Amateur Television Club
Grenehurst, Pinewood Rd
High Wycombe
Bucks HP12 4DD
United Kingdom
01494-528899
e-mail memsec@batc.org.uk

Buckmaster Publishing
6196 Jefferson Highway
Mineral, VA 23117
800-282-5628
540-894-5777
fax 540-894-9141
e-mail info@buck.com
web www.buck.com/

Caddock Electronics
1717 Chicago Ave
Riverside, CA 92507-2364
909-788-1700
fax 909-369-1151
web www.caddock.com/

Calogic
237 Whitney Pl
Fremont, CA 94539
510-656-2900

Jim Cates, WA6GER
3241 Eastwood Rd
Sacramento, CA 95821
916-487-3580

Cetron Communications
715 Hamilton St
Geneva, IL 60134
800-238-7661
708-208-3700
fax 708-208-3750

Circuit Specialists
220 S Country Club Dr, Bldg #2
Mesa, AZ 85210
602-966-0764
800-528-1417
480-464-2485
fax 480-464-5824

Coilcraft
1102 Silver Lake Rd
Cary, IL 60013
847-639-6400
fax 847-639-1469
e-mail info@coilcraft.com
web www.coilcraft.com/

Communication Concepts, Inc
(CCI)
508 Millstone Dr
Beavercreek, OH 45434-5840
937-426-8600
fax 937-429-3811
e-mail ccidayton@pobox.com

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

Communications and Power Industries
Eimac Division
301 Industrial Way
San Carlos, CA 94070-2682
800-414-TUBE (414-8823)
650-594-4175
web www.eimac.com/

Communications Quarterly
— see [CQ Communications](#)

Communications Specialists Inc
426 West Taft Ave
Orange, CA 92865-4296
714-998-3021
800-854-0547
fax 714-974-3420 or
800-850-0547
web www.com-spec.com/

Condenser Products Corp
2131 Broad St
Brooksville, FL 34609
904-796-3561
fax 904-799-0221

Contact East, Inc
335 Willow St
North Andover, MA 01845
508-682-2000
fax 508-688-7829

Ken Cornell
225 Baltimore Ave
Point Pleasant, NJ 08742

Courage HANDI-HAM System
3915 Golden Valley Rd
Golden Valley, MN 55422
612-520-0515
612-520-0245 (TTY)
fax 612-520-0577
e-mail handiham@mtn.org
web www.mtn.org/handiham/

CQ Communications
25 Newbridge Rd
Hicksville, NY 11801
516-681-2922 (business office)
fax 516-681-2926
e-mail cqmagazine@aol.com
web www.cq-amateur-radio.com/

Curry Communications
PO Box 1884
Burbank, CA 91507
818-846-0617

Cushcraft Corp
PO Box 4680
Manchester, NH 03103
603-627-7877
fax 603-627-1764
e-mail hamsales@cushcraft.com
web www.cushcraft.com/

Custom Computer Services, Inc
PO Box 2452
Brookfield, WI 53008
414-781-2794
web www.ccsinfo.com/picc.html

Jacques d'Avignon, VE3VIA
965 Lincoln Dr
Kingston, ON K7M 4Z3
Canada
613-634-1519
e-mail
monitor@limestone.kosone.com

Dallas Remote Imaging Group
4209 Meadowdale Dr, Ste 3
Carrollton, TX 75010
214-394-7438 (BBS)
214-394-7325 (Voice)
fax 214-492-7747
e-mail jwallach@drig.com
web www.drug.com/

Davis RF Co, Div of Davis Associates Wire & Cable, LLC
PO Box 730
Carlisle, MA 01741
800-328-4773 (orders and general info)
978-369-1738 (technical info)
fax 978-369-3484
e-mail davisRFinc@aol.com
web www.davisRF.com/

DC Electronics
PO Box 3203
2200 N Scottsdale Rd
Scottsdale, AZ 85271-3203
800-467-7736
web www.dckits.com/index.htm

DCI Inc
29 Hummingbird Way
White City, SK S0G 5B0
Canada
306-781-4451
e-mail dc@dc.com

Digi-Key Corp
701 Brooks Ave S
PO Box 677
Thief River Falls, MN
56701-0677
800-344-4539 (800-DIGI-KEY)
fax 218-681-3380
web www.digikey.com/

Digital Vision, Inc
270 Bridge St
Dedham, MA 02026
617-329-5400
617-329-8387 (BBS)

Dover Research
321 W 4th St
Jordan, MN 55352-1313
612-492-3913

Down East Microwave
954 Rte 519
Frenchtown, NJ 08825
908-996-3584
fax 908-996-3072
web
www.downeastmicrowave.com/

East Coast Amateur Radio, Inc
415 Division St
N Tonawanda, NY 14120
716-695-3929

EDI, Inc
1260 Karl Ct
Wauconda, IL 60084
708-487-3347
fax 708-487-3346

Edlie Electronics, Inc
2700 Hempstead Tpk
Levittown, NY 11756-1443
orders 800-647-4722
516-735-3330
fax 516-731-5125

Eimac
—see [Communications and Power Industries](#)

Electric Radio Magazine
14643 County Rd G
Cortez, CO 81321-9575
970-564-9185 (voice and **fax**)
e-mail er@frontier.net

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

Electro Sonic, Inc
100 Gordon Baker Rd
Willowdale, ON M2H 3B3
Canada
416-494-1666
416-494-1555

Electronic Emporium
3621-29 E Weir Ave
Phoenix, AZ 85040
602-437-8633
fax 602-437-8835

Electronic Equipment Bank (EEB)
323 Mill St, NE
Vienna, VA 22180
orders 800-368-3270
technical 703-938-3350
fax 703-938-6911
e-mail eeb@access.digex.net
web www.access.digex.net/eeb/eeb/html

Electronic Industries Alliance (EIA)
2500 Wilson Blvd
Arlington, VA 22201-3834
703-907-7500
web www.eia.org/

Electronic Precepts of Florida
11651 87th St
Largo, FL 34643-4917
800-367-4649
fax 813-544-1910

Electronic Rainbow, Inc
6227 Coffman Rd
Indianapolis, IN 46268
317-291-7262
fax 317-291-7269

Electronics Now
500-B Bi-County Blvd
Farmingdale, NY 11735
800-288-0652 (Customer Service)
800-999-7139 (New subscriptions)
516-293-3000 (Admin Office)
fax 516-293-3115

Elktronics
12536 T.77
Findlay, OH 45840
419-422-8206

Elna Ferrite Laboratories, Inc
234 Tinker St
PO Box 395
Woodstock, NY 12498
914-679-2497

Embedded Research
PO Box 92492
Rochester, NY 14692
e-mail embres@frontier.net
web www.frontiernet.net/~embres

EMI Filter Company
9075A 130 Ave N
Largo, FL 34643
800-323-7990
fax 813-586-9378

Encomm
1506 Capitol Ave
Plano, TX 75074

Engineering Consulting
583 Candlewood St
Brea, CA 92621
714-671-2009
fax 714-255-9984

ESF Copy Service
4011 Clearview Dr
Cedar Falls, IA 50613-6111
319-266-7040

ETO, Inc
4975 N 30th St
Colorado Springs, CO 80919
719-260-1191
719-599-3861
fax 719-260-0395

Fair Radio Sales Co, Inc
1016 E Eureka St
PO Box 1105
Lima, OH 45802-1105
419-227-6573
419-223-2196
fax 419-227-1313
e-mail fairradio@wcoil.com
web www.fairradio.com/

Fair-Rite Products Corp
PO Box J, 1 Commercial Row
Wallkill, NY 12589
914-895-2055
fax 914-895-2629
e-mail ferrites@fair-rite.com
web fair-rite.com/

Fala Electronics
PO Box 1376
Milwaukee, WI 53201-1376

FAR Circuits
18N640 Field Court
Dundee, IL 60118-9269
847-836-9148 (voice and **fax**)
web www.cl.ais.net/faircir/

G-O-Metric
909 Norwich Ave
Delran, NJ 08075

Gary Meyers, K9RX
1753 Elmwood Dr
Rockhill, SC 29730

Gateway Electronics
8123 Page Blvd
St. Louis, MO 63130
800-669-5810
314-427-6116
fax 314-427-3147
e-mail gateway@mo.net
web www.gatewayelex.com/

Glen Martin Engineering
Rte 3, Box 322
Boonville, MO 65233
816-882-2734
fax 816-882-7200
web www.glenmartin.com/

Grove Enterprises Inc
PO Box 98
Brasstown, NC 28902
800-438-8155 (orders)
704-837-9200 (BBS)
fax 704-837-2216
e-mail nada@grove.net
web www.grove.net/

HAL Communications Corp
1201 W Kenyon Rd
PO Box 365
Urbana, IL 61801-0365
217-367-7373 (voice and fax)
e-mail halcomm@phairienet.org
web www.halcomm.com/

Ham Equipment Buyers Guide
189 Kenilworth
Glen Ellyn, IL 60137

Hammond Mfg Co, Inc
4700 Genesee St
Cheektowaga, NY 14225-2466
716-631-5700
fax 716-631-1156

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

Hammond Mfg, Ltd
394 Edinburgh Rd, N
Guelph, ON N1H 1E5
Canada
519-822-8323

Hamtronics, Inc
65-Q Moul Rd
Hilton, NY 14468
716-392-9430
fax 716-392-9420
web www.hamtronics.com/

H. B. Electronics
43 Rector St
E Greenwich RI 02818-3312
e-mail
hb.electronics@businesson.com
web www.businesson.com/hamparts/

Heath Order Desk (old kits)
455 Riverview Dr
Benton Harbor, MI 49022
616-925-5899

Heathkit Educational Systems
PO Box 8589
Benton Harbor, MI 49023-8589
800-253-0570
fax 616-925-4876
e-mail techsupport@heathkit.com
web www.heathkit.com/

Heldref Publications
1319 Eighteenth St, NW
Washington, DC 20036
800-365-9753

Henry Radio
2050 South Bundy Dr
Los Angeles, CA 90025
310-820-1234
800-877-7979 (Orders)
fax 310-820-1234
e-mail henryradio@earthlink.net
web www.henryradio.com/

Herbach and Rademan
(H & R Co)
16 Roland Ave
Mt Laurel, NJ 08054-1012
800-848-8001 (Orders only)
609-802-0422
fax 609-802-0465
e-mail sales@herbach.com
web www.herbach.com/

HERD Electronics
514 S Baltimore St
Dillsburg, PA 17019-9601
717-432-4519
fax 717-432-7850
e-mail herd@juno.com

HI-Manuals
PO Box 802
Council Bluffs, IA 51502-0802
e-mail himan@radiks.net
web www.hi-manuals.com/

HI-Tech Software, LLC
Suite 105, 7830 Ellis Rd
Melbourne, FL 39204
800-735-5717
web www.htsoft.com/

Hosfelt Electronics
2700 Sunset Blvd
Steubenville, OH 43952
800-524-6464
fax 800-524-5414
e-mail hosfelt@clover.net
web www.hosfelt.com/

Howard W. Sams and Company
2647 Waterfront Pky E Dr
Indianapolis, IN 46214-2041
800-428-7267 (428-SAMS)
317-298-5565
fax 317-298-5604
web www.hwsams.com/

ICOM America, Inc
2380 116th Ave NE
PO Box C-90029
Bellevue, WA 98004
425-454-8155
425-450-6088 (literature)
fax 425-454-1509
e-mail
75540.525@compuserve.com
web www.icomamerica.com/

Idiom Press
PO Box 1025
Geyserville, CA 95441-1025

IEEE
345 E 47th St
New York, NY 10017-2394

IEEE Operations Center
445 Hoes Ln
PO Box 1331
Piscataway, NJ 08855-1331
908-981-0060

Industrial Communications Engi-
neers (ICE)
PO Box 18495
Indianapolis, IN 46218-0495
317-545-5412
800-423-2666
fax 317-545-9645

Industrial Safety Co
1390 Neubrecht Rd
Lima, OH 45801
419-227-6030
fax 419-228-5034

International Components Corp
105 Maxess Rd
Melville, NY 11747
800-645-9154
516-293-1500 (NY)
fax 516-293-4983
e-mail oemsales@icc107.com
web www.icc107.com/index/

International Crystal Mfg Co
10 North Lee
PO Box 26330
Oklahoma City, OK 73126-0330
800-725-1426
405-236-3741
fax 800-322-9426
e-mail
customerservice@icmfg.com
web www.icmfg.com/

International Radio
13620 Tyee Rd
Umpqua, OR 97486
541-459-5623
fax 541-459-5632
e-mail inrad@rosenet.net
web www.qth.com/inrad/

International Telecommunication
Union (ITU)
Place des Nations
CH 1211
Geneva 20, Switzerland
web www.itu.ch/

International Visual Communi-
cations Association (IVCA)
PO Box 140336
Nashville, TN 37214

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

IPS Radio and Space Services
PO Box 5606
West Chatswood NSW 2057
Australia
+61 2 414 8300
fax +61 2 414 8331
e-mail rwc@ips.gov.au
web www.ips.gov.au

Jade Products Inc
PO Box 368
East Hampstead, NH 03826
800-JADE-PRO (800-523-3776)
603-329-6995
fax 603-329-4499

Jameco Electronics
1355 Shoreway Rd
Belmont, CA 94002
800-831-4242
fax 800-237-6948
e-mail info@jameco.com
web www.jameco.com/

James Millen Electronics
PO Box 4215BV
Andover, MA 01810-4215
508-975-2711
508-475-7831
fax 508-474-8949

JAN Crystals
2341 Crystal Dr
PO Box 06017
Fort Myers, FL 33906-6017
800-526-9825 (JAN-XTAL)
941-936-2397
fax 941-936-3750

JDR Microdevices
1850 South 10th St
San Jose, CA 95122-4108
800-538-5000 (Orders)
408-494-1400
fax 800-538-5005
e-mail sales@jdr.com
web www.jdr.com/

Jolida Tube Factory
10820 Guilford Rd
Annapolis Junction, MD 20701
800-783-2555

K-Com
PO Box 82
Randolph OH 44265
330-325-2110
fax 330-325-2525
e-mail k-com@worldnet.att.net
web www.k-comfilters.com/

Kanga US
3521 Spring Lake Dr
Findlay, OH 45840
419-423-4604
419-423-5643
e-mail kanga@bright.net
web www.bright.net/~kanga/kanga/

Kangaroo Tabor Software
Rte 2, Box 106
Farwell, TX 79325-9430
fax 806-225-4006
e-mail ku5s@wtrt.net
web www.taborsoft.com/

Kantronics
1202 East 23rd St
Lawrence, KS 66046-5099
785-842-7745
fax 785-842-2031
e-mail purchasing@kantronics.com
web www.kantronics.com/

Kenwood Communications Corp
2201 East Dominguez St
PO Box 22745
Long Beach, CA 90801-5745
310-639-5300 (customer support)
800-536-9663 - (repairs/parts)
310-761-8284 (BBS)
fax 310-631-3913
web www.kenwood.net

Kepro Circuit Systems, Inc
630 Axminister Dr
Fenton, MO 63026-2992
800-325-3878
314-343-1630
fax 314-343-0668

Kilo-Tec
PO Box 10
Oak View, CA 93022
805-646-9645 (voice and fax)

Kirby
298 West Carmel Dr
Carmel, IN 46032
317-843-2212

KLM Electronics
PO Box 816
Morgan Hill, CA 95037

Kooltronic
1700 Morse Ave
Ventura, CA 93003
805-642-8521

KVG
2240 Woolbright Rd, Ste 320-A
Boynton Beach, FL 33426-6325
407-734-9007
fax 407-734-9008

K2AW's Silicon Alley
175 Friends Ln
Westbury, NY 11590
516-334-7024
fax 516-334-7024

L. L. Grace Communications
PO Box 1345
Voorhees, NJ 08043
609-751-1018
fax 609-751-9705
e-mail n2rec@amsat.org

John Langner, WB2OSZ
115 Stedman St
Chelmsford, MA 01824-1823
508-256-6907

Lashen Electronics, Inc
21 Broadway
Denville, NJ 07834
973-627-3783
fax 973-625-9501
e-mail sales@lashen.com
web www.lashen.com/

Roy Lewallen, W7EL
PO Box 6658
Beaverton, OR 97007
503-646-2885
fax 503-671-9046
e-mail w7el@teleport.com

Lodestone Pacific
4769 Wesley Dr
Anaheim, CA 92807
914-970-0900
fax 914-970-0800

The Longwave Club of America
45 Wildflower Rd
Levittown, PA 19057
215-945-0543
e-mail naswa1@aol.com
web anarc.org/lwca/

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

M/A-COM, Inc (an AMP Company)
1011 Pawtucket Blvd
PO Box 3295
Lowell, MA 01853-3295
508-442-4500
fax 508-442-4436
e-mail sales@macom.com
web www.amp.com/

M² Antenna Systems
7560 North Del Mar Ave
Fresno, CA 93711
559-432-8873
fax 559-432-3059
e-mail mzinc@mzinc.com
web www.mzinc.com/

MAI/Prime Parts
5736 N Michigan Rd
Indianapolis, IN 46208
317-257-6811
fax 317-257-1590
e-mail mai@iquest.net

The Manual Man
27 Walling St
Sayreville, NJ 08872-1818
908-238-8964
fax 908-238-8964

Mark V Electronics
8019 E Slauson Ave
Montebello, CA 90640
800-423-FIVE (Orders outside CA)
800-521-MARK (CA orders)
213-888-8988
fax 213-888-6868

Marlin P. Jones & Associates, Inc
PO Box 12685
Lake Park, FL 33403-0685
800-652-6733
561-848-8236 (Tech)
fax 800-432-9937
e-mail mpja@gate.net

Maxim Integrated Products
120 San Gabriel Dr
Sunnyvale, CA 94086
408-737-7600
fax 408-737-7194
web www.maxim-ic.com/

Richard Measures, AG6K
6455 LaCumbre Rd
Somis, CA 93066
805-384-3734
e-mail 2@vc.net
web www.vcnet/measures/

Mendelsohn Electronics Co, Inc
340 E First St
Dayton, OH 45402
800-344-4465
937-461-3525
fax 937-461-3391

Metal and Cable Corp, Inc
9241 Ravenna Rd, Unit C-10
PO Box 117
Twinsburg, OH 44087
216-425-8455
fax 216-425-3504
web www.metal-cable.com/

MFJ Enterprises
PO Box 494
Mississippi State, MS 39762
601-323-5869
800-647-1800
fax 601-323-6551
e-mail mfj@mfjenterprises.com
web www.mfjenterprises.com/

Micro Engineering Labs, Inc.
Box 7532
Colorado Springs, CO 80933-7532
719-520-5323
web www.melabs.com/mel/

Micro Video Products
16201 Osborne St
Westminster, CA 92683-7722
800-473-0538

Microchip Technology
2355 W Chandler Blvd
Chandler, AZ 85224-6199
602-786-7200
fax 602-899-9210
web www.microchip.com/

Microcraft Corp
PO Box 937Q
Thiensville, WI 53092
414-241-8144

Microwave Components of Michigan
PO Box 1697
Taylor, MI 48180
313-753-4581 (evenings)

Microwave Filter Co, Inc
6743 Kinne St
E Syracuse NY 13057
800-448-1666
315-438-4700
fax 315-463-1467
e-mail
mfcsales@microwavefilter.com
web www.mwfilter.com/

Mini Circuits Labs
PO Box 350166
Brooklyn, NY 11235-0003
800-654-7949
718-934-4500
fax 718-332-4661
web www.minicircuits.com/

Mirage Communications
116 Willow Rd
Starkville, MS 39759
601-323-8287
fax 601-323-6551
web www.mirageamp.com/

Bob Mobile, WA1OUB
RFD 2, Hillsboro Cir
Hillsborough, NH 03244

Model Aviation
5151 East Memorial Dr
Muncie, IN 47302
317-287-1256
fax 317-289-4248

Modern Radio Laboratories
PO Box 14902-Q
Minneapolis, MN 55414-0902

Morse Telegraph Club, Inc
1101 Maplewood Dr
Normal, IL 61761
e-mail jramtc@mwci.net

Motorola Semiconductor Products,
Inc
5005 East McDowell Rd
Phoenix, AZ 85008
512-891-2030
512-891-3773
web www.mot.com/

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

Mouser Electronics
2401 Hwy 287 N
Mansfield, TX 76063
800-346-6873
fax 817-483-0931
e-mail sales@mouser.com
web www.mouser.com/

National Electronics
PO Box 15417
Shawnee Mission, KS 66285
800-762-5049 (orders)
e-mail sales@national-electronics.com
web www.sound.net/~ne/

National Fire Protection Association
1 Batterymarch Park
PO Box 9101
Quincy, MA 02269-9101
800-344-3555
web www.nfpa.org/

National Semiconductor Corp
PO Box 58090
Santa Clara, CA 95052-8090
800-272-9959
408-721-5000
fax 800-432-9672

National Technical Information Service
5285 Port Royal Rd
Springfield, VA 22161
703-487-4650 (sales desk)
703-487-4639 (TDD - for the hearing impaired)
fax 703-321-8547

The New RTTY Journal
PO Box 236
Champaign, IL 61824-0236

New Sensor Corp
20 Cooper Station
New York, NY 10003
212-529-0466
800-633-5477 (orders)
fax 212-529-0486

Newark Electronics
4801 N. Ravenswood Ave
Chicago, IL 60640-4496
800-463-9275
312-784-5100
web www.newark.com/

Noble Publishing
2245 Dillard St
Tucker, GA 30084
770-908-2320
770-939-0157

NOISE/COM Co
E 49 Midland Ave
Paramus, NJ 07652
201-261-8797
fax 201-261-8339
e-mail info@noisecom.com
web www.noisecom.com/

Northern Lights Software
2881 C.R. 21
Canton, NY 13617
315-379-0161
fax 315-379-5804
e-mail w9ip@webcom.com

Nuts & Volts Magazine
430 Princeland Court
Corona, CA 91719-9938
909-371-8497
fax 909-371-3052
e-mail subscribe@nutsvolts.com
web www.nutsvolts.com/

Oak Hills Research
2460 S Moline Way
Aurora, CO 80014
800-238-8205 (orders)
303-752-3382
fax 303-745-6792
e-mail qrp@ohr.com
web www.morsex.com/ohr/

Ocean State Electronics
6 Industrial Dr
Westerly, RI 02891
401-596-3080
800-866-6626
fax 401-596-3590

Old Tech—Books & Things
PO Box 803
Carlisle, MA 01741

Osborne McGraw-Hill
2600 Tenth St
Berkeley, CA 94710

PacComm Packet Radio Systems Inc
4413 North Hesperides St
Tampa, FL 33614-7618
800-486-7388 (Orders)
813-874-2980
fax 813-872-8696
e-mail info@janrix.com
web www.paccomm.com/

Palomar Engineers
PO Box 462222
Escondido, CA 92046
760-747-3343
fax 760-747-3346
e-mail 75353.2175@compuserve.com

Pasternack Enterprises
PO Box 16759
Irvine, CA 92713
714-261-1920
fax 714-261-7451

PC Electronics
2522 Paxson Ln
Arcadia, CA 91007
626-447-4565
fax 626-447-0489
e-mail tom@hamtv.com
web www.hamtv.com/

Peter W. Dahl Co, Inc
5869 Waycross Ave
El Paso, TX 79924
915-751-2300
fax 915-751-0768
e-mail pwdco@pwdahl.com
web www.pwdahl.com/

Phillips Components
PO Box 8533
Scottsdale, AZ 85252
602-269-5974
800-880-6637 (MMDS)
602-947-7700
fax 602-947-7799

Popular Communications
— See [CQ Communications](#)

Power Supply Components
677 Palomar Ave
Sunnyvale, CA 94086
408-737-1333
fax 408-737-0502

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

Practical Wireless
Arrowsmith Court
Station Approach
Broadstone, Dorset BH18 8PW
United Kingdom
44-1202-659950
e-mail rob@pwpub.demon.co.uk

PRO Distributors
2811-B 74th St
Lubbock, TX 79423
800-658-2027

The PX Shack
52 Stonewyck Dr
Belle Mead, NJ 08502

QRP Quarterly (Subscriptions)
2046 Ash Hill Rd
Carrolton, TX 75007

Quantics
PO Box 2163
Nevada City, CA 95959-1263

R & B Enterprises
20 Clipper Rd
W Conshohocken, PA 19428
610-825-1960
fax 610-825-1684
e-mail rbemc@ix.netcom.net

R & D Electronics
5363 Broadway Ave
Cleveland, OH 44127-1551
800-642-1123 (orders)
216-621-1121
fax 216-621-8628

R & L Electronics
1315 Maple Ave
Hamilton, OH 45011
800-221-7735
513-868-6399
fax 513-868-6574
e-mail sales@randl.com
web www.randl.com/

Radio Adventures Corp.
RD #4, Box 240
Summit Dr
Franklin, PA 16346
814-437-5355
fax 814-437-5432
e-mail info@radioadv.com
web www.radioadv.com/

Radio Amateur Telecommunica-
tions Society
203 Bishop Blvd
N Brunswick, NJ 08902
e-mail askrat@rats.org
web www.rats.org/

Radio Book Store
PO Box 209
Rindge, NH 03461
800-457-7373
fax 603-899-6826
web www.radiobooks.com/

Radio Society of Great Britain
Lambda House
Cranborne Rd
Potters Bar
Herts EN6 3JE
United Kingdom
44—01-707-659015
web www.rsgb.org/

Radio Switch Corp.
PO Box 159
Marlboro, NJ 07746-0159
732-462-6100

Radiokit
PO Box 973
Pelham, NH 03076
603-635-2235
Telex: 887697
fax 603-635-2943

Radioware
PO Box 209
Rindge, NH 03461
800-457-7373
fax 603-899-6826
e-mail radware@radio-ware.com
web www.radio-ware.com/

Rainy Day Books
PO Box 775
Fitzwilliam, NH 03447
603-585-3448
fax 603-215-0046

Ramsey Electronics, Inc
793 Canning Pkwy
Victor, NY 14564
716-924-4560
fax 716-924-4555

The Raymond Sario Co
6147 Via Serena St
Alta Loma CA 91701
800-413-1129 (orders)
909-413-1129
fax 909-484-5125
e-mail wb6siv@cyberg8t.com
web www.sario.com/

RF Parts Co
435 South Pacific St
San Marcos, CA 92069
760-744-0700
800-737-2787 (orders)
fax 760-744-1943
e-mail rpf@rfparts.com
web www.rfparts.com/

RMD Technology, Inc
250 Airport Industrial Dr
Ypsilanti, MI 48198-6061
313-482-2670
fax 313-482-2671
e-mail robertrau@aol.com

Robert H. Bauman Sales
PO Box 122
Itasca, IL 60143

ROHN
PO Box 2000
Peoria, IL 61656
309-697-4400
fax 309-697-5612
e-mail rohn@rohnet.com

Ron Boucher
PO Box 541
Goffstown, NH 03045
603-497-2988
fax 603-497-3244
e-mail
72440.1356@compuserve.com

S & S Engineering
14102 Brown Rd
Smithsburg, MD 21783
301-416-0661
fax 301-416-0963
e-mail n3ga@aol.com
web www.xmetric.com/sseng/

Sentry Mfg Co
PO Box 250
Chickasha, OK 73023
405-224-6780
800-252-6780
fax 405-224-8808

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

SESCOM, Inc
2100 Ward Dr
Henderson, NV 89015-4249
702-565-3400
fax 702-565-4828

SHF Microwave Parts Company
7102 West 500 South
219-785-4552
La Porte, IN 46350-9575
219-785-4552
e-mail prutz@shfmicro.com
web www.shfmicro.com/

Simple Design Implementations
PO Box 9303
Forestville, CT 06011-9303
860-582-8526

Sky Publishing Company
PO Box 9111
Belmont, MA 02178-9111
800-253-0245
617-864-7360
fax 617-864-6117
e-mail skytel@skypub.com
web www.skypub.com/

Skymoon
9012 Kings Dr
Manvel, TX 7578

SkyWave Technologies
17 Pine Knoll Rd
Lexington, MA 02173
617-862-6742

Small Parts, Inc
13980 NW 58th Ct
PO Box 4650
Miami Lakes, FL 33014-0650
800-220-4242 (Orders)
305-557-7955 (Customer service)
fax 800-423-9009
e-mail smlparts@smallparts.com
web www.smallparts.com/

Society of Wireless Pioneers, Inc
PO Box 86
Geyserville, CA 95441
e-mail k6dzy@netdex.com
web web.mountain.net/~carto/

Software Systems Consulting
615 South El Camino Real
San Clemente, CA 92672
714-498-5784
fax 714-498-0568

The Solar Depot
99 rear Washington St
Melrose, MA 02176
617-665-7609
e-mail rmeuse@world.std.com

Solar Energy of South Florida
1024 NE 21st St
Belle Glade, FL 33430
407-996-6290

Solder-It Co
Box 20100
Cleveland, OH 44120
216-791-4600
800-897-8989
fax 216-721-3700
e-mail fdoo6@apk.net
web www.solder-it.com/

Southern Electronics Supply
1909 Tulane Ave
New Orleans, LA 70112
504-524-2343
e-mail e-mail@southernele.com
web www.southernele.com/

Southwestern Bell
7486 Shadeland Station Way
Indianapolis, IN 46256
317-576-6847

Sparrevohn Engineering
143 Nieto Ave SW #1
Long Beach, CA 90815
562-799-1577
web www.members.aol.com/zsmrtfred/

SPEC-COM Journal
PO Box 1002
Dubuque, IA 52004-1002
319-557-8791
fax 319-583-6462

Spectrum International, Inc
PO Box 1084
Concord, MA 01742
508-263-2145
fax 508-263-7008

Star Circuits
PO Box 94917
Las Vegas, NV 89193
800-433-6319

Star-Tronics
PO Box 98102
Las Vegas, NV 89193-8102
702-795-7151 (voice and **fax**)

Steinmetz Electronics
7519 Maplewood Ave
Hammond, IN 46324
219-931-9316

Sunlight Energy Systems
955 Manchester Ave SW
N Lawrence, OH 44666
330-832-4161

Surplus Sales of Nebraska
1502 Jones St
Omaha, NE 68102-3112
800-244-4567 (orders)
402-346-4750
fax 402-346-2939
e-mail grinnell@surplussales.com
web www.surplussales.com/

Surplus Traders
PO Box 276, Winters Ln
Alburt, VT 05440
514-739-9328
fax 514-345-8303
e-mail marv@73.com
web www.73.com/a/

Svetlana Electron Devices
8200 S. Memorial Parkway
Huntsville, AL 35802
256-882-1344
800-239-6900
fax 256-880-8077
e-mail sales@svetlana.com
web www.svetlana.com/

TAB/McGraw-Hill, Inc
860 Taylor Station Rd
Blacklick, OH 43004
800-262-4729
fax 614-759-3641
e-mail customer.service@mcgraw-hill.com

Tandy National Parts
900 E Northside Dr
Ft Worth, TX 76102
800-322-3690
fax 817-870-5626

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

TCE Labs
2365 Waterfront Park Dr
Canyon Lake, TX 78133
830-899-4575

TE Systems
PO Box 25845
Los Angeles, CA 90025
310-478-0591
fax 310-473-4038

Tech America
PO Box 1981
Fort Worth, TX 76101-1981
web www.techam.com
800-877-0072

Tejas RF Technology
PO Box 720331
Houston, TX 77272-0331
713-879-9300
fax 713-879-9494

Telecom Industries
1385 Akron St
Copaigue, NY 11726
516-789-5020

Teletec Corp
10101 Capital Blvd
Wake Forest, NC 27587
909-556-7800

Telex Communications, Inc
8601 East Cornhusker Highway
Lincoln, NE 68505
402-467-5321
402-465-7021 (parts and service)
fax 402-467-3279

Tempo Research Corp
—see [AEA](#)

Ten-Tec, Inc
1185 Dolly Parton Pkwy
Sevierville, TN 37862
423-453-7172
fax 423-428-4483
web www.tentec.com/

Texas Towers
1108 Summit Ave, Suite 4
Plano, TX 75074
800-272-3467
972-422-7306 (Tech)
fax 972-881-0776
e-mail sales@texastowers.com
web www.texastowers.com/

Timewave Technology, Inc
2401 Pilot Knob Rd
Suite 134
St Paul MN 55120
612-452-5939
fax 612-452-4571

Toroid Corp of Maryland
202 Northwood Dr
Salisbury, MD 21801
410-860-0300
fax 410-860-0302

Tri-Ex Tower Corp
7182 Rasmussen Ave
Visalia, CA 93291
800-328-2393 (orders)
209-651-7850 ext. 352 or 353
(Tech Support)
fax 209-651-5157

Trinity Software
7801 Rice Dr
Rowlett, TX 75088
972-475-7132

Tucson Amateur Packet Radio
8987-309 E Tanque Verde Rd,
#337
Tucson, AZ 85749-9399
817-383-0000 (voice mail)
fax 817-566-2544
e-mail tapr@tapr.org
web www.tapr.org

TX RX Systems, Inc
8625 Industrial Pky
Angola, NY 14006
716-549-4700
fax 716-549-4772

Typetronics
PO Box 8873
Fort Lauderdale, FL 33310-8873
954-583-1340
fax 954-583-0777

Unified Microsystems
PO Box 133
Slinger, WI 53086
414-644-9036
fax 414-644-9036
e-mail uns@nconnect.net

United Nations Bookstore
UN General Assembly Building,
Room 32B
New York, NY 10017

Universal Manufacturing Co
43900 Groesbeck Hwy
Clinton Township, MI 48036
810-463-2560
fax 810-463-2964

US Electronics
585 North Bicycle Path
Port Jefferson Station, NY 11776
516-331-2552
e-mail info@uselec.com
web www.uselectronics.com/

US Government Printing Office
Washington, DC 20402-9371
202-783-3238
202-512-1800 (credit card orders)
web www.gpo.gov/

US Plastic Corp
1390 Neubrecht Rd
Lima, OH 45801
800-537-9724
fax 419-228-5034

US Tower Corp
1220 Marcin St
Visalia, CA 93291
209-733-2438
fax 209-733-7194

VK3UM EME Planner
Doug McArthur
30 Rolloway Rise
Chirnside Park 3116
Australia

The W5YI Group
PO Box 565101
Dallas, TX 75356
800-669-9594 (orders)
817-274-0400
e-mail w5yi@w5yi.org
web www.w5yi.org/

W6EL Software
11058 Queensland St
Los Angeles, CA 90034-3029
310-473-7322
e-mail ad363@lafn.org

W7FG Vintage Manuals
3300 Wayside Dr
Bartlesville, OK 74006
800-807-6146 (orders)
918-333-3754
e-mail w7fg@eigen.net
web www.w7fg.com/

Continued on [next page](#).

ARRL Handbook Address List

Continued from [previous page](#).

Watkins-Johnson Company,
Telecommunications Group
700 Quince Orchard Rd
Gaithersburg, MD 20878-1794
301-948-7550
800-954-3577
(800-WJ-HELPS)
fax 301-921-7479
e-mail wjhelps@wj.com or
mike.cox@wj.com
web www.wj.com/

Ed Wetherhold, W3NQN
1426 Catlyn Pl
Annapolis, MD 21401-4208
410-268-0916
fax 410-268-4779

Wilderness Radio
PO Box 734
Los Altos, CA 94023-0734
650-494-3806
e-mail qrpbob@datamers.com
web www.fix.net/jparker/wild.html

Winegard
3000 Kirkwood St
Burlington, IA 52601-1007

The Wireman Inc
261 Pittman Rd
Landrum, SC 29356-9544
800-727-WIRE (800-727-9473)
Orders only
864-895-4195 Technical
fax 864-895-5811
e-mail info@thewireman.com
web www.thewireman.com/

Worldradio
2120 28th St
Sacramento, CA 95818
916-457-3655
800-366-9192 (subscriptions)
e-mail kb6hp@ms.net
web www.wr6w.com/

Wyman Research, Inc
8339 South, 850 West
Waldron, IN 46182-9644
765-525-6452

Yaesu U.S.A.
17210 Edwards Rd
Cerritos, CA 90703
562-404-2700
fax 562-404-1210
e-mail yaesu@worldnet.att.net
web www.yaesu.com/

Zero Surge
944 State Rte 12
Frenchtown NJ 08825
908-996-7700
fax 908-996-7773

Z-TRAK
RFD 1 Box 33
Milo, ME 04463

73 Amateur Radio Today
70 Route 202N
Peterborough, NH 03458
603-924-0058
800-274-7373 (subscriptions)

Technical Information Packages

The following is a list of information packages and bibliographies that are available to provide assistance for technical problems and introductory information on topics of interest. To request paper copies of an information package, send a separate written request to the ARRL Technical Secretary. Enclose a check or money order for the amount of \$2 for ARRL Members or \$4 for non-members for each package requested (covers the cost of photocopying and mailing).

To request paper copies of article bibliographies, send a written request to the ARRL Technical Secretary and enclose a large (9 × 12) envelope, self-addressed and postage paid. There is no fee for bibliographies, but there is a charge for article copies as explained on each article list.

Most of these packages are also available electronically at no charge from the Technical Information Service web pages: <http://www.arrl.org/tis/>.

Package Title	Description
Alternate/Emergency Power	Reference to <i>QST</i> , Apr 1993 Lab Notes
ATV	Information about Fast-Scan Amateur Television
Buying a Rig	What Rig Should I Buy?? (Reprints from <i>QST</i>)
Digital Modes	Getting started in: AMTOR, APRS, Packet, RTTY, TCP/IP, PSK31, WEFAX
DSP	General information on Digital Signal Processing
Electrical Safety	Reprint from <i>ARRL Antenna Book</i> (pp 1-8 to 1-16)
EMI/RFI Pkg.	General information about EMI/RFI
EMI — Audio	Interference to audio equipment
EMI — Automotive	Automotive Interference solutions
EMI — Bibliography	List of <i>QST</i> articles about interference
EMI — CATVI	Interference to Cable Television Systems (Reprints from Communications Technology)
EMI — CB	Interference from Non-Amateur Transmitters
EMI — Computer	Reprint from <i>QST</i> , Sep 1995 Lab Notes
EMI — Consumer	Consumer Pamphlet on RFI
EMI — Electrical	How to track and solve electrical interference
EMI — Ignition	Suggestions for solving ignition noise RFI
EMI — Pacemaker	Susceptibility of Cardiac Pacemakers to interference
EMI — RF Bulbs	Information about RF-driven lamps
EMI — Smoke Detector	Interference to Smoke Detectors (Reprints from <i>QST</i> , Nov 1980 and Feb 1981)
EMI — Telephone/FCC	FCC Information Bulletin on Telephone Interference
EMI — Telephones	Reprint from <i>QST</i> , Oct 1992 Lab Notes
EMI — Television	Reprint from <i>QST</i> , Mar 1994 Lab Notes
EMI — Touch Lamp	Various <i>QST</i> Hints & Kinks reprints
EMI — VCR	Brief suggestions
G5RV	Bibliography of G5RV articles, and reprint from <i>Antenna Compendium I</i>
Grid Squares	How to Locate them (Reprint from Jan 1989 <i>QST</i> , p 29)
Indoor Antennas	Select an Indoor Antenna (Reprint from <i>QST</i> , Dec 1992 Lab Notes)
Lightning Protection	Reprint of two-part Lab Notes column
Mobile — Marine	Maritime Mobile Installation suggestions
Moonbounce/EME	Information about moonbounce (Reprint from <i>QST</i> , July 1985, pp 18-21)
Packet	Beginner Packet, TCP/IP, address coordinators
Propagation	Propagation Introduction and Terms explained
RF Exposure	Overview of FCC RF exposure regulations
Satellites	Information about amateur satellite operation
SSTV	Reprint from <i>QST</i> , Jan 1993, p 20
Synchronous Detection	Reprint from <i>QEX</i> , Sep 1992, p 9
TV Channels	CATV General Information

TIS Bibliography List

These bibliography files are provided by the ARRL Technical Information Service.

The following items are lists of articles from many Amateur Radio magazines and other related publications, by subject. To request paper copies of article bibliographies, send a written request to the Technical Secretary, ARRL, 225 Main Street, Newington, CT 06111, and enclose a large (9 × 12) self-addressed, stamped envelope with two units of first class postage. There is no fee for bibliographies, but there is a charge for article copies as explained in each article list. They can also be found at <http://www.arrl.org/tis/bibs/>.

Title	File	Title	File
AMTOR Articles	amtora.html	Heathkit	heath.html
Alternate Power	altpwr.html	Historical References	historic.html
Amateur FAX/WEFAX	fax.html	Homebrew Components	hmbrcmp.html
Amateur Fast-Scan Television (ATV)	atv.html	ICOM equipment & mods	icom.html
Antenna Rotators	antrot.html	Integrated Circuits	ic.html
Antenna Switchers	antswite.html	Kenwood equipment and mods	kenwood.html
Antenna Theory	anttheor.html	Keys, Keyers and Keying	keyer.html
Antennas, 160-40 Meter	ant16040.html	Laser Communications	light.html
Antennas, 30-10 Meter	ant3010.html	Lightning	lghtnbib.html
Antennas, End-Fed and Long Wire	antendfd.html	MFJ Products	mfj.html
Antennas, J Poles	antjpole.html	Maritime Mobile Operation	maritime.html
Antennas, Mobile	antmobil.html	Microwave Operation	microwv.html
Antennas, VHF and up	antvhf.html	NBVM	nbvm.html
Antennas, Vee	antvee.html	Oscilloscopes	oscope.html
Antennas, Vertical	antvert.html	Packet Radio	packbib.html
Antennas, curtain type	antcurt.html	Pactor (Digital Mode)	pactrbib.html
Antennas, limited space	antlimsp.html	Phone Patches	fonpatch.html
Antennas, log periodic	antlog.html	Power Supplies	pwrstpp.html
Antennas, loop	antloop.html	Printed circuit boards	pcbrd.html
Antennas, matching	antmatch.html	Propagation	prop.html
BC-221 (Freq Meter) Articles	bc221.html	Public Service Communications	public.html
Balloons and Ballooning	balloon.html	QRP - Articles on low power	qrp.html
Basic Construction	basconst.html	RF Energy Safety	rfsafe.html
Basic Electronics	baselect.html	RFI, Pacemaker	rfipcmkr.html
Batteries, Nicads and Chargers	battery.html	Radio Astronomy	radastro.html
Bicycle Operating	bicycle.html	Radio Frequency Interference (RFI)	rfi.html
CB Conversion to 10 Meters	cbconv.html	Radio TeleTYpe (RTTY)	rtty.html
CTCSS - sub-audible tone encode/decode	ctcssbib.html	Receivers, HF	rcvrhf.html
Clover (Digital Protocol)	clover.html	Receivers, VHF and up	rcvrvhf.html
Coax cables and feedlines	coax.html	Remote Control	remote.html
Collins equipment	collins.html	Repeaters	rptr.html
Computers, Apple	apple.html	SWR/Power Meters	swr.html
Computers, Atari	atari.html	Safety	safety.html
Computers, IBM	ibm.html	Satellite (amateur)	satbib.html
Computers, Programs	prog.html	Shuttle Amateur Radio EXperiment	sarex.html
Computers, Radio Shack	trs.html	Slow-Scan Television	sstvbib.html
Computers, VIC and Commodore	vic.html	Speech Processing	speech.html
Computers, general	compgen.html	Spread Spectrum	spread.html
Computers, microprocessor	up.html	Station Accessories Proj.	projacc.html
Contesting	contest.html	Surface Mount Devices	surface.html
Crystals	crystal.html	Surplus Equipment	surplus.html
DTMF - tone decoders	dtmf.html	Synthesizers	synth.html
Digital Signal Processing	dsp.html	Television	tv.html
Direction finding, Radio (RDF)	dfing.html	Ten Tec products	tentec.html
Diversity Reception	diverse.html	Test equipment	testeqpt.html
Drake Equipment	drake.html	Time Signals	time.html
Earth-Moon-Earth Communications	eme.html	Towers/tower safety	tower.html
Echoes (including LDE)	echo.html	Transmit/Receive Switching	trswitch.html
Electro-static discharge	esd.html	Transmitters, HF	xmtrhf.html
Fiber Optics	fiber.html	Transmitters, VHF and up	xmtrvhf.html
Filters, IF	filterif.html	Transverters	transvtr.html
Filters, RF	filterrf.html	Very Low Frequency (VLF) and lower	vlf.html
Filters, audio	filteraf.html	WARC Band equipment	warc.html
Grounds	grounds.html	Weak Signal Reception	weaksig.html
Handicap (suitable equip.)	handicap.html	Yaesu equipment and mods	yaesu.html

Voltage-Power Conversion Table

Based on a 50-ohm system

Voltage			Power	
RMS	Peak-to-Peak	dBmV	Watts	dBm
0.01 μ V	0.0283 μ V	-100	2×10^{-18}	-147.0
0.02 μ V	0.0566 μ V	-93.98	8×10^{-18}	-141.0
0.04 μ V	0.113 μ V	-87.96	32×10^{-18}	-134.9
0.08 μ V	0.226 μ V	-81.94	128×10^{-18}	-128.9
0.1 μ V	0.283 μ V	-80.0	200×10^{-18}	-127.0
0.2 μ V	0.566 μ V	-73.98	800×10^{-18}	-121.0
0.4 μ V	1.131 μ V	-67.96	3.2×10^{-15}	-114.9
0.8 μ V	2.236 μ V	-61.94	12.8×10^{-15}	-108.9
1.0 μ V	2.828 μ V	-60.0	20.0×10^{-15}	-107.0
2.0 μ V	5.657 μ V	-53.98	80.0×10^{-15}	-101.0
4.0 μ V	11.31 μ V	-47.96	320.0×10^{-15}	-94.95
8.0 μ V	22.63 μ V	-41.94	1.28×10^{-12}	-88.93
10.0 μ V	28.28 μ V	-40.00	2.0×10^{-12}	-86.99
20.0 μ V	56.57 μ V	-33.98	8.0×10^{-12}	-80.97
40.0 μ V	113.1 μ V	-27.96	32.0×10^{-12}	-74.95
80.0 μ V	226.3 μ V	-21.94	128.0×10^{-12}	-68.93
100.0 μ V	282.8 μ V	-20.0	200.0×10^{-12}	-66.99
200.0 μ V	565.7 μ V	-13.98	800.0×10^{-12}	-60.97
400.0 μ V	1.131 mV	-7.959	3.2×10^{-9}	-54.95
800.0 μ V	2.263 mV	-1.938	12.8×10^{-9}	-48.93
1.0 mV	2.828 mV	0.0	20.0×10^{-9}	-46.99
2.0 mV	5.657 mV	6.02	80.0×10^{-9}	-40.97
4.0 mV	11.31 mV	12.04	320×10^{-9}	-34.95
8.0 mV	22.63 mV	18.06	1.28 μ W	-28.93
10.0 mV	28.28 mV	20.00	2.0 μ W	-26.99
20.0 mV	56.57 mV	26.02	8.0 μ W	-20.97
40.0 mV	113.1 mV	32.04	32.0 μ W	-14.95
80.0 mV	226.3 mV	38.06	128.0 μ W	-8.93
100.0 mV	282.8 mV	40.0	200.0 μ W	-6.99
200.0 mV	565.7 mV	46.02	800.0 μ W	-0.97
223.6 mV	632.4 mV	46.99	1.0 mW	0
400.0 mV	1.131 V	52.04	3.2 mW	5.05
800.0 mV	2.263 V	58.06	12.80 mW	11.07
1.0 V	2.828 V	60.0	20.0 mW	13.01
2.0 V	5.657 V	66.02	80.0 mW	19.03
4.0 V	11.31 V	72.04	320.0 mW	25.05
8.0 V	22.63 V	78.06	1.28 W	31.07
10.0 V	28.28 V	80.0	2.0 W	33.01
20.0 V	56.57 V	86.02	8.0 W	39.03
40.0 V	113.1 V	92.04	32.0 W	45.05
80.0 V	226.3 V	98.06	128.0 W	51.07
100.0 V	282.8 V	100.0	200.0 W	53.01
200.0 V	565.7 V	106.0	800.0 W	59.03
223.6 V	632.4 V	107.0	1000.0 W	60.0
400.0 V	1,131.0 V	112.0	3,200.0 W	65.05
800.0 V	2,263.0 V	118.1	12,800.0 W	71.07
1000.0 V	2,828.0 V	120.0	20,000 W	73.01
2000.0 V	5,657.0 V	126.0	80,000 W	79.03
4000.0 V	11,310.0 V	132.0	320,000 W	85.05
8000.0 V	22,630.0 V	138.1	1.28 MW	91.07
10,000.0 V	28,280.0 V	140.0	2.0 MW	93.01

Continued on [next page](#).

Voltage-Power Conversion Table

Continued from [previous page](#).


$$\text{Voltage, } V_{p-p} = V_{\text{RMS}} \times \sqrt{2}$$

$$\text{Voltage, dBmV} = 20 \times \text{Log}_{10} \left[\frac{V_{\text{RMS}}}{0.001\text{V}} \right]$$

$$\text{Power, Watts} = \left[\frac{V_{\text{RMS}}^2}{50 \Omega} \right]$$

$$\text{Power, dBm} = 10 \times \text{Log}_{10} \left[\frac{\text{Power (watts)}}{0.001\text{W}} \right]$$

Measured inductance for #12 Wire Windings




Values are for inductors with half-inch leads and wound with eight turns per inch.

Large Machine-Wound Coil Specifications

Coil Dia, Inches	Turns Per Inch	Inductance in μH
1 $\frac{1}{4}$	4	2.75
	6	6.3
	8	11.2
	10	17.5
	16	42.5
1 $\frac{1}{2}$	4	3.9
	6	8.8
	8	15.6
	10	24.5
	16	63
1 $\frac{3}{4}$	4	5.2
	6	11.8
	8	21
	10	33
	16	85
2	4	6.6
	6	15
	8	26.5
	10	42
	16	108
2 $\frac{1}{2}$	4	10.2
	6	23
	8	41
	10	64
3	4	14
	6	31.5
	8	56
	10	89

Inductance Factor for Large Machine-Wound Coils




Factor to be applied to the inductance of large coils for coil lengths up to 5 inches.

Small Machine-Wound Coil Specifications

Coil Dia, Inches	Turns Per Inch	Inductance in μH
1/2 (A)	4	0.18
	6	0.40
	8	0.72
	10	1.12
	16	2.8
	32	12
5/8 (A)	4	0.28
	6	0.62
	8	1.1
	10	1.7
	16	4.4
	32	18
3/4 (B)	4	0.6
	6	1.35
	8	2.4
	10	3.8
	16	9.9
	32	40
1 (B)	4	1.0
	6	2.3
	8	4.2
	10	6.6
	16	16.9
	32	68

Inductance Factor for Small Machine-Wound Coils



Factor to be applied to the inductance of small coils as a function of coil length. Use curve A for coils marked A, and curve B for coils marked B.

How to Use the Standard Value Capacitor (SVC) Filter Tables

Detailed instructions for using these tables appear in the Filters chapter. If you are unfamiliar with filter design from tables, look there to learn the basics. This simple example is intended as a memory aid, not a tutorial.

Let's design a low-pass filter for a 20-m CW transmitter. Based on measurements of the second harmonic, insertion loss (attenuation) should be at least 20 dB at the minimum second-harmonic frequency (28 MHz). Insertion loss should be minimal at the maximum operating frequency (14.1 MHz).

When choosing a filter, look for appropriate cutoff and attenuation frequencies, but *ignore the decimal points* because the component values are easily scaled by powers of ten. A 5-element Chebyshev design looks like a good choice because designs 20 through 22 show 20-dB frequencies of 2.73 and 2.77 MHz and cutoff frequencies of 1.44 to 1.66 MHz. In fact, those numbers are *too* close to our targets (27.7 MHz is only 1.1% under 28 MHz). Using 5% components, we would be lucky to get within 5% of the design targets. It's better to move each target value 10% or so to the safe side, which yields 20 dB at 25.2 MHz and $f_{co} = 15.5$ MHz. No 5-element design in the table can meet these criteria.

In the 7-element Chebyshev list, however, design 25 meets the needs. It has a maximum SWR of 1.099:1, which is acceptable.

FREQUENCY (MHz)

NO.	F_{co}	3 dB	20 dB	40 dB	MAX SWR	C1,7 (pF)	L2,6 (μ H)	C3,5 (pF)	L4 (μ H)
25	1.68	1.93	2.35	3.03	1.099	1500	6.58	3300	7.72

Scaling the filter is easy. We need only divide one of the frequencies listed into the desired frequency, round to the nearest power of ten and multiply all frequencies and divide all component values by the result: $28/2.35 = 11.91$, say 10; which gives:

FREQUENCY (MHz)

NO.	F_{co}	3 dB	20 dB	40 dB	MAX SWR	C1,7 (pF)	L2,6 (μ H)	C3,5 (pF)	L4 (μ H)
25	16.8	19.3	23.5	30.3	1.099	150	0.658	330	0.772

In some cases, the filter terminating impedances may not be 50 Ω . Then we need to adjust the filter values to match the required impedance. All tabulated designs are easily scaled to impedance levels other than 50 Ω , while keeping the convenience of standard-value capacitors and the "scan mode" of design selection. If the desired new impedance level differs from 50 Ω by a factor that is some power of ten, the 50- Ω design is scaled by shifting the decimal points of the component values, that is multiplying or dividing by some power of ten. The other data remain unchanged. For example, if the impedance level is increased by ten or one hundred times (to 500 or 5000 Ω), the decimal point of the capacitor is shifted to the left (dividing) one or two places and the decimal point of the inductor is shifted to the right (multiplying) one or two places. With increasing impedance, capacitor values decrease and inductor values increase. The opposite is true when impedance decreases.

When the desired impedance level differs from the standard 50- Ω value by a factor that is not a power of ten, such as 1.2, 1.5 or 1.86, the search criteria to select the design number must be adjusted by that factor:

1. Calculate the impedance scaling ratio:

$$R = \frac{Z_x}{50} \quad (1)$$

where Z_x is the desired new impedance level, in ohms.

2. Calculate the cutoff frequency (f_{50co}) of a "trial" 50- Ω filter,

$$f_{50co} = R \times f_{xco} \quad (2)$$

where R is the impedance scaling ratio and f_{xco} is the desired cutoff frequency of the filter at the new impedance level.

3. Select a design from the SVC tables based on the calculated f_{50co} . The capacitor values of this design are taken directly, but the frequency and inductor values must be scaled to the new impedance level.

Continued on [next page](#).

How to Use the Standard Value Capacitor (SVC) Filter Tables

Continued from [previous page](#).

4. Calculate the exact f_{xco} values, where

$$f_{xco} = \frac{f'_{50co}}{R} \quad (3)$$

and f'_{50co} is the tabulated cutoff frequency of the selected design. Calculate the other frequencies of the design in the same way.

5. Calculate the inductor values for the new filter by multiplying the tabulated inductor values of the selected design by the square of the scaling ratio, R .

For example, assume that our 20-m low-pass filter were to be used in a 1000- Ω IF stage. This requires that we apply both methods, because a change from 50 to 1000 involves factors of 10 and 2 ($50 \times 2 \times 10 = 1000$). Therefore, we must first scale the desired frequencies by from 50 Ω to 100 Ω ($50 \times 2 = 100$):

$$R = 100/50 = 2$$

$$f_{50co} = 2 \times 15.5 = 31 \text{ MHz}$$

$$f_{20dB} = 2 \times 25.2 = 50.4 \text{ MHz}$$

Select a filter based on these two values. Design 59 from the 7-element low-pass Chebyshev list looks good. Scale all frequencies of the final design by dividing the tabulated frequencies impedance scaling ratio, 2:

$$f_{co} = 3.3/2 = 1.65$$

$$f_{20dB} = 4.81/2 = 2.405$$

The inductor values are scaled to 100 Ω by multiplying them by the square of the impedance ratio, where $R = 2$ and $R^2 = 4.0$:

$$L_{2,6} = 4.0 \times 3.24 \mu\text{H} = 12.96 \mu\text{H}$$

$$L_4 = 4.0 \times 3.88 \mu\text{H} = 15.52 \mu\text{H}$$

The 100- Ω design is now impedance scaled to 1000 Ω by shifting the decimal points of the capacitor values to the left and the decimal points of the inductor values to the right. The final scaled component values for the 1000- Ω filter are:

$$C_{1,7} = 68 \text{ pF}$$

$$C_{3,5} = 160 \text{ pF}$$

$$L_{2,6} = 129.6 \mu\text{H}$$

$$L_4 = 155.2 \mu\text{H}.$$

5-Element Chebyshev Low-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values

Filter No.	F_{co}	Frequency (MHz)			Max SWR	C1,5 (pF)	L2,4 (μ H)	C3 (pF)
		3 dB	20 dB	40 dB				
1	1.01	1.15	1.53	2.25	1.355	3600	10.8	6200
2	1.02	1.21	1.65	2.45	1.212	3000	10.7	5600
3	1.15	1.29	1.71	2.51	1.391	3300	9.49	5600
4	1.10	1.32	1.81	2.69	1.196	2700	9.88	5100
5	1.25	1.41	1.88	2.75	1.386	3000	8.67	5100
6	1.04	1.37	1.94	2.94	1.085	2200	9.82	4700
7	1.15	1.41	1.95	2.92	1.155	2400	9.37	4700
8	1.32	1.50	2.01	2.96	1.332	2700	8.29	4700
9	1.13	1.50	2.12	3.22	1.081	2000	9.00	4300
10	1.26	1.54	2.13	3.19	1.157	2200	8.56	4300
11	1.39	1.61	2.18	3.21	1.276	2400	7.88	4300
12	1.05	1.62	2.38	3.66	1.028	1600	8.35	3900
13	1.23	1.65	2.34	3.55	1.076	1800	8.19	3900
14	1.39	1.70	2.35	3.51	1.159	2000	7.75	3900
15	1.55	1.79	2.41	3.55	1.295	2200	7.05	3900
16	1.17	1.76	2.57	3.94	1.033	1500	7.70	3600
17	1.27	1.77	2.55	3.88	1.057	1600	7.64	3600
18	1.46	1.82	2.54	3.81	1.135	1800	7.28	3600
19	1.65	1.92	2.59	3.83	1.268	2000	6.64	3600
20	1.88	2.08	2.73	3.97	1.497	2200	5.70	3600
21	1.43	1.94	2.77	4.21	1.068	1500	6.96	3300
22	1.54	1.97	2.77	4.17	1.109	1600	6.79	3300
23	1.76	2.07	2.81	4.17	1.238	1800	6.21	3300
24	2.02	2.25	2.96	4.31	1.470	2000	5.31	3300
25	1.31	2.10	3.11	4.79	1.022	1200	6.43	3000
26	1.48	2.12	3.06	4.68	1.046	1300	6.39	3000
27	1.75	2.19	3.05	4.57	1.135	1500	6.07	3000
28	1.89	2.25	3.08	4.57	1.206	1600	5.77	3000
29	2.19	2.45	3.23	4.71	1.440	1800	4.92	3000
30	1.51	2.34	3.44	5.29	1.026	1100	5.78	2700
31	1.70	2.36	3.40	5.17	1.057	1200	5.73	2700
32	1.87	2.40	3.38	5.10	1.104	1300	5.57	2700
33	2.20	2.56	3.46	5.11	1.268	1500	4.98	2700
34	2.39	2.69	3.56	5.21	1.406	1600	4.53	2700
35	1.75	2.63	3.85	5.91	1.033	1000	5.14	2400
36	1.99	2.67	3.81	5.78	1.072	1100	5.05	2400
37	2.19	2.74	3.81	5.71	1.135	1200	4.85	2400
38	2.40	2.84	3.86	5.73	1.227	1300	4.55	2400
39	1.89	2.87	4.21	6.47	1.030	910	4.71	2200
40	2.14	2.91	4.16	6.31	1.068	1000	4.64	2200
41	2.39	2.99	4.16	6.23	1.135	1100	4.45	2200
42	2.64	3.11	4.22	6.25	1.238	1200	4.14	2200
43	2.93	3.29	4.36	6.39	1.398	1300	3.71	2200
44	2.05	3.16	4.64	7.13	1.028	820	4.28	2000
45	2.36	3.20	4.57	6.94	1.068	910	4.22	2000
46	2.63	3.28	4.57	6.86	1.135	1000	4.05	2000
47	2.93	3.43	4.65	6.89	1.251	1100	3.73	2000
48	3.29	3.67	4.85	7.07	1.440	1200	3.28	2000
49	2.34	3.51	5.14	7.88	1.033	750	3.85	1800
50	2.63	3.56	5.08	7.71	1.069	820	3.79	1800
51	2.96	3.66	5.09	7.62	1.145	910	3.61	1800
52	3.30	3.84	5.19	7.67	1.268	1000	3.32	1800
53	3.76	4.15	5.45	7.93	1.497	1100	2.85	1800
54	2.70	3.96	5.76	8.82	1.039	680	3.42	1600

Continued on [next page](#).

5-Element Chebyshev Low-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values


Continued from [previous page](#).

Filter No.	F_{co}	Frequency (MHz)			Max SWR	C1,5 (pF)	L2,4 (μ H)	C3 (pF)
		3 dB	20 dB	40 dB				
55	3.06	4.03	5.71	8.63	1.086	750	3.34	1600
56	3.38	4.14	5.73	8.57	1.159	820	3.18	1600
57	3.82	4.39	5.89	8.67	1.311	910	2.86	1600
58	2.77	4.21	6.18	9.48	1.030	620	3.21	1500
59	3.14	4.26	6.10	9.26	1.067	680	3.17	1500
60	3.51	4.38	6.10	9.14	1.135	750	3.03	1500
61	3.88	4.56	6.20	9.17	1.241	820	2.82	1500
62	4.46	4.95	6.51	9.48	1.473	910	2.41	1500
63	3.39	4.88	7.08	10.8	1.044	560	2.77	1300
64	3.84	4.98	7.02	10.6	1.097	620	2.70	1300
65	4.26	5.14	7.08	10.5	1.181	680	2.55	1300
66	4.79	5.46	7.29	10.7	1.341	750	2.28	1300
67	3.61	5.28	7.68	11.8	1.039	510	2.56	1200
68	4.06	5.36	7.61	11.5	1.083	560	2.51	1200
69	4.55	5.54	7.65	11.4	1.167	620	2.37	1200
70	5.07	5.84	7.84	11.5	1.304	680	2.16	1200
71	3.96	5.76	8.38	12.8	1.041	470	2.35	1100
72	4.39	5.84	8.31	12.6	1.079	510	2.31	1100
73	4.88	6.01	8.33	12.5	1.152	560	2.20	1100
74	5.50	6.34	8.54	12.6	1.293	620	1.99	1100
75	4.40	6.34	9.20	14.1	1.043	430	2.13	1000
76	4.91	6.45	9.13	13.8	1.087	470	2.09	1000
77	5.38	6.62	9.17	13.7	1.154	510	2.00	1000
78	6.00	6.95	9.37	13.8	1.282	560	1.83	1000
79	4.81	6.97	10.1	15.5	1.042	390	1.94	910
80	5.43	7.09	10.0	15.2	1.091	430	1.89	910
81	6.00	7.31	10.1	15.1	1.167	470	1.80	910
82	6.60	7.64	10.3	15.2	1.283	510	1.66	910
83	4.86	7.69	11.4	17.5	1.023	330	1.76	820
84	5.51	7.76	11.2	17.1	1.052	360	1.74	820
85	6.07	7.89	11.1	16.8	1.095	390	1.70	820
86	6.77	8.17	11.2	16.7	1.184	430	1.60	820
87	7.54	8.61	11.5	17.0	1.327	470	1.45	820
88	5.26	8.40	12.4	19.2	1.022	300	1.61	750
89	6.04	8.49	12.2	18.7	1.052	330	1.59	750
90	6.70	8.64	12.2	18.4	1.101	360	1.55	750
91	7.33	8.89	12.3	18.3	1.175	390	1.48	750
92	8.24	9.42	12.6	18.5	1.327	430	1.33	750
93	6.69	9.36	13.5	20.6	1.054	300	1.44	680
94	7.48	9.56	13.4	20.2	1.110	330	1.40	680
95	8.25	9.89	13.6	20.2	1.196	360	1.32	680
96	9.10	10.4	13.9	20.4	1.328	390	1.20	680
97	7.21	10.2	14.8	22.6	1.048	270	1.32	620
98	8.18	10.5	14.7	22.2	1.107	300	1.28	620
99	9.11	10.9	14.9	22.1	1.203	330	1.19	620
100	10.1	11.5	15.3	22.5	1.355	360	1.08	620
101	7.82	11.3	16.4	25.1	1.042	240	1.19	560
102	9.02	11.6	16.3	24.6	1.105	270	1.16	560
103	8.66	12.4	18.0	27.6	1.044	220	1.09	510
104	9.64	12.6	17.9	27.1	1.088	240	1.06	510
105	9.22	13.5	19.6	30.0	1.039	200	1.00	470
106	9.85	14.7	21.5	33.0	1.034	180	0.919	430

Continued on [next page](#).

5-Element Chebyshev Low-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values

Continued from [previous page](#).



The schematic for a 5-element capacitor input/output Chebyshev low-pass filter is shown at A. At B is the typical attenuation response curve.

7-Element Chebyshev Low-Pass Filter Designs—50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values

Filter No.	Frequency (MHz)				Max SWR	C1,7 (pF)	L2,6 (μH)	C3,5 (pF)	L4 (μH)
	F_{co}	3 dB	20 dB	40 dB					
1	1.02	1.10	1.31	1.65	1.254	3300	11.2	6200	12.6
2	1.04	1.16	1.40	1.79	1.142	2700	10.9	5600	12.6
3	1.13	1.23	1.45	1.84	1.264	3000	10.1	5600	11.3
4	1.05	1.23	1.51	1.96	1.071	2200	10.3	5100	12.3
5	1.12	1.26	1.53	1.96	1.123	2400	10.0	5100	11.7
6	1.23	1.34	1.59	2.01	1.247	2700	9.29	5100	10.4
7	1.03	1.30	1.63	2.15	1.030	1800	9.52	4700	11.9
8	1.12	1.33	1.64	2.13	1.064	2000	9.50	4700	11.4
9	1.21	1.37	1.66	2.13	1.119	2200	9.27	4700	10.8
10	1.29	1.42	1.70	2.16	1.200	2400	8.82	4700	10.0
11	1.10	1.41	1.79	2.36	1.023	1600	8.68	4300	11.0
12	1.21	1.45	1.79	2.33	1.058	1800	8.71	4300	10.5
13	1.31	1.49	1.81	2.33	1.114	2000	8.50	4300	9.91
14	1.42	1.56	1.86	2.36	1.202	2200	8.06	4300	9.14
15	1.54	1.65	1.93	2.43	1.336	2400	7.39	4300	8.18
16	1.25	1.57	1.97	2.59	1.031	1500	7.90	3900	9.85
17	1.32	1.59	1.97	2.57	1.050	1600	7.91	3900	9.62
18	1.44	1.64	1.99	2.56	1.109	1800	7.73	3900	9.04
19	1.57	1.72	2.05	2.60	1.205	2000	7.30	3900	8.27
20	1.44	1.73	2.14	2.78	1.056	1500	7.29	3600	8.82
21	1.52	1.76	2.15	2.78	1.086	1600	7.22	3600	8.54
22	1.66	1.84	2.20	2.81	1.176	1800	6.86	3600	7.83
23	1.83	1.96	2.30	2.90	1.327	2000	6.22	3600	6.90
24	1.51	1.86	2.32	3.05	1.037	1300	6.70	3300	8.27
25	1.68	1.93	2.35	3.03	1.099	1500	6.58	3300	7.72
26	1.77	1.98	2.38	3.05	1.147	1600	6.40	3300	7.37
27	1.96	2.11	2.49	3.14	1.294	1800	5.83	3300	6.50
28	1.56	2.02	2.56	3.38	1.021	1100	6.04	3000	7.68
29	1.68	2.05	2.56	3.35	1.042	1200	6.09	3000	7.47
30	1.79	2.09	2.57	3.33	1.073	1300	6.05	3000	7.21
31	1.99	2.20	2.64	3.37	1.176	1500	5.72	3000	6.52
32	2.11	2.28	2.70	3.42	1.257	1600	5.42	3000	6.08
33	1.75	2.25	2.84	3.75	1.023	1000	5.45	2700	6.89
34	1.89	2.29	2.84	3.71	1.048	1100	5.48	2700	6.68
35	2.02	2.34	2.86	3.70	1.086	1200	5.41	2700	6.40
36	2.15	2.41	2.90	3.72	1.141	1300	5.26	2700	6.06
37	2.44	2.61	3.07	3.86	1.327	1500	4.66	2700	5.18
38	2.01	2.54	3.20	4.21	1.027	910	4.86	2400	6.09
39	2.17	2.59	3.20	4.17	1.056	1000	4.86	2400	5.88
40	2.33	2.66	3.24	4.17	1.104	1100	4.77	2400	5.59
41	2.49	2.76	3.30	4.21	1.176	1200	4.57	2400	5.22
42	2.67	2.88	3.41	4.30	1.282	1300	4.27	2400	4.77
43	2.15	2.76	3.49	4.60	1.024	820	4.44	2200	5.61
44	2.35	2.82	3.49	4.55	1.053	910	4.46	2200	5.41
45	2.52	2.89	3.52	4.54	1.099	1000	4.38	2200	5.15
46	2.72	3.01	3.60	4.59	1.176	1100	4.19	2200	4.78
47	2.94	3.16	3.73	4.70	1.294	1200	3.88	2200	4.33
48	2.38	3.04	3.84	5.06	1.025	750	4.04	2000	5.09
49	2.57	3.09	3.84	5.01	1.050	820	4.06	2000	4.93
50	2.78	3.18	3.88	5.00	1.100	910	3.98	2000	4.68
51	2.99	3.31	3.96	5.05	1.176	1000	3.81	2000	4.35
52	3.26	3.50	4.12	5.19	1.308	1100	3.50	2000	3.89
53	2.67	3.38	4.26	5.61	1.027	680	3.64	1800	4.57
54	2.89	3.45	4.27	5.56	1.056	750	3.65	1800	4.41
55	3.09	3.54	4.31	5.55	1.100	820	3.59	1800	4.21

Continued on [next page](#).

7-Element Chebyshev Low-Pass Filter Designs—50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values


Continued from [previous page](#).

Filter No.	F_{co}	Frequency (MHz)			Max SWR	C1,7 (pF)	L2,6 (μ H)	C3,5 (pF)	L4 (μ H)
		3 dB	20 dB	40 dB					
56	3.35	3.69	4.42	5.62	1.188	910	3.40	1800	3.87
57	3.65	3.92	4.60	5.80	1.327	1000	3.11	1800	3.45
58	3.07	3.82	4.80	6.30	1.033	620	3.24	1600	4.03
59	3.30	3.90	4.81	6.25	1.064	680	3.24	1600	3.88
60	3.55	4.02	4.87	6.26	1.120	750	3.15	1600	3.67
61	3.81	4.18	4.99	6.34	1.204	820	3.00	1600	3.39
62	3.16	4.05	5.12	6.75	1.024	560	3.03	1500	3.82
63	3.45	4.13	5.12	6.68	1.053	620	3.04	1500	3.69
64	3.69	4.24	5.17	6.66	1.097	680	2.99	1500	3.51
65	3.99	4.41	5.28	6.73	1.176	750	2.86	1500	3.26
66	4.31	4.64	5.48	6.91	1.297	820	2.64	1500	2.94
67	3.81	4.72	5.90	7.74	1.036	510	2.64	1300	3.26
68	4.10	4.82	5.93	7.69	1.070	560	2.62	1300	3.14
69	4.43	4.98	6.02	7.72	1.133	620	2.54	1300	2.94
70	4.78	5.21	6.19	7.85	1.230	680	2.39	1300	2.70
71	4.13	5.11	6.39	8.38	1.035	470	2.43	1200	3.01
72	4.40	5.20	6.41	8.33	1.064	510	2.43	1200	2.91
73	4.72	5.35	6.49	8.34	1.116	560	2.37	1200	2.76
74	5.12	5.60	6.67	8.48	1.214	620	2.23	1200	2.52
75	4.49	5.57	6.97	9.15	1.035	430	2.23	1100	2.76
76	4.82	5.68	7.00	9.09	1.066	470	2.22	1100	2.66
77	5.12	5.83	7.07	9.10	1.112	510	2.18	1100	2.54
78	5.52	6.07	7.24	9.21	1.196	560	2.07	1100	2.35
79	4.93	6.12	7.67	10.1	1.034	390	2.03	1000	2.51
80	5.33	6.26	7.70	10.0	1.069	430	2.02	1000	2.41
81	5.69	6.44	7.80	10.0	1.122	470	1.97	1000	2.29
82	6.08	6.68	7.97	10.1	1.198	510	1.88	1000	2.13
83	6.63	7.09	8.32	10.5	1.343	560	1.71	1000	1.89
84	5.48	6.75	8.43	11.0	1.038	360	1.85	910	2.28
85	5.84	6.87	8.46	11.0	1.068	390	1.84	910	2.20
86	6.28	7.09	8.58	11.0	1.126	430	1.79	910	2.07
87	6.75	7.39	8.80	11.2	1.213	470	1.69	910	1.91
88	5.68	7.39	9.37	12.4	1.020	300	1.65	820	2.10
89	6.17	7.52	9.36	12.2	1.043	330	1.66	820	2.04
90	6.60	7.68	9.41	12.2	1.079	360	1.65	820	1.96
91	7.01	7.89	9.53	12.2	1.131	390	1.61	820	1.86
92	7.59	8.27	9.82	12.5	1.233	430	1.51	820	1.70
93	6.72	8.21	10.2	13.4	1.042	300	1.52	750	1.87
94	7.23	8.40	10.3	13.3	1.080	330	1.51	750	1.79
95	7.72	8.66	10.4	13.4	1.138	360	1.46	750	1.69
96	8.24	9.00	10.7	13.6	1.222	390	1.39	750	1.57
97	7.36	9.04	11.3	14.8	1.039	270	1.38	680	1.70
98	7.98	9.27	11.4	14.7	1.082	300	1.37	680	1.62
99	8.58	9.59	11.6	14.8	1.148	330	1.32	680	1.52
100	9.23	10.0	11.9	15.1	1.247	360	1.24	680	1.39
101	7.91	9.86	12.4	16.2	1.032	240	1.26	620	1.56
102	8.67	10.1	12.4	16.1	1.075	270	1.25	620	1.49
103	9.39	10.5	12.7	16.2	1.145	300	1.20	620	1.39
104	8.86	11.0	13.7	18.0	1.036	220	1.14	560	1.40
105	9.49	11.2	13.8	17.8	1.068	240	1.13	560	1.35
106	9.72	12.0	15.0	19.7	1.036	200	1.03	510	1.28

Continued on [next page](#).

7-Element Chebyshev Low-Pass Filter Designs—50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values

Continued from [previous page](#).



The schematic for a 7-element Chebyshev low-pass filter. See [page 30.33](#) for the attenuation response curve.


5-Element Chebyshev Low-Pass Filter Designs—50-Ohm Impedance, L-In/Out for Standard-Value L and C

Filter No.	Frequency (MHz)				Max SWR	L _{1,5} (μH)	C _{2,4} (pF)	L ₃ (μH)
	F _{co}	3 dB	20 dB	40 dB				
1	0.744	1.15	1.69	2.60	1.027	5.60	4700	13.7
2	0.901	1.26	1.81	2.76	1.055	5.60	4300	12.7
3	1.06	1.38	1.94	2.93	1.096	5.60	3900	11.8
4	1.19	1.47	2.05	3.07	1.138	5.60	3600	11.2
5	1.32	1.58	2.17	3.23	1.192	5.60	3300	10.6
6	0.911	1.39	2.03	3.12	1.030	4.70	3900	11.4
7	1.08	1.50	2.16	3.29	1.056	4.70	3600	10.6
8	1.25	1.63	2.30	3.48	1.092	4.70	3300	9.92
9	1.42	1.77	2.46	3.68	1.142	4.70	3000	9.32
10	1.61	1.92	2.63	3.90	1.209	4.70	2700	8.79
11	1.05	1.64	2.41	3.72	1.025	3.90	3300	9.63
12	1.29	1.80	2.60	3.96	1.054	3.90	3000	8.83
13	1.54	1.99	2.80	4.22	1.099	3.90	2700	8.15
14	1.80	2.19	3.03	4.53	1.164	3.90	2400	7.57
15	1.99	2.35	3.20	4.75	1.222	3.90	2200	7.23
16	1.34	2.00	2.93	4.49	1.034	3.30	2700	7.89
17	1.68	2.25	3.20	4.84	1.077	3.30	2400	7.15
18	1.92	2.43	3.40	5.11	1.118	3.30	2200	6.73
19	2.16	2.63	3.62	5.40	1.174	3.30	2000	6.35
20	1.65	2.46	3.59	5.51	1.035	2.70	2200	6.43
21	1.99	2.70	3.86	5.85	1.069	2.70	2000	5.93
22	2.34	2.97	4.15	6.24	1.118	2.70	1800	5.50
23	2.71	3.27	4.49	6.68	1.188	2.70	1600	5.13
24	2.92	3.43	4.67	6.92	1.233	2.70	1500	4.97
25	2.01	3.01	4.39	6.74	1.034	2.20	1800	5.26
26	2.52	3.37	4.80	7.27	1.077	2.20	1600	4.76
27	2.78	3.57	5.02	7.56	1.107	2.20	1500	4.55
28	3.34	4.02	5.52	8.21	1.190	2.20	1300	4.18
29	2.36	3.61	5.29	8.14	1.029	1.80	1500	4.38
30	3.12	4.14	5.89	8.92	1.080	1.80	1300	3.88
31	3.51	4.45	6.23	9.36	1.118	1.80	1200	3.67
32	3.93	4.78	6.60	9.85	1.169	1.80	1100	3.48
33	4.37	5.15	7.01	10.4	1.233	1.80	1000	3.31
34	3.10	4.51	6.56	10.0	1.041	1.50	1200	3.51
35	3.65	4.90	6.99	10.6	1.073	1.50	1100	3.27
36	4.21	5.34	7.47	11.2	1.118	1.50	1000	3.06
37	4.75	5.77	7.95	11.9	1.173	1.50	910	2.89
38	3.53	5.41	7.94	12.2	1.029	1.20	1000	2.92
39	4.30	5.94	8.53	13.0	1.060	1.20	910	2.69
40	5.09	6.53	9.18	13.8	1.106	1.20	820	2.49
41	5.73	7.04	9.75	14.6	1.155	1.20	750	2.35
42	6.42	7.61	10.4	15.4	1.219	1.20	680	2.23
43	4.40	6.60	9.65	14.8	1.033	1.00	820	2.40
44	5.27	7.20	10.3	15.7	1.064	1.00	750	2.22
45	6.15	7.87	11.1	16.7	1.108	1.00	680	2.07
46	6.95	8.51	11.8	17.6	1.160	1.00	620	1.95
47	7.80	9.22	12.6	18.6	1.227	1.00	560	1.85
48	5.23	7.96	11.7	17.9	1.030	0.82	680	1.99
49	6.33	8.72	12.5	19.0	1.061	0.82	620	1.83
50	7.45	9.56	13.4	20.3	1.106	0.82	560	1.70
51	8.44	10.3	14.3	21.4	1.158	0.82	510	1.60
52	9.28	11.0	15.1	22.4	1.211	0.82	470	1.53
53	6.41	9.66	14.1	21.7	1.032	0.68	560	1.64
54	7.75	10.6	15.2	23.1	1.064	0.68	510	1.51
55	8.83	11.4	16.1	24.3	1.100	0.68	470	1.42
56	9.97	12.3	17.1	25.6	1.148	0.68	430	1.34

Continued on [next page](#).

5-Element Chebyshev Low-Pass Filter Designs—50-Ohm Impedance, L-In/Out for Standard-Value L and C


Continued from [previous page](#).



The schematic for a 5-element inductor input/output Chebyshev low-pass filter. See [page 30.33](#) for the attenuation response curve.

7-Element Chebyshev Low-Pass Filter Designs—50-Ohm Impedance, L-In/Out for Standard-Value L and C


Filter No.	Frequency (MHz)				Max SWR	L1,7 (μH)	C2,6 (pF)	L3,5 (μH)	C4 (pF)
	F_{co}	3 dB	20 dB	40 dB					
1	1.01	1.18	1.44	1.87	1.081	5.89	4300	13.4	5100
2	1.09	1.29	1.60	2.08	1.059	5.06	3900	12.0	4700
3	1.03	1.09	1.26	1.58	1.480	10.1	4300	17.1	4700
4	1.20	1.40	1.73	2.24	1.071	4.81	3600	11.2	4300
5	1.16	1.23	1.44	1.81	1.383	8.34	3900	14.6	4300
6	1.33	1.54	1.88	2.43	1.087	4.58	3300	10.3	3900
7	1.42	1.68	2.07	2.70	1.064	3.95	3000	9.27	3600
8	1.34	1.41	1.63	2.04	1.506	7.98	3300	13.4	3600
9	1.53	1.85	2.31	3.02	1.045	3.36	2700	8.32	3300
10	1.50	1.59	1.86	2.33	1.406	6.57	3000	11.4	3300
11	1.63	2.06	2.59	3.41	1.029	2.83	2400	7.41	3000
12	1.69	1.81	2.13	2.68	1.317	5.36	2700	9.70	3000
13	1.86	2.27	2.83	3.70	1.042	2.71	2200	6.78	2700
14	1.91	2.07	2.46	3.12	1.238	4.31	2400	8.19	2700
15	2.14	2.52	3.11	4.04	1.064	2.63	2000	6.18	2400
16	2.01	2.11	2.45	3.06	1.506	5.32	2200	8.91	2400
17	2.29	2.78	3.46	4.52	1.045	2.24	1800	5.54	2200
18	2.25	2.39	2.79	3.49	1.406	4.38	2000	7.61	2200
19	2.45	3.09	3.88	5.11	1.029	1.89	1600	4.94	2000
20	2.53	2.71	3.19	4.02	1.317	3.57	1800	6.47	2000
21	2.85	3.37	4.15	5.39	1.064	1.97	1500	4.64	1800
22	2.86	3.11	3.69	4.68	1.238	2.88	1600	5.46	1800
23	3.13	3.84	4.79	6.27	1.039	1.59	1300	4.00	1600
24	3.27	4.12	5.18	6.81	1.029	1.41	1200	3.70	1500
25	3.47	3.90	4.70	6.02	1.140	2.01	1300	4.17	1500
26	3.99	4.61	5.64	7.28	1.087	1.53	1100	3.43	1300
27	4.27	5.05	6.22	8.09	1.064	1.32	1000	3.09	1200
28	4.01	4.22	4.90	6.11	1.506	2.66	1100	4.45	1200
29	4.63	5.53	6.85	8.91	1.056	1.17	910	2.81	1100
30	4.49	4.77	5.57	6.98	1.406	2.19	1000	3.81	1100
31	5.05	6.11	7.60	9.92	1.047	1.03	820	2.53	1000
32	4.93	5.23	6.10	7.64	1.416	2.02	910	3.49	1000
33	5.58	6.70	8.31	10.8	1.052	0.954	750	2.31	910
34	5.54	5.94	6.99	8.80	1.326	1.65	820	2.97	910
35	6.23	7.41	9.16	11.9	1.059	0.881	680	2.10	820
36	5.92	6.24	7.26	9.06	1.476	1.76	750	2.98	820
37	6.79	8.12	10.0	13.1	1.055	0.796	620	1.91	750
38	6.64	7.07	8.27	10.4	1.379	1.45	680	2.54	750
39	7.46	8.97	11.1	14.5	1.051	0.711	560	1.73	680
40	7.21	7.63	8.89	11.1	1.438	1.40	620	2.41	680
41	8.18	9.85	12.2	15.9	1.050	0.645	510	1.57	620
42	8.10	8.66	10.2	12.8	1.345	1.15	560	2.05	620
43	9.21	10.8	13.2	17.1	1.074	0.633	470	1.46	560
44	8.78	9.31	10.9	13.6	1.425	1.14	510	1.96	560
45	10.1	11.8	14.4	18.7	1.081	0.589	430	1.34	510



The schematic for a 7-element inductor input/output Chebyshev low-pass filter. See [page 30.33](#) for the attenuation response curve.

5-Branch Elliptic Low-Pass Filter Designs— 50-Ohm Impedance, Standard E12 Capacitor Values for C1, C3 and C5

Filter No.	F_{co}	F_{3dB} (MHz)	F_{As}	A_s (dB)	Max. SWR	C1	C3	C5 (pF)	C2	C4	L2 (μH)	L4	F2	F4
1	0.795	0.989	1.57	47.4	1.092	2700	5600	2200	324	937	12.1	10.1	2.54	1.64
2	1.06	1.20	1.77	46.2	1.234	2700	4700	2200	341	982	9.36	7.56	2.82	1.85
3	1.47	1.57	2.15	45.4	1.586	2700	3900	2200	364	1045	6.32	4.88	3.32	2.23
4	0.929	1.18	1.91	48.0	1.077	2200	4700	1800	257	743	10.2	8.59	3.11	1.99
5	1.27	1.45	2.17	46.7	1.215	2200	3900	1800	271	779	7.85	6.39	3.45	2.26
6	1.69	1.82	2.54	45.9	1.489	2200	3300	1800	287	821	5.64	4.42	3.96	2.64
7	1.12	1.44	2.41	49.8	1.071	1800	3900	1500	192	549	8.45	7.25	3.95	2.52
8	1.49	1.73	2.70	48.8	1.183	1800	3300	1500	200	570	6.75	5.62	4.33	2.81
9	2.11	2.27	3.27	47.8	1.506	1800	2700	1500	213	604	4.55	3.64	5.12	3.40
10	1.28	1.66	2.63	46.3	1.064	1500	3300	1200	192	561	7.20	6.00	4.28	2.74
11	1.79	2.06	2.99	44.8	1.195	1500	2700	1200	204	592	5.52	4.42	4.75	3.11
12	2.52	2.70	3.63	43.8	1.525	1500	2200	1200	220	636	3.71	2.82	5.58	3.76
13	1.56	2.08	3.55	50.1	1.055	1200	2700	1000	127	363	5.88	5.07	5.83	3.71
14	2.23	2.59	4.04	48.8	1.183	1200	2200	1000	133	380	4.50	3.75	6.50	4.22
15	3.17	3.41	4.90	47.8	1.506	1200	1800	1000	142	402	3.03	2.42	7.68	5.10
16	1.94	2.52	4.15	48.4	1.064	1000	2200	820	115	331	4.79	4.06	6.78	4.34
17	2.73	3.14	4.73	47.0	1.199	1000	1800	820	121	348	3.66	2.99	7.56	4.93
18	3.73	4.02	5.63	46.2	1.491	1000	1500	820	129	368	2.56	2.01	8.76	5.85
19	2.39	3.11	5.20	49.4	1.065	820	1800	680	89.3	256	3.91	3.35	8.51	5.44
20	3.26	3.79	5.85	48.2	1.185	820	1500	680	93.6	267	3.07	2.54	9.39	6.10
21	4.83	5.17	7.30	47.2	1.569	820	1200	680	100	286	1.95	1.54	11.4	7.58
22	2.85	3.71	6.15	48.8	1.063	680	1500	560	76.6	220	3.26	2.78	10.1	6.43
23	4.16	4.74	7.14	47.3	1.221	680	1200	560	81.3	233	2.40	1.97	11.4	7.44
24	5.72	6.13	8.58	46.5	1.547	680	1000	560	86.3	246	1.65	1.30	13.3	8.91
25	3.67	4.69	7.95	50.5	1.076	560	1200	470	57.6	164	2.59	2.23	13.0	8.31
26	5.02	5.77	9.01	49.4	1.212	560	1000	470	60.3	171	2.01	1.68	14.5	9.40
27	7.18	7.68	11.1	48.6	1.582	560	820	470	64.1	181	1.32	1.06	17.3	11.5
28	4.40	5.60	9.24	49.3	1.079	470	1000	390	51.4	147	2.16	1.84	15.1	9.66
29	6.17	7.01	10.6	48.0	1.236	470	820	390	54.2	155	1.63	1.34	17.0	11.1
30	8.63	9.20	12.9	47.3	1.604	470	680	390	57.6	164	1.09	0.857	20.1	13.4
31	5.47	6.91	11.8	51.3	1.086	390	820	330	38.5	109	1.76	1.52	19.3	12.3
32	7.55	8.59	13.5	50.2	1.242	390	680	330	40.4	114	1.34	1.12	21.7	14.1
33	10.9	11.5	16.8	49.5	1.659	390	560	330	42.8	120	0.862	0.695	26.2	17.4
34	6.59	8.17	13.0	47.7	1.096	330	680	270	39.0	112	1.46	1.22	21.1	13.6
35	9.10	10.2	15.0	46.5	1.267	330	560	270	41.2	118	1.09	0.881	23.7	15.6
36	12.4	13.2	18.1	45.8	1.635	330	470	270	43.9	125	0.741	0.573	27.9	18.8



The schematic for a 5-branch elliptic low-pass filter is shown at A. At B is the typical attenuation response curve.

5-Element Chebyshev High-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values

Filter No.	F _{co}	Frequency (MHz)			Max SWR	C _{1,5} (pF)	L _{2,4} (μH)	C ₃ (pF)
		3 dB	20 dB	40 dB				
1	1.04	0.726	0.501	0.328	1.044	5100	6.45	2200
2	1.04	0.788	0.554	0.366	1.081	4300	5.97	2000
3	1.17	0.800	0.550	0.359	1.039	4700	5.85	2000
4	1.07	0.857	0.615	0.410	1.135	3600	5.56	1800
5	1.17	0.877	0.616	0.406	1.076	3900	5.36	1800
6	1.33	0.890	0.609	0.397	1.034	4300	5.26	1800
7	1.12	0.938	0.686	0.461	1.206	3000	5.20	1600
8	1.25	0.974	0.693	0.461	1.109	3300	4.86	1600
9	1.38	0.994	0.691	0.454	1.057	3600	4.71	1600
10	1.54	1.00	0.683	0.444	1.028	3900	4.67	1600
11	1.14	0.978	0.723	0.490	1.268	2700	5.09	1500
12	1.28	1.03	0.738	0.492	1.135	3000	4.64	1500
13	1.43	1.06	0.738	0.486	1.068	3300	4.44	1500
14	1.61	1.07	0.730	0.476	1.033	3600	4.38	1500
15	1.21	1.08	0.812	0.555	1.398	2200	4.82	1300
16	1.35	1.14	0.841	0.567	1.227	2400	4.29	1300
17	1.55	1.20	0.853	0.566	1.104	2700	3.94	1300
18	1.75	1.23	0.848	0.555	1.046	3000	3.81	1300
19	1.28	1.15	0.871	0.597	1.440	2000	4.57	1200
20	1.45	1.24	0.909	0.614	1.238	2200	3.99	1200
21	1.60	1.29	0.923	0.616	1.135	2400	3.71	1200
22	1.84	1.32	0.921	0.605	1.057	2700	3.54	1200
23	2.14	1.34	0.906	0.588	1.022	3000	3.50	1200
24	1.57	1.34	0.989	0.669	1.251	2000	3.69	1100
25	1.75	1.40	1.01	0.672	1.135	2200	3.40	1100
26	1.93	1.44	1.01	0.664	1.072	2400	3.27	1100
27	2.27	1.46	0.992	0.645	1.026	2700	3.21	1100
28	1.71	1.47	1.08	0.734	1.268	1800	3.39	1000
29	1.93	1.54	1.11	0.739	1.135	2000	3.09	1000
30	2.15	1.58	1.11	0.730	1.068	2200	2.96	1000
31	2.41	1.60	1.10	0.714	1.033	2400	2.92	1000
32	1.66	1.50	1.14	0.783	1.473	1500	3.54	910
33	1.82	1.59	1.18	0.803	1.311	1600	3.18	910
34	2.09	1.69	1.22	0.812	1.145	1800	2.83	910
35	2.36	1.74	1.22	0.802	1.068	2000	2.70	910
36	2.68	1.76	1.20	0.783	1.030	2200	2.66	910
37	2.12	1.81	1.33	0.898	1.241	1500	2.73	820
38	2.28	1.86	1.35	0.902	1.159	1600	2.58	820
39	2.61	1.93	1.35	0.890	1.069	1800	2.43	820
40	3.01	1.96	1.33	0.866	1.028	2000	2.39	820
41	2.17	1.90	1.42	0.970	1.341	1300	2.67	750
42	2.57	2.06	1.48	0.985	1.135	1500	2.32	750
43	2.76	2.10	1.48	0.978	1.086	1600	2.25	750
44	3.21	2.14	1.46	0.952	1.033	1800	2.19	750
45	2.45	2.13	1.58	1.08	1.304	1200	2.36	680
46	2.69	2.23	1.62	1.09	1.181	1300	2.17	680
47	3.17	2.33	1.63	1.07	1.067	1500	2.01	680
48	3.44	2.35	1.62	1.06	1.039	1600	1.99	680
49	2.70	2.34	1.74	1.18	1.293	1100	2.14	620
50	2.99	2.46	1.78	1.19	1.167	1200	1.96	620
51	3.28	2.53	1.79	1.19	1.097	1300	1.87	620
52	3.93	2.59	1.76	1.15	1.030	1500	1.81	620
53	3.02	2.60	1.93	1.31	1.282	1000	1.92	560
54	3.37	2.74	1.97	1.32	1.152	1100	1.75	560

Continued on [next page](#).

5-Element Chebyshev High-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values


Continued from [previous page](#).

Filter No.	F_{co}	Frequency (MHz)			Max SWR	C1,5 (pF)	L2,4 (μ H)	C3 (pF)
		3 dB	20 dB	40 dB				
55	3.72	2.81	1.98	1.31	1.083	1200	1.67	560
56	4.10	2.85	1.97	1.29	1.044	1300	1.64	560
57	3.31	2.86	2.12	1.44	1.283	910	1.75	510
58	3.69	3.00	2.17	1.45	1.154	1000	1.60	510
59	4.11	3.09	2.17	1.44	1.079	1100	1.52	510
60	4.59	3.14	2.15	1.41	1.039	1200	1.49	510
61	3.49	3.05	2.28	1.55	1.327	820	1.66	470
62	3.95	3.24	2.35	1.57	1.167	910	1.49	470
63	4.39	3.34	2.36	1.56	1.087	1000	1.41	470
64	4.94	3.40	2.34	1.53	1.041	1100	1.38	470
65	3.81	3.34	2.49	1.70	1.327	750	1.52	430
66	4.24	3.52	2.56	1.72	1.184	820	1.38	430
67	4.77	3.65	2.58	1.71	1.091	910	1.29	430
68	5.36	3.72	2.56	1.68	1.043	1000	1.26	430
69	4.20	3.68	2.75	1.87	1.328	680	1.38	390
70	4.72	3.89	2.83	1.90	1.175	750	1.24	390
71	5.22	4.02	2.84	1.88	1.095	820	1.17	390
72	5.93	4.10	2.82	1.85	1.042	910	1.14	390
73	4.48	3.95	2.96	2.02	1.355	620	1.30	360
74	5.01	4.18	3.05	2.05	1.196	680	1.16	360
75	5.60	4.34	3.08	2.04	1.101	750	1.09	360
76	6.23	4.42	3.07	2.01	1.052	820	1.06	360
77	4.79	4.25	3.20	2.19	1.391	560	1.22	330
78	5.44	4.55	3.33	2.24	1.203	620	1.07	330
79	6.03	4.72	3.36	2.23	1.110	680	1.00	330
80	6.77	4.82	3.35	2.20	1.052	750	0.970	330
81	7.70	4.87	3.30	2.14	1.023	820	0.962	330
82	5.28	4.68	3.53	2.41	1.386	510	1.10	300
83	5.94	4.99	3.65	2.46	1.212	560	0.978	300
84	6.66	5.20	3.70	2.46	1.107	620	0.910	300
85	7.43	5.31	3.68	2.42	1.054	680	0.882	300
86	8.56	5.36	3.62	2.35	1.022	750	0.875	300
87	6.05	5.31	3.97	2.70	1.332	470	0.956	270
88	6.69	5.58	4.07	2.74	1.196	510	0.870	270
89	7.43	5.78	4.11	2.73	1.105	560	0.817	270
90	8.39	5.91	4.08	2.68	1.048	620	0.792	270
91	7.07	6.09	4.51	3.06	1.276	430	0.818	240
92	7.84	6.38	4.61	3.08	1.155	470	0.752	240
93	8.59	6.55	4.62	3.06	1.088	510	0.719	240
94	9.64	6.66	4.58	3.00	1.042	560	0.702	240
95	7.61	6.60	4.90	3.33	1.295	390	0.760	220
96	8.53	6.95	5.02	3.36	1.157	430	0.690	220
97	9.43	7.15	5.04	3.33	1.085	470	0.658	220
98	10.4	7.26	5.01	3.28	1.044	510	0.644	220
99	7.58	6.83	5.19	3.56	1.470	330	0.776	200
100	8.53	7.33	5.42	3.67	1.268	360	0.678	200
101	9.36	7.64	5.52	3.70	1.159	390	0.628	200
102	10.4	7.88	5.54	3.66	1.081	430	0.596	200
103	8.55	7.67	5.81	3.98	1.440	300	0.685	180
104	9.69	8.24	6.06	4.09	1.238	330	0.597	180
105	10.7	8.57	6.15	4.10	1.135	360	0.556	180
106	9.80	8.73	6.58	4.50	1.406	270	0.595	160

Continued on [next page](#).

5-Element Chebyshev High-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values

Continued from [previous page](#).



The schematic for a 5-element capacitor input/output Chebyshev high-pass filter is shown at A. At B is the typical attenuation response curve.

7-Element Chebyshev High-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values

Filter No.	Frequency (MHz)				Max SWR	C1,7 (pF)	L2,6 (μH)	C3,5 (pF)	L4 (μH)
	F _{co}	3 dB	20 dB	40 dB					
1	1.02	0.826	0.660	0.504	1.036	5100	6.16	2000	4.98
2	1.00	0.880	0.724	0.563	1.109	3900	5.67	1800	4.86
3	1.08	0.905	0.732	0.563	1.058	4300	5.55	1800	4.60
4	1.16	0.922	0.734	0.558	1.030	4700	5.55	1800	4.45
5	1.00	0.924	0.780	0.617	1.257	3000	5.53	1600	4.93
6	1.09	0.971	0.806	0.630	1.147	3300	5.15	1600	4.48
7	1.16	1.00	0.819	0.634	1.086	3600	4.99	1600	4.22
8	1.23	1.02	0.824	0.632	1.050	3900	4.93	1600	4.05
9	1.34	1.04	0.825	0.625	1.023	4300	4.95	1600	3.92
10	1.03	0.958	0.815	0.648	1.327	2700	5.43	1500	4.89
11	1.13	1.02	0.853	0.669	1.176	3000	4.92	1500	4.31
12	1.22	1.06	0.871	0.676	1.099	3300	4.70	1500	4.01
13	1.30	1.09	0.879	0.675	1.056	3600	4.63	1500	3.83
14	1.39	1.11	0.880	0.670	1.031	3900	4.63	1500	3.71
15	1.22	1.13	0.954	0.755	1.282	2400	4.57	1300	4.09
16	1.34	1.20	0.994	0.776	1.141	2700	4.17	1300	3.62
17	1.45	1.24	1.01	0.780	1.073	3000	4.03	1300	3.38
18	1.57	1.27	1.02	0.775	1.037	3300	4.00	1300	3.24
19	1.31	1.21	1.03	0.816	1.294	2200	4.25	1200	3.81
20	1.41	1.28	1.07	0.836	1.176	2400	3.94	1200	3.45
21	1.55	1.34	1.09	0.845	1.086	2700	3.74	1200	3.16
22	1.68	1.37	1.10	0.841	1.042	3000	3.70	1200	3.01
23	1.41	1.32	1.12	0.887	1.308	2000	3.93	1100	3.53
24	1.54	1.39	1.16	0.912	1.176	2200	3.61	1100	3.16
25	1.65	1.44	1.19	0.921	1.104	2400	3.46	1100	2.95
26	1.80	1.49	1.20	0.919	1.048	2700	3.39	1100	2.78
27	1.97	1.52	1.20	0.907	1.021	3000	3.41	1100	2.68
28	1.54	1.44	1.22	0.971	1.327	1800	3.62	1000	3.26
29	1.70	1.53	1.28	1.00	1.176	2000	3.28	1000	2.87
30	1.82	1.59	1.31	1.01	1.099	2200	3.14	1000	2.67
31	1.95	1.63	1.32	1.01	1.056	2400	3.08	1000	2.55
32	2.15	1.67	1.32	1.00	1.023	2700	3.10	1000	2.45
33	1.85	1.67	1.40	1.10	1.188	1800	3.01	910	2.64
34	2.00	1.75	1.44	1.11	1.100	2000	2.85	910	2.43
35	2.15	1.80	1.45	1.11	1.053	2200	2.81	910	2.31
36	2.31	1.83	1.45	1.10	1.027	2400	2.81	910	2.24
37	1.91	1.77	1.50	1.19	1.297	1500	2.91	820	2.61
38	2.03	1.85	1.55	1.22	1.204	1600	2.74	820	2.42
39	2.22	1.94	1.59	1.24	1.100	1800	2.57	820	2.19
40	2.41	2.00	1.61	1.23	1.050	2000	2.53	820	2.08
41	2.61	2.03	1.61	1.22	1.024	2200	2.54	820	2.01
42	2.26	2.04	1.71	1.34	1.176	1500	2.46	750	2.16
43	2.38	2.10	1.73	1.35	1.120	1600	2.38	750	2.04
44	2.60	2.17	1.76	1.35	1.056	1800	2.31	750	1.91
45	2.83	2.22	1.76	1.34	1.025	2000	2.32	750	1.84
46	2.40	2.20	1.85	1.46	1.230	1300	2.31	680	2.05
47	2.69	2.34	1.92	1.49	1.097	1500	2.13	680	1.81
48	2.82	2.39	1.94	1.49	1.064	1600	2.10	680	1.75
49	3.11	2.45	1.94	1.47	1.027	1800	2.10	680	1.67
50	2.66	2.43	2.04	1.61	1.214	1200	2.08	620	1.84
51	2.84	2.52	2.09	1.63	1.133	1300	1.98	620	1.71
52	3.16	2.64	2.13	1.63	1.053	1500	1.91	620	1.58
53	3.33	2.67	2.13	1.62	1.033	1600	1.91	620	1.54
54	2.73	2.55	2.17	1.73	1.343	1000	2.05	560	1.85

Continued on [next page](#).

7-Element Chebyshev High-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values


Continued from [previous page](#).

Filter No.	F_{co}	Frequency (MHz)			Max SWR	C1,7 (pF)	L2,6 (μH)	C3,5 (pF)	L4 (μH)
		3 dB	20 dB	40 dB					
55	2.98	2.71	2.27	1.79	1.196	1100	1.86	560	1.64
56	3.19	2.82	2.32	1.81	1.116	1200	1.77	560	1.52
57	3.39	2.89	2.35	1.81	1.070	1300	1.73	560	1.45
58	3.81	2.98	2.36	1.79	1.024	1500	1.73	560	1.37
59	3.27	2.97	2.49	1.96	1.198	1000	1.70	510	1.49
60	3.53	3.10	2.55	1.99	1.112	1100	1.61	510	1.38
61	3.76	3.18	2.58	1.99	1.064	1200	1.58	510	1.31
62	4.01	3.24	2.59	1.98	1.036	1300	1.57	510	1.27
63	3.51	3.21	2.69	2.12	1.213	910	1.58	470	1.40
64	3.79	3.35	2.76	2.15	1.122	1000	1.49	470	1.28
65	4.07	3.45	2.80	2.16	1.066	1100	1.45	470	1.21
66	4.35	3.52	2.81	2.14	1.035	1200	1.45	470	1.17
67	3.79	3.47	2.93	2.31	1.233	820	1.46	430	1.30
68	4.12	3.65	3.02	2.35	1.126	910	1.37	430	1.18
69	4.42	3.76	3.06	2.36	1.069	1000	1.33	430	1.11
70	4.77	3.85	3.07	2.34	1.035	1100	1.33	430	1.07
71	4.20	3.85	3.24	2.55	1.222	750	1.32	390	1.17
72	4.52	4.02	3.32	2.59	1.131	820	1.24	390	1.07
73	4.89	4.15	3.37	2.60	1.068	910	1.21	390	1.01
74	5.27	4.24	3.39	2.58	1.034	1000	1.20	390	0.969
75	4.48	4.13	3.48	2.75	1.247	680	1.24	360	1.10
76	4.86	4.33	3.59	2.80	1.138	750	1.15	360	1.00
77	5.20	4.47	3.65	2.82	1.079	820	1.12	360	0.942
78	5.64	4.58	3.67	2.80	1.038	910	1.11	360	0.899
79	4.87	4.49	3.79	2.99	1.254	620	1.14	330	1.01
80	5.26	4.71	3.91	3.05	1.148	680	1.06	330	0.924
81	5.67	4.87	3.98	3.07	1.080	750	1.03	330	0.864
82	6.07	4.98	4.00	3.06	1.043	820	1.02	330	0.829
83	5.32	4.91	4.15	3.28	1.264	560	1.04	300	0.930
84	5.80	5.18	4.30	3.36	1.145	620	0.965	300	0.838
85	6.22	5.36	4.37	3.38	1.082	680	0.933	300	0.787
86	6.71	5.49	4.40	3.36	1.042	750	0.923	300	0.752
87	7.25	5.58	4.40	3.33	1.020	820	0.931	300	0.731
88	5.98	5.50	4.64	3.66	1.247	510	0.926	270	0.824
89	6.46	5.77	4.78	3.74	1.142	560	0.867	270	0.752
90	6.98	5.97	4.87	3.76	1.075	620	0.837	270	0.703
91	7.50	6.11	4.89	3.74	1.039	680	0.831	270	0.675
92	6.39	5.97	5.08	4.04	1.336	430	0.873	240	0.787
93	6.94	6.32	5.29	4.16	1.200	470	0.798	240	0.704
94	7.41	6.55	5.41	4.21	1.123	510	0.762	240	0.656
95	7.95	6.75	5.48	4.22	1.068	560	0.742	240	0.620
96	8.61	6.90	5.50	4.19	1.032	620	0.740	240	0.595
97	7.56	6.88	5.77	4.54	1.202	430	0.733	220	0.646
98	8.11	7.16	5.91	4.60	1.119	470	0.697	220	0.599
99	8.63	7.35	5.98	4.61	1.071	510	0.681	220	0.570
100	9.28	7.51	6.00	4.58	1.036	560	0.677	220	0.548
101	7.70	7.19	6.11	4.86	1.327	360	0.723	200	0.652
102	8.30	7.56	6.34	4.99	1.205	390	0.667	200	0.589
103	8.97	7.90	6.51	5.06	1.114	430	0.632	200	0.542
104	9.59	8.11	6.58	5.07	1.064	470	0.618	200	0.515
105	8.72	8.09	6.86	5.44	1.294	330	0.637	180	0.571
106	9.42	8.51	7.11	5.57	1.176	360	0.590	180	0.517

Continued on [next page](#).

7-Element Chebyshev High-Pass Filter Designs— 50-Ohm Impedance, C-In/Out for Standard E24 Capacitor Values


Continued from [previous page](#).



The schematic for a 7-element capacitor input/output Chebyshev high-pass filter. See [page 30.43](#) for the attenuation response curve.


5-Branch Elliptic High-Pass Filter Designs— 50-Ohm Impedance, Standard E12 Capacitor Values for C1, C3 and C5

Filter No.	F_{co}	F_{3dB} (MHz)	F_{As}	A_s (dB)	Max. SWR	C1	C3	C5 (nF)	C2	C4	L2 (μH)	L4	F2 (MHz)	F4
1	1.01	0.936	0.670	45.9	1.489	2.7	1.8	3.3	20.7	7.24	6.58	8.40	0.431	0.646
2	1.14	0.976	0.608	50.4	1.186	3.3	1.8	3.9	32.3	11.4	5.53	6.54	0.377	0.582
3	1.30	1.01	0.604	49.4	1.071	3.9	1.8	4.7	35.8	12.5	5.19	6.07	0.369	0.578
4	1.19	1.11	0.810	45.4	1.543	2.2	1.5	2.7	16.4	5.71	5.65	7.28	0.523	0.780
5	1.38	1.20	0.797	46.8	1.199	2.7	1.5	3.3	22.0	7.66	4.61	5.65	0.499	0.765
6	1.56	1.19	0.685	51.6	1.064	3.3	1.5	3.9	33.7	11.9	4.32	4.97	0.417	0.655
7	1.51	1.40	1.01	45.9	1.489	1.8	1.2	2.2	13.8	4.82	4.39	5.60	0.646	0.968
8	1.75	1.51	1.00	46.6	1.180	2.2	1.2	2.7	17.7	6.14	3.65	4.47	0.627	0.961
9	2.02	1.52	0.920	48.3	1.055	2.7	1.2	3.3	23.4	8.09	3.44	4.04	0.562	0.880
10	1.78	1.65	1.15	47.8	1.506	1.5	1.0	1.8	12.7	4.47	3.71	4.64	0.733	1.10
11	2.07	1.80	1.20	46.8	1.199	1.8	1.0	2.2	14.7	5.11	3.07	3.77	0.749	1.15
12	2.38	1.83	1.13	47.8	1.064	2.2	1.0	2.7	18.6	6.43	2.87	3.40	0.689	1.08
13	2.22	2.08	1.55	43.7	1.531	1.2	0.82	1.5	8.19	2.83	3.05	4.02	1.01	1.49
14	2.52	2.17	1.39	48.7	1.186	1.5	0.82	1.8	13.5	4.73	2.51	3.01	0.865	1.33
15	2.89	2.23	1.36	48.2	1.065	1.8	0.82	2.2	15.5	5.37	2.36	2.78	0.833	1.30
16	2.57	2.40	1.68	47.8	1.560	1.0	0.68	1.2	8.40	2.96	2.60	3.27	1.08	1.62
17	3.05	2.68	1.85	44.7	1.215	1.2	0.68	1.5	8.77	3.02	2.10	2.64	1.17	1.78
18	3.48	2.66	1.57	49.9	1.063	1.5	0.68	1.8	14.1	4.94	1.96	2.28	0.957	1.50
19	3.17	2.96	2.13	46.1	1.554	0.82	0.56	1.0	6.31	2.21	2.13	2.72	1.37	2.05
20	3.62	3.16	2.05	48.6	1.210	1.0	0.56	1.2	8.93	3.14	1.74	2.10	1.28	1.96
21	4.19	3.30	2.11	46.1	1.076	1.2	0.56	1.5	9.30	3.19	1.61	1.94	1.30	2.02
22	4.30	3.79	2.55	46.9	1.233	0.82	0.47	1.0	6.69	2.33	1.48	1.82	1.60	2.45
23	4.89	3.84	2.31	49.7	1.079	1.0	0.47	1.2	9.34	3.27	1.36	1.59	1.41	2.21
24	5.87	3.89	2.31	47.4	1.021	1.2	0.47	1.5	9.71	3.32	1.35	1.58	1.39	2.20
25	4.44	4.17	3.01	46.5	1.618	0.56	0.39	0.68	4.37	1.53	1.54	1.97	1.94	2.90
26	5.14	4.52	2.99	48.0	1.236	0.68	0.39	0.82	5.88	2.06	1.23	1.50	1.87	2.87
27	5.88	4.67	2.90	48.0	1.085	0.82	0.39	1.0	7.05	2.45	1.13	1.34	1.78	2.78
28	5.99	5.34	3.60	47.1	1.269	0.56	0.33	0.68	4.63	1.62	1.06	1.31	2.27	3.46
29	6.81	5.48	3.37	49.0	1.096	0.68	0.33	0.82	6.15	2.15	0.961	1.13	2.07	3.22
30	8.07	5.50	3.17	49.3	1.026	0.82	0.33	1.0	7.33	2.54	0.945	1.09	1.91	3.02
31	6.38	5.99	4.26	47.3	1.609	0.39	0.27	0.47	3.18	1.12	1.06	1.34	2.74	4.10
32	7.34	6.47	4.18	49.2	1.241	0.47	0.27	0.56	4.33	1.53	0.856	1.03	2.61	4.01
33	8.39	6.73	4.17	48.4	1.092	0.56	0.27	0.68	4.90	1.71	0.784	0.930	2.57	4.00
34	7.92	7.36	4.98	49.6	1.522	0.33	0.22	0.39	3.05	1.08	0.828	1.02	3.17	4.79
35	9.21	8.05	5.27	48.1	1.217	0.39	0.22	0.47	3.40	1.19	0.686	0.832	3.30	5.06
36	10.4	8.18	4.84	50.5	1.077	0.47	0.22	0.56	4.56	1.60	0.636	0.740	2.95	4.62




The schematic for a 5-branch elliptic high-pass filter is shown at A. At B is the typical attenuation response curve.

Relationship Between Noise Figure and Noise Temperature



Pi-Network Resistive Attenuators (50 Ω)


dB Atten.	R1 (Ohms)	R2 (Ohms)
1	870.0	5.8
2	436.0	11.6
3	292.0	17.6
4	221.0	23.8
5	178.6	30.4
6	150.5	37.3
7	130.7	44.8
8	116.0	52.8
9	105.0	61.6
10	96.2	71.2
11	89.2	81.6
12	83.5	93.2
13	78.8	106.0
14	74.9	120.3
15	71.6	136.1
16	68.8	153.8
17	66.4	173.4
18	64.4	195.4
19	62.6	220.0
20	61.0	247.5
21	59.7	278.2
22	58.6	312.7
23	57.6	351.9
24	56.7	394.6
25	56.0	443.1
30	53.2	789.7
35	51.8	1405.4
40	51.0	2500.0
45	50.5	4446.0
50	50.3	7905.6
55	50.2	14,058.0
60	50.1	25,000.0



Note: A PC board kit for the Low-Power Step Attenuator (Sep 1982 QST) is available from FAR Circuits. Project details are in the Handbook [template package STEP ATTENUATOR](#).

T-Network Resistive Attenuators (50 Ω)

<i>dB Atten.</i>	<i>R1 (Ohms)</i>	<i>R2 (Ohms)</i>
1	2.9	433.3
2	5.7	215.2
3	8.5	141.9
4	11.3	104.8
5	14.0	82.2
6	16.6	66.9
7	19.0	55.8
8	21.5	47.3
9	23.8	40.6
10	26.0	35.0
11	28.0	30.6
12	30.0	26.8
13	31.7	23.5
14	33.3	20.8
15	35.0	18.4
16	36.3	16.2
17	37.6	14.4
18	38.8	12.8
19	40.0	11.4
20	41.0	10.0
21	41.8	9.0
22	42.6	8.0
23	43.4	7.1
24	44.0	6.3
25	44.7	5.6
30	47.0	3.2
35	48.2	1.8
40	49.0	1.0
45	49.4	0.56
50	49.7	0.32
55	49.8	0.18
60	49.9	0.10



Tower Manufacturers

Contact information appears in the [Handbook Address List](#) elsewhere in this chapter. Send updates to the Handbook Editor at ARRL Headquarters.

Aluma Tower
Glen Martin Engineering
Hy-Gain Division, Telex Communications, Inc
M² Enterprises
National Tower Co
Rohn
Texas Towers
Tri-Ex Tower Corp
Universal Manufacturing Co
US Tower Corp

Antenna Wire Strength

<i>American Wire Gauge</i>	Recommended Tension¹ (pounds)		Weight (pounds per 1000 feet)	
	<i>Copper-clad steel²</i>	<i>Hard-drawn copper</i>	<i>Copper-clad steel²</i>	<i>Hard-drawn copper</i>
4	495	214	115.8	126
6	310	130	72.9	79.5
8	195	84	45.5	50
10	120	52	28.8	31.4
12	75	32	18.1	19.8
14	50	20	11.4	12.4
16	31	13	7.1	7.8
18	19	8	4.5	4.9
20	12	5	2.8	3.1

¹ Approximately one-tenth the breaking load. Might be increased 50% if end supports are firm and there is no danger of ice loading.

² "Copperweld," 40% copper.

Impedance of Various Two-Conductor Lines

Wire Size	Twists per Inch				
	2.5	5	7.5	10	12.5
no. 20	43	39	35		
no. 22	46	41	39	37	32
no. 24	60	45	44	43	41
no. 26	65	57	54	48	47
no. 28	74	53	51	49	47
no. 30			49	46	47

Measured in ohms at 14.0 MHz.

This chart illustrates the impedance of various two-conductor lines as a function of the wire size and number of twists per inch.

Standard vs American Wire Gauge

SWG	Diam (in.)	Nearest AWG
12	0.104	10
14	0.08	12
16	0.064	14
18	0.048	16
20	0.036	19
22	0.028	21
24	0.022	23
26	0.018	25
28	0.0148	27
30	0.0124	28
32	0.0108	29
34	0.0092	31
36	0.0076	32
38	0.006	34
40	0.0048	36
42	0.004	38
44	0.0032	40
46	0.0024	—

Attenuation per Foot for Lines

Wire Size	Twists per Inch				
	2.5	5	7.5	10	12.5
no. 20	0.11	0.11	0.12		
no. 22	0.11	0.12	0.12	0.12	0.12
no. 24	0.11	0.12	0.12	0.13	0.13
no. 26	0.11	0.13	0.13	0.13	0.13
no. 28	0.11	0.13	0.13	0.16	0.16
no. 30			0.25	0.27	0.27

Measured in decibels at 14.0 MHz.

Attenuation in dB per foot for the same lines as shown above.

Equivalent Values of Reflection Coefficient, Attenuation, SWR and Return Loss

Reflection Coefficient (%)	Attenuation (dB)	Max SWR	Return Loss	Reflection Coefficient (%)	Attenuation (dB)	Max SWR	Return Loss
1.000	0.000434	1.020	40.00	27.000	0.3287	1.740	11.37
1.517	0.001000	1.031	36.38	28.000	0.3546	1.778	11.06
2.000	0.001738	1.041	33.98	30.000	0.4096	1.857	10.46
3.000	0.003910	1.062	30.46	31.623	0.4576	1.925	10.00
4.000	0.006954	1.083	27.96	32.977	0.5000	1.984	9.64
4.796	0.01000	1.101	26.38	33.333	0.5115	2.000	9.54
5.000	0.01087	1.105	26.02	34.000	0.5335	2.030	9.37
6.000	0.01566	1.128	24.44	35.000	0.5675	2.077	9.12
7.000	0.02133	1.151	23.10	36.000	0.6028	2.125	8.87
7.576	0.02500	1.164	22.41	37.000	0.6394	2.175	8.64
8.000	0.02788	1.174	21.94	38.000	0.6773	2.226	8.40
9.000	0.03532	1.198	20.92	39.825	0.75000	2.324	8.00
10.000	0.04365	1.222	20.00	40.000	0.7572	2.333	7.96
10.699	0.05000	1.240	19.41	42.000	0.8428	2.448	7.54
11.000	0.05287	1.247	19.17	42.857	0.8814	2.500	7.36
12.000	0.06299	1.273	18.42	44.000	0.9345	2.571	7.13
13.085	0.07500	1.301	17.66	45.351	1.0000	2.660	6.87
14.000	0.08597	1.326	17.08	48.000	1.1374	2.846	6.38
15.000	0.09883	1.353	16.48	50.000	1.2494	3.000	6.02
15.087	0.10000	1.355	16.43	52.000	1.3692	3.167	5.68
16.000	0.1126	1.381	15.92	54.042	1.5000	3.352	5.35
17.783	0.1396	1.433	15.00	56.234	1.6509	3.570	5.00
18.000	0.1430	1.439	14.89	58.000	1.7809	3.762	4.73
19.000	0.1597	1.469	14.42	60.000	1.9382	4.000	4.44
20.000	0.1773	1.500	13.98	60.749	2.0000	4.095	4.33
22.000	0.2155	1.564	13.15	63.000	2.1961	4.405	4.01
23.652	0.2500	1.620	12.52	66.156	2.5000	4.909	3.59
24.000	0.2577	1.632	12.40	66.667	2.5528	5.000	3.52
25.000	0.2803	1.667	12.04	70.627	3.0000	5.809	3.02
26.000	0.3040	1.703	11.70	70.711	3.0103	5.829	3.01

$$\rho = \frac{\text{SWR} - 1}{\text{SWR} + 1}$$

where $\rho = 0.01 \times$ (reflection coefficient in %)

$$\rho = 10^{\frac{-\text{RL}}{20}}$$

where RL = return loss (dB)

$$\rho = \sqrt{1 - (0.1^X)}$$

where $X = A/10$ and $A =$ attenuation (dB)

$$\text{SWR} = \frac{1 + \rho}{1 - \rho}$$


Return loss (dB) = $-8.68589 \ln(\rho)$

where \ln is the natural log (log to the base e)

Attenuation (dB) = $-4.34295 \ln(1 - \rho^2)$

where \ln is the natural log (log to the base e)

Guy Wire Lengths to Avoid



The black bars indicate ungrounded guy wire lengths to avoid for the eight HF amateur bands. This chart is based on resonance within 10% of any frequency in the band. Grounded wires will exhibit resonance at odd multiples of a quarter wavelength. (*Jerry Hall, K1TD*)

Morse Code Character Set¹

A	didah	• –	Period [.]:	didahdidahdidah	• – • – • –	<u>AAA</u>
B	dahdididit	– •••	Comma [.,]:	dahdahdidahdah	– – •• – –	<u>MIM</u>
C	dahdidahdit	– • – •	Question mark or request for repetition [?]:	dididahdahdidit	•• – – ••	<u>IMI</u>
D	dahdidit	– ••	Error:	dididididididit	••••••••	<u>HH</u>
E	dit	•	Hyphen or dash [-]:	dahdididididah	– ••• –	<u>DU</u>
F	dididahdit	•• – •	Double dash [=]:	dahdidididah	– •• –	<u>BT</u>
G	dahdahdit	– – •	Colon [:]:	dahdahdahdididit	– – – •••	<u>OS</u>
H	didididit	••••	Semicolon [;]:	dahdidahdidahdit	– • – • – •	<u>KR</u>
I	didit	••	Left parenthesis [(]:	dahdidahdahdit	– • – – –	<u>KN</u>
J	didahdahdah	• – – –	Right parenthesis [)]:	dahdidahdahdidah	– – – • – –	<u>KK</u>
K	dahdidah	– • –	Fraction bar [/]:	dahdidididit	– •• – •	<u>DN</u>
L	didahdidit	• – ••	Quotation marks [“”]:	didahdidididit	• – •• – •	<u>AF</u>
M	dahdah	– –	Dollar sign [\$]:	didididididididah	••• – • – •	<u>SX</u>
N	dahdit	– •	Apostrophe [’]:	didahdahdahdahdit	• – – – – •	<u>WG</u>
O	dahdahdah	– – –	Paragraph [¶]:	didahdidahdidit	• – • – ••	<u>AL</u>
P	didahdahdit	• – – •	Underline [_]:	dididahdahdidah	•• – – • –	<u>IQ</u>
Q	dahdahdidah	– – • –	Starting signal:	dahdidahdidah	– • – • –	<u>KA</u>
R	didahdit	• – •	Wait:	didahdididit	••••••	<u>AS</u>
S	dididit	•••	End of message or cross [+]:	didahdidahdit	• – •••	<u>AR</u>
T	dah	–	Invitation to transmit [K]:	dahdidah	– • –	<u>K</u>
U	dididah	•• –	End of work:	dididididididah	••• – • –	<u>SK</u>
V	didididah	••• –	Understood:	didididididit	••• – •	<u>SN</u>

Notes:

1. Not all Morse characters shown are used in FCC code tests. License applicants are responsible for knowing, and may be tested on, the 26 letters, the numerals 0 to 9, the period, the comma, the question mark, AR, SK, BT and fraction bar [DN].

2. The following letters are used in certain European languages which use the Latin alphabet:

Ä, A	didahdidah	• – • –
Á, Â, Æ, Å	didahdahdidah	• – – • –
Ç, Ç	dahdidahdidit	– • – ••
É, Ê, Ë	dididahdidit	•• – ••
È	didahdididah	• – •• –
Ê	dahdidididit	– •• – •
Ë, Ô, Ó	dahdahdahdit	– – – •
Ñ	dahdahdidahdah	– – • – –
Ü	dididahdah	•• – –
Ž	dahdahdidit	– – ••
Z	dahdahdididah	– – •• –
CH, Ş	dahdahdahdah	– – – –

3. Special Esperanto characters:

Ĉ	dahdidahdidit	– • – ••
Ŝ	didididahdit	••• – •
Ĵ	didahdahdahdit	• – – – –
Ĥ	dahdidahdahdit	– • – – –
Ŭ	dididahdah	•• – –
Ĝ	dahdahdidahdit	– – • – •

4. Signals used in other radio services:

Interrogatory	dididahdidah	•• – • –	<u>INT</u>
Emergency silence	didididididahdah	•••• – –	<u>HM</u>
Executive follows	didididididah	•• – •• –	<u>IX</u>
Break-in signal	dahdahdahdahdah	– – – – –	<u>TTTTT</u>
Emergency signal	didididahdahdahdididit	••• – – – •••	<u>SOS</u>
Relay of distress	dahdididahdididididit	– •• – •• – ••	<u>DDD</u>

Morse Abbreviated Numbers

<i>Numeral</i>	<i>Long Number</i>		<i>Abbreviated Number</i>	<i>Equivalent Character</i>	
1	didahdahdahdah	• – – – –	didah	• –	A
2	dididahdahdah	•• – – –	dididah	•• –	U
3	didididahdah	••• – –	didididah	••• –	V
4	dididididah	•••• –	dididididah	•••• –	4
5	dididididit	•••••	dididididit	••••• or •	5 or E
6	dahdidididit	– ••••	dahdidididit	– ••••	6
7	dahdahdididit	– – •••	dahdididit	– •••	B
8	dahdahdahdidit	– – – ••	dahdidit	– ••	D
9	dahdahdahdahdit	– – – – •	dahdit	– •	N
0	dahdahdahdahdah	– – – – –	dah	–	T

Note: These abbreviated numbers are not legal for use in call signs. They should be used only where there is agreement between operators and when no confusion will result.

The ASCII Coded Character Set

Bit Number				Hex	1st	2nd	3rd	4th	5th	6th	7th	8th
3	2	1	0	2nd	0	1	2	3	4	5	6	7
0	0	0	0	0	NUL	DLE	SP	0	@	P	`	p
0	0	0	1	1	SOH	DC1	!	1	A	Q	a	q
0	0	1	0	2	STX	DC2	"	2	B	R	b	r
0	0	1	1	3	ETX	DC3	#	3	C	S	c	s
0	1	0	0	4	EOT	DC4	\$	4	D	T	d	t
0	1	0	1	5	ENQ	NAK	%	5	E	U	e	u
0	1	1	0	6	ACK	SYN	&	6	F	V	f	v
0	1	1	1	7	BEL	ETB	'	7	G	W	g	w
1	0	0	0	8	BS	CAN	(8	H	X	h	x
1	0	0	1	9	HT	EM)	9	I	Y	i	y
1	0	1	0	A	LF	SUB	*	:	J	Z	j	z
1	0	1	1	B	VT	ESC	+	;	K	[k	{
1	1	0	0	C	FF	FS	,	<	L	\	l	
1	1	0	1	D	CR	GS	-	=	M]	m	}
1	1	1	0	E	SO	RS	.	>	N	^	n	~
1	1	1	1	F	SI	US	/	?	O	—	o	DEL

ACK	acknowledge	FF	form feed
BEL	bell	FS	file separator
BS	backspace	GS	group separator
CAN	cancel	HT	horizontal tab
CR	carriage return	LF	line feed
DC1	device control 1	NAK	negative acknowledge
DC2	device control 2	NUL	null
DC3	device control 3	RS	record separator
DC4	device control 4	SI	shift in
DEL	(delete)	SO	shift out
DLE	data link escape	SOH	start of heading
ENQ	enquiry	SP	space
EM	end of medium	STX	start of text
EOT	end of transmission	SUB	substitute
ESC	escape	SYN	synchronous idle
ETB	end of block	US	unit separator
ETX	end of text	VT	vertical tab

Notes

1. "1" = mark, "0" = space.
2. Bit 6 is the most-significant bit (MSB). Bit 0 is the least-significant bit (LSB).

ITA2 (Baudot) and AMTOR Codes

Combination No.	ITA2 ¹ Code		CCIR 476 ² Code		Character Set		
	Bit No. 43210	Hex	Bit No. 6543210	Hex	Letters Case	ITA2	Figures Case U.S. TTYs ³
1	00011	03	1000111	47	A	—	—
2	11001	19	1110010	72	B	?	?
3	01110	0E	0011101	1D	C	:	:
4	01001	09	1010011	53	D	5	\$
5	00001	01	1010110	56	E	3	3
6	01101	0D	0011011	1B	F	4	!
7	11010	1A	0110101	35	G	4	&
8	10100	14	1101001	69	H	4	# or motor stop
9	00110	06	1001101	4D	I	8	8
10	01011	0B	0010111	17	J	BELL	'
11	01111	0F	0011110	1E	K	((
12	10010	12	1100101	65	L))
13	11100	1C	0111001	39	M	.	.
14	01100	0C	1011001	59	N	,	,
15	11000	18	1110001	71	O	9	9
16	10110	16	0101101	2D	P	0	0
17	10111	17	0101110	2E	Q	1	1
18	01010	0A	1010101	55	R	4	4
19	00101	05	1001011	4B	S	'	BELL
20	10000	10	1110100	74	T	5	5
21	00111	07	1001110	4E	U	7	7
22	11110	1E	0111100	3C	V	=	;
23	10011	13	0100111	27	W	2	2
24	11101	1D	0111010	3A	X	/	/
25	10101	15	0101011	2B	Y	6	6
26	10001	11	1100011	63	Z	+	"
27	01000	08	1111000	78	← CR (Carriage return)		
28	00010	02	1101100	6C	≡ LF (Line feed)		
29	11111	1F	1011010	5A	↓ LTRS (Letter shift)		
30	11011	1B	0110110	36	↑ FIGS (Figure shift)		
31	00100	04	1011100	5C	SP (Space)		
32	00000	00	1101010	6A	BLK (Blank)		

Notes

- ¹ 1 represents the mark condition (shown as Z in ITU recommendations) which is the higher emitted radio frequency for FSK, the lower audio frequency for AFSK. 0 represents the space condition (shown as A in ITU documents). Bits are numbered 0 (least-significant bit) through 4 (most-significant bit). The order of bit transmission is LSB first, MSB last. Symbols A and Z are defined in CCIR Rec. R.140.
- ² 1 represents the mark condition (shown as B in CCIR recommendations), which is the higher emitted radio frequency for FSK, the lower audio frequency for AFSK. 0 represents the space condition (shown as Y in CCIR recommendations). Bits are numbered 0 (LSB) through 6 (MSB). The order of bit transmission is LSB first, MSB last.
- ³ Many U.S. teletypewriters have these figures case characters.
- ⁴ At present unassigned. Reception of these signals, however, should not initiate a request for repetition.
- ⁵ The pictorial representations of ☒ or ✖ indicate WRU (Who are you?), which is used for an answer-back function in telex networks.

Baudot Signaling Rates and Speeds

<i>Signaling Rate (bauds)</i>	<i>Data Pulse (ms)</i>	<i>Stop Pulse (ms)</i>	<i>Speed (WPM)</i>	<i>Common Name</i>
45.45	22.0	22.0	65.00	Western Union
	22.0	31.0	61.33	"60 speed"
	22.0	33.0	60.61	45 bauds
50.00	20.0	30.0	66.67	European; 50 bauds
56.92	17.57	25.00	76.68	"75 speed"
	17.57	26.36	75.89	57 bauds
74.20	13.47	19.18	100.00	"100 speed"
	13.47	20.21	98.98	74 bauds
100.0	10.00	15.00	133.33	100 bauds

Code Conversion, ITA1 through 4 (Notes 1 and 2)

Combination number	ITA1 Bit No. 43210	Figure Case ITA1	Letter Case All Codes	Figure Case ITA2-4	ITA2 Bit No. 43210	ITA3 Bit No. 6543210	ITA4 Bit No. 543210
1	++++-	1	A	—	00011	0101100	000110
2	+---++	8	B	?	11001	1001100	110010
3	+---+-	9	C	:	01110	0011001	011100
4	+-----	0	D	Note 4	01001	0011100	010010
5	+++--+	2	E	3	00001	0001110	000010
6	+----+	Note 3	F	Note 4	01101	1100100	011010
7	+--+--+	7	G	Note 4	11010	1000011	110100
8	+---+-	+	H	Note 4	10100	0100101	101000
9	++----+	Note 3	I	8	00110	0000111	001100
10	+----+	6	J	BELL	01011	1100010	010110
11	---+--	(K	(01111	1101000	011110
12	---+--	=	L)	10010	0100011	100100
13	---+--)	M	.	11100	1000101	111000
14	-----+	Note 3	N	,	01100	0010101	011000
15	++-----	5	O	9	11000	0110001	110000
16	-----	%	P	0	10110	0101001	101100
17	----+-	/	Q	1	10111	1011000	101110
18	----++	—	R	4	01010	0010011	010100
19	-+---+	.	S	'	00101	0101010	001010
20	-+---+	Note 3	T	5	10000	1010001	100000
21	++---+	4	U	7	00111	0100110	001110
22	-+---+	'	V	=	11110	1001001	111100
23	-+---+	?	W	2	10011	1010010	100110
24	-+---+	,	X	/	11101	0110100	111010
25	++---++	3	Y	6	10101	1010100	101010
26	-+---+	:	Z	+	10001	1000110	100010
27	+++---	Carriage return		Carriage return	01000	1100001	010000
28	-+---+	Line feed		Line feed	00010	0001101	000100
29	-+---+	Letter blank (space)		Letter shift	11111	0111000	111110
30	+----+	Figure blank (space)		Figure shift	11011	0110010	110110
31	---+--	Error		Space	00100	0001011	001000
32	+++++	Instrument at rest		Blank	00000	1110000	000001
—				Phasing signal	—	—	110011
—				Signal repetition	—	0010110	—
—				Signal alpha	Note 5	1001010	000000
—				Signal beta	Note 6	0011010	111111

Notes

Note 1: For complete specifications of these codes see the following International Telecommunication Union documents: ITA1 and 2—Telegraph Regulations (Geneva Revision, 1958), ITA3—CCITT Rec. S.13, ITA4—CCITT Rec. R.44.

Note 2: In ITA1, + indicates positive current, – negative current. In ITA2 through ITA4, 1 represents mark condition (shown as Z in ITU recommendations, which is the higher emitted radio frequency for FSK, the lower for AFSK). 0 represents the space condition (shown as A in ITU recommendations). For meanings of A and Z see CCITT Rec. 140. The normal order of bit transmission is lowest significant bit (LSB) first.

Note 3: At the disposal of each administration for its internal service.

Note 4: At present unassigned. Reception of these signals, however, should not initiate a request for repetition. See CCITT Rec S.4.

Note 5: Permanent 0 polarity.

Note 6: Permanent 1 polarity.

Conversion from ASCII to Morse and Baudot

ASCII		Int'l Morse		Baudot	
Code	Char	Code	Char	Code 1 43210	Char ²
0000000	NUL			↑↓ 00000	Blank
0000001	SOH				
0000010	STX				
0000011	ETX				
0000100	EOT				
0000101	ENQ			↑ 01001	WRU (ITA)
0000110	ACK			↑ 01011	Bell (ITA)
0000111	BEL			↑ 00101	Bell (U.S.)
0001000	BS				
0001001	HT				
0001010	LF			↑↓ 00010	LF
0001011	VT				
0001100	FF				
0001101	CR			↑↓ 01000	CR
0001110	SO				
0001111	SI				
0010000	DLE				
0010001	DC1				
0010010	DC2				
0010011	DC3				
0010100	DC4				
0010101	NAK				
0010110	SYN				
0010111	ETB				
0011000	CAN				
0011001	EM				
0011010	SUB				
0011011	ESC				
0011100	FS				
0011101	GS				
0011110	RS				
0011111	US				
0100000	SP	Space		00100	SP
0100001	!				
0100010	"	• - • • - •	AF "	↑ 10001	" (U.S.)
0100011	#			↑ 10100	# (U.S.)
0100100	\$	• • • - • • -	SX \$	↑ 01001	\$ (U.S.)
0100101	%				
0100110	&				
0100111	'	• - - - - •	WG '	↑ 00101	' (ITA)
				↑ 01011	' (U.S.)
0101000	(- • - - •	KN (↑ 01111	(
0101001)	- • - - • -	KK)	↑ 10010)
0101010	*				
0101011	+	• - • - •	AR +	↑ 10001	+ (ITA)
0101100	,	- • • - -	MIM ,	↑ 01100	,
0101101	-	- • • • • -	DU -	↑ 00011	-
0101110	.	• - • - • -	AAA .	↑ 11100	.
0101111	/	- • • - •	DN /	↑ 11101	/
0110000	0	- - - - -	0	↑ 10110	0
0110001	1	• - - - -	1	↑ 10111	1
0110010	2	• • - - -	2	↑ 10011	2
0110011	3	• • • - -	3	↑ 00001	3
0110100	4	• • • • -	4	↑ 01010	4
0110101	5	• • • • •	5	↑ 10000	5

Continued on [next page](#).

Conversion from ASCII to Morse and Baudot

Continued from [previous page](#).

ASCII		Int'l Morse		Baudot	
Code	Char	Code	Char	Code	Char ²
0110110	6	-...•	6	↑ 10101	6
0110111	7	--...•	7	↑ 00111	7
0111000	8	---..•	8	↑ 00110	8
0111001	9	----.•	9	↑ 11000	9
0111010	:	----...•	OS :	↑ 01110	:
0111011	;	-•-•-•	KR ;	↑ 11110	; (U.S.)
0111100	<				
0111101	=	-...-	BT̄ =	↑ 11110	= (ITA)
0111110	>				
0111111	?	•- - - ••	IMI ?	↑ 11001	?
1000000	@				
1000001	A	•-	A	↓ 00011	A
1000010	B	-...•	B	↓ 11001	B
1000011	C	-•-•	C	↓ 01110	C
1000100	D	-..•	D	↓ 01001	D
1000101	E	•	E	↓ 00001	E
1000110	F	••-•	F	↓ 01101	F
1000111	G	--•	G	↓ 11010	G
1001000	H	••••	H	↓ 10100	H
1001001	I	••	I	↓ 00110	I
1001010	J	•----	J	↓ 01011	J
1001011	K	-•-	K	↓ 01111	K
1001100	L	•-••	L	↓ 10010	L
1001101	M	--	M	↓ 11100	M
1001110	N	-•	N	↓ 01100	N
1001111	O	---	O	↓ 11000	O
1010000	P	•--•	P	↓ 10110	P
1010001	Q	--•-	Q	↓ 10111	Q
1010010	R	•-•	R	↓ 01010	R
1010011	S	•••	S	↓ 00101	S
1010100	T	-	T	↓ 10000	T
1010101	U	••-	U	↓ 00111	U
1010110	V	•••-	V	↓ 11110	V
1010111	W	•--	W	↓ 10011	W
1011000	X	-••--	X	↓ 11101	X
1011001	Y	-•--	Y	↓ 10101	Y
1011010	Z	--••	Z	↓ 10001	Z
1011011	[
1011100	\				
1011101]				
1011110	^				
1011111	˘	•- - - •-	iQ̄		
1100000					
1100001	a	•-	A	↓ 00011	A
1100010	b	-...•	B	↓ 11001	B
1100011	c	-•-•	C	↓ 01110	C
1100100	d	-..•	D	↓ 01001	D
1100101	e	•	E	↓ 00001	E
1100110	f	••-•	F	↓ 01101	F
1100111	g	--•	G	↓ 11010	G
1101000	h	••••	H	↓ 10100	H
1101001	i	••	I	↓ 00110	I
1101010	j	•----	J	↓ 01011	J
1101011	k	-•-	K	↓ 01111	K
1101100	l	•-••	L	↓ 10010	L

Continued on [next page](#).

Conversion from ASCII to Morse and Baudot

Continued from [previous page](#).

<i>ASCII</i>		<i>Int'l Morse</i>		<i>Baudot</i>	
<i>Code</i>	<i>Char</i>	<i>Code</i>	<i>Char</i>	<i>Code</i>	<i>Char</i> ²
6543210				¹ 43210	
1101101	m	--	M	↓ 11100	M
1101110	n	-•	N	↓ 01100	N
1101111	o	---	O	↓ 11000	O
1110000	p	•--•	P	↓ 10110	P
1110001	q	--•-	Q	↓ 10111	Q
1110010	r	•-•	R	↓ 01010	R
1110011	s	•••	S	↓ 00101	S
1110100	t	-	T	↓ 10000	T
1110101	u	••-	U	↓ 00111	U
1110110	v	•••-	V	↓ 11110	V
1110111	w	•--	W	↓ 10011	W
1111000	x	--•-	X	↓ 11101	X
1111001	y	-•---	Y	↓ 10101	Y
1111010	z	--••	Z	↓ 10001	Z
1111011	{				
1111100					
1111101	}				
1111110	~				
1111111	DEL				

Notes

- ¹ In Baudot code, it is necessary to check to see what the current case is before conversion (↓ = letters, ↑ = figures, ↓↑ = either case).
- ² Figures–case characters are the same for both ITA2 and U.S. teletypewriters except where indicated.

Data Interface Connections

<i>Pin</i>	<i>Ckt</i>	<i>EIA-232-D Description</i>	<i>No.</i>	<i>V. 24 Name</i>	<i>Common Abbr.*</i>
1	—	Shield			
2	BA	Transmitted Data	103	Transmitted Data	TxD
3	BB	Received Data	104	Received Data	RxD
4	CA	Request to Send	105	Request to Send	RTS
5	CB	Clear to Send	106	Clear to Send	CTS
6	CC	DCE Ready	107	Data Set Ready	DSR
7	AB	Signal Ground	102	Signal Ground	SG
8	CF	Received Line Signal Detector	109	Data Carrier Detect	CD
9	—	(Reserved for Testing)			
10	—	(Reserved for Testing)			
11	—	Unassigned			
12	SCF/CI	Sec. Rec'd Line Sig. Detector/Data Sig. Rate Select (DCE Source)	122	Backward Channel Received Line Signal Detector	SCD
13	SCB	Sec. Clear to Send	121	Backward Channel Ready	SCTS
14	SBA	Sec. Transmitted Data	118	Transmitted Backward Channel Data	STxD
15	DB	Transmission Signal Element Timing (DCE Source)	114	Transmitter Signal Element Timing (DCE Source)	TxC
16	SSB	Sec. Received Data	119	Received Backward Channel Data	SRxD
17	DD	Receiver Signal Element Timing (DCE Source)	115	Receiver Signal Element	RxC
18	LL	Local Loopback			
19	SCA	Sec. Request to Send	120	Transmitted Backward Line Signal	SRTS
20	CD	DTE Ready	108/2	Data Terminal Ready	DTR
21	RL/CG	Remote Loopback/Signal Quality Detector	110	Data Signal Quality Detector	SQ
22	CE	Ring Indicator	125	Calling Indicator	RI
23	CH/CI	Data Signal Rate Select (DTE/DCE Source)	111 112	Data Rate Selector Data Rate Selector	
24	DA	Transmit Signal Element Timing (DTE Source)	113	Transmitter Signal Element Timing, (DTE Source)	ETxC
25	TM	Test Mode			

* Most abbreviations in this column are generally recognized by association with their full names. Exceptions are: ETxC=External Transmitter Clock, RxC=Receiver Clock and TxC=Transmitter Clock.

EIA-449 37-Pin Connector Assignments

<i>Pin</i>	<i>Direction</i>	<i>Mnemonic</i>	<i>Circuit name</i>
1	—	SHIELD	
2	from DCE	SI	Signaling rate indicator
3	—	SPARE	
4	to DCE	SD	Send data
5	from DCE	ST	Send timing
6	from DCE	RD	Receive data
7	to DCE	RS	Request to send
8	from DCE	RT	Receive timing
9	from DCE	CS	Clear to send
10	to DCE	LL	Local loopback
11	from DCE	DM	Data mode
12	to DCE	TR	Terminal ready
13	from DCE	RR	Receiver ready
14	to DCE	RL	Remote loopback
15	from DCE	IC	Incoming call
16	to DCE	SF/SR	Select frequency Signaling rate selector
17	to DCE	TT	Terminal timing
18	from DCE	TM	Test mode
19	—	SG	Signal ground
20	from DCE	RC	Receive common
21	—	SPARE	
22	to DCE	SD	Send data
23	from DCE	ST	Send timing
24	from DCE	RD	Receive data
25	to DCE	RS	Request to send
26	from DCE	RT	Receive timing
27	from DCE	CS	Clear to send
28	to DCE	IS	Terminal in service
29	from DCE	DM	Data mode
30	to DCE	TR	Terminal ready
31	from DCE	RR	Receiver ready
32	to DCE	SS	Select standby
33	from DCE	SQ	Signal quality
34	to DCE	NS	New signal
35	to DCE	TT	Terminal timing
36	from DCE	SB	Standby indicator
37	to DCE	SC	Send common

EIA-449 9-Pin Connector Assignments

<i>Pin</i>	<i>Direction</i>	<i>Mnemonic</i>	<i>Circuit Name</i>
1	—	SHIELD	
2	from DCE	SRR	Secondary receiver ready
3	to DCE	SSD	Secondary send data
4	from DCE	SRF	Secondary receive data
5	—	SG	Signal ground
6	—	RC	Receive common
7	to DCE	SRS	Secondary request to send
8	from DCE	SCS	Secondary clear to send
9	to DCE	SC	Send common

ISO 2593 Pin Allocations for V.35 Interfaces

<i>Pin</i>	<i>Circuit</i>	<i>Direction</i>	<i>Function</i>
A	101	Common	Protective ground or earth
B	102	Common	Signal ground or common return
C	105	from DTE	Request to send
D	106	to DTE	Ready for sending
E	107	to DTE	Data set ready
F	109	from DTE	Data channel received line signal detector
H	108/1	from DTE	Connect data set to line
	108/2	from DTE	Data terminal ready
	125	to DTE	Calling indicator
K	—	—	F ₁
L	—	—	F ₂
M	—	—	F ₁
N	—	—	F ₂
R	104	to DTE	Received data A-wire
T	104	to DTE	Received data B-wire
V	115	to DTE	Receiver signal element timing A-wire
X	115	to DTE	Receiver signal element timing B-wire
Y	114	to DTE	Transmitter signal element timing A-wire

N = Pins permanently reserved for national use. Pins HH, JJ and KK are used in the U.K. for transmitter-clock control.

AA	114	to DTE	Transmitter signal element timing B-wire
P	103	from DTE	Transmitted data A-wire
S	103	from DTE	Transmitted data B-wire
U	113	from DTE	Transmitter signal element timing A-wire
Z	—	—	F ₃
W	113	from DTE	Transmitter signal element timing B-wire
BB	—	—	F ₃
CC	—	—	F ₄
DD	—	—	F ₅
EE	—	—	F ₄
FF	—	—	F ₅
HH	—	—	N ₁
JJ	—	—	N ₂
KK	—	—	N ₁
LL	—	—	N ₂
MM	—	—	F
NN	—	—	F

F = Pins reserved by ISO, not for national use. Subscripts indicate pins to form pairs.

RTTY Control Sequences (from CCITT Recommendation S.4)

<i>Sequence</i>	<i>Meaning</i>
ZCZC	start of message
NNNN	end of message
CCCC	enable remote reperforator (or other device)
SSSS	enable remote terminal
FFFF	disable remote reperforator
KKKK	ready for test
KLKL	enable remote reader
XXXXX	error signal

EME Software

See the [ARRL Handbook Address List](#) for contact information.

EME Tracker

RealTrak

SkymooN

VHF PAK

VK3UM EME Planner

Z-TRAK

Voluntary HF Band Plans for Considerate US Operators

The following frequencies are generally recognized for certain modes or activities (all frequencies are in MHz).

Nothing in the rules recognizes a net's, group's or any individual's special privilege to any specific frequency. Section 97.101(b) of the Rules states that "Each station licensee and each control operator must cooperate in selecting transmitting channels and in making the most effective use of the amateur service frequencies. No frequency will be assigned for the exclusive use of any station." No one "owns" a frequency.

It's good practice—and plain old common sense—for any operator, regardless of mode, to check to see if the frequency is in use prior to engaging operation. If you are there first, other operators should make an effort to protect you from interference to the extent possible given that 100% interference-free operation is an unrealistic expectation in today's congested bands.

1.800-1.830	CW, data and other narrowband modes	14.060	QRP CW calling frequency
1.810	QRP CW calling frequency	14.070-14.095	Data
1.830-1.840	CW, data and other narrowband modes, intercontinental QSOs only	14.095-14.0995	Automatically controlled data stations
1.840-1.850	CW; SSB, SSTV and other wideband modes, intercontinental QSOs only	14.100	IBP/NCDXF beacons
1.850-2.000	CW; phone, SSTV and other wideband modes	14.1005-14.112	Automatically controlled data stations
		14.230	SSTV
		14.285	QRP SSB calling frequency
		14.286	AM calling frequency
		18.100-18.105	Data
3.500-3.510	CW DX	18.105-18.110	Automatically controlled data stations
3.590	RTTY DX		
3.580-3.620	Data		
3.620-3.635	Automatically controlled data stations	21.060	QRP CW calling frequency
3.710	QRP Novice/Technician CW calling frequency	21.070-21.090	Data
3.790-3.800	DX window	21.090-21.100	Automatically controlled data stations
3.845	SSTV	21.340	SSTV
3.885	AM calling frequency	21.385	QRP SSB calling frequency
3.985	QRP SSB calling frequency	24.920-24.925	Data
		24.925-24.930	Automatically controlled data stations
7.040	RTTY DX		
	QRP CW calling frequency		
7.075-7.100	Phone in KH/KL/KP <i>only</i>	28.060	QRP CW calling frequency
7.080-7.100	Data	28.070-28.120	Data
7.100-7.105	Automatically controlled data stations	28.120-28.189	Automatically controlled data stations
7.110	QRP Novice/Technician CW calling frequency	28.190-28.225	Beacons
7.171	SSTV	28.385	QRP SSB calling frequency
7.285	QRP SSB calling frequency	28.680	SSTV
7.290	AM calling frequency	29.000-29.200	AM
		29.300-29.510	Satellite downlinks
10.106	QRP CW calling frequency	29.520-29.580	Repeater inputs
10.130-10.140	Data	29.600	FM simplex
10.140-10.150	Automatically controlled data stations	29.620-29.680	Repeater outputs


Notes

ARRL band plans for frequencies above 28.300 MHz are shown in *The ARRL Repeater Directory* and *The FCC Rule Book*. For detailed packet frequencies, see *QST*, September 1987, page 54, and March 1988, page 51.

IBP/NCDXF beacons operate on 14.100, 18.110, 21.150, 24.930 and 28.200 MHz.


TVI Troubleshooting Flowchart

(also see [EMI](#) chapter)




TV Channels vs Harmonics

This chart shows CATV and broadcast channels used in the United States and their relationship to the harmonics of MF, HF, VHF and UHF amateur bands.




US Amateur Bands/Power Limits

160 METERS




Amateur stations operating at 1900-2000 kHz must not cause harmful interference to the radiolocation service and are afforded no protection from radiolocation operations.

80 METERS



5167.5 kHz (SSB only): Alaska emergency use only.

40 METERS




* Phone and Image modes are permitted between 7075 and 7100 kHz for FCC licensed stations in ITU Regions 1 and 3 and by FCC licensed stations in ITU Region 2 West of 130 degrees West longitude or South of 20 degrees North latitude. See Sections 97.305(c) and 97.307(f)(11). Novice and Technician Plus licensees outside ITU Region 2 may use CW only between 7050 and 7075 kHz. See Section 97.301(e). These exemptions do not apply to stations in the continental US.

30 METERS




Maximum power on 30 meters is 200 watts PEP output. Amateurs must avoid interference to the fixed service outside the US.


20 METERS




17 METERS




15 METERS



12 METERS




10 METERS




Novices and Technician Plus Licensees are limited to 200 watts PEP output on 10 meters.

6 METERS



2 METERS




1.25 METERS




Novices are limited to 25 watts PEP output from 222 to 225 MHz.


70 CENTIMETERS **



33 CENTIMETERS **



23 CENTIMETERS **



Novices are limited to 5 watts PEP output from 1270 to 1295 MHz.

US AMATEUR BANDS

December 20, 1994

US AMATEUR POWER LIMITS

At all times, transmitter power should be kept down to that necessary to carry out the desired communications. Power is rated in watts PEP output. Unless otherwise stated, the maximum power output is 1500 W. Power for all license classes is limited to 200 W in the 10,100-10,150 kHz band and in all Novice subbands below 28,100 kHz. Novices and Technicians are restricted to 200 W in the 28,100-28,500 kHz subbands. In addition, Novices are restricted to 25 W in the 222-225 MHz band and 5 W in the 1270-1295 MHz subband.

Operators with Technician class licenses and above may operate on all bands above 50 MHz. For more detailed information see *The FCC Rule Book*.

KEY

- = CW, RTTY and data
- = CW, RTTY, data, MCW, test, phone and image
- = CW, phone and image
- = CW and phone
- = CW, RTTY, data, phone, and image
- = CW only

E = EXTRA CLASS
A = ADVANCED
G = GENERAL
P = TECHNICIAN PLUS
T = TECHNICIAN
N = NOVICE

** Geographical and power restrictions apply to these bands. See *The FCC Rule Book* for more information about your area.

Above 23 Centimeters:

All licensees except Novices are authorized all modes on the following frequencies:

- 2300-2310 MHz
- 2390-2450 MHz
- 3300-3500 MHz
- 5650-5925 MHz
- 10.0-10.5 GHz
- 24.0-24.25 GHz
- 47.0-47.2 GHz
- 75.5-81.0 GHz
- 119.98-120.02 GHz
- 142-149 GHz
- 241-250 GHz
- All above 300 GHz

For band plans and sharing arrangements, see *The ARRL Operating Manual* or *The FCC Rule Book*.



VHF/UHF/EHF Calling Frequencies


Band (MHz)	Calling Frequency
50	50.125 SSB 50.620 digital (packet) 52.525 National FM simplex frequency
144	144.010 EME 144.100, 144.110 CW 144.200 SSB 146.520 National FM simplex frequency
222	222.100 CW/SSB 223.500 National FM simplex frequency
432	432.010 EME 432.100 CW/SSB 446.000 National FM simplex frequency
902	902.100 CW/SSB 903.1 Alternate CW, SSB 906.500 National FM simplex frequency
1296	1294.500 National FM simplex frequency 1296.100 CW/SSB
2304	2304.4 2305.2 FM simplex frequency
10000	10368.1 Narrow-band

VHF/UHF Activity Nights

Some areas do not have enough VHF/UHF activity to support contacts at all times. This schedule is intended to help VHF/UHF operators make contact. This is only a starting point; check with others in your area to see if local hams have a different schedule.

Band (MHz)	Day	Local Time
50	Sunday	6 PM
144	Monday	7 PM
222	Tuesday	8 PM
432	Wednesday	9 PM
902	Friday	9 PM
1296	Thursday	10 PM

ITU Regions



The International Telecommunication Union divides the world into three regions. Geographic details appear in *The FCC Rule Book*.

Allocation of International Call Signs

Call Sign Series	Allocated to	Call Sign Series	Allocated to	Call Sign Series	Allocated to
AAA-ALZ	United States of America	FAA-FZZ	France	OFA-OJZ	Finland
AMA-AOZ	Spain	GAA-GZZ	United Kingdom of Great Britain and Northern Ireland	OKA-OLZ	Czech Republic
APA-ASZ	Pakistan			OMA-OMZ	Slovak Republic
ATA-AWZ	India	HAA-HAZ	Hungary	ONA-OTZ	Belgium
AXA-AXZ	Australia	HBA-HBZ	Switzerland	OUA-OZZ	Denmark
AYA-AZZ	Argentina	HCA-HDZ	Ecuador	PAA-PIZ	Netherlands
A2A-A2Z	Botswana	HEA-HEZ	Switzerland	PJA-PJZ	Netherlands
A3A-A3Z	Tonga	HFA-HFZ	Poland		Antilles
A4A-A4Z	Oman	HGA-HGZ	Hungary	PKA-POZ	Indonesia
A5A-A5Z	Bhutan	HHA-HHZ	Haiti	PPA-PYZ	Brazil
A6A-A6Z	United Arab Emirates	HIA-HIZ	Dominican Republic	PZA-PZZ	Suriname
		HJA-HKZ	Colombia	P2A-P2Z	Papua New Guinea
A7A-A7Z	Qatar	HLA-HLZ	South Korea	P3A-P3Z	Cyprus
A8A-A8Z	Liberia	HLA-HLZ	South Korea	P4A-P4Z	Aruba
A9A-A9Z	Bahrain	HMA-HMZ	North Korea	P5A-P9Z	North Korea
BAA-BZZ	China	HNA-HNZ	Iraq	RAA-RZZ	Russian Federation
CAA-CEZ	Chile	HOA-HPZ	Panama	SAA-SMZ	Sweden
CFA-CKZ	Canada	HQA-HRZ	Honduras	SNA-SRZ	Poland
CLA-CMZ	Cuba	HSA-HSZ	Thailand	• SSA-SSM	Egypt
CNA-CNZ	Morocco	HTA-HTZ	Nicaragua	• SSN-SSZ	Sudan
COA-COZ	Cuba	HUA-HUZ	El Salvador	STA-STZ	Sudan
CPA-CPZ	Bolivia	HVA-HVZ	Vatican City	SUA-SUZ	Egypt
CQA-CUZ	Portugal	HWA-HYZ	France	SVA-SZZ	Greece
CVA-CXZ	Uruguay	HZA-HZZ	Saudi Arabia	S2A-S3Z	Bangladesh
CYA-CZZ	Canada	H2A-H2Z	Cyprus	S5A-S5Z	Slovenia
C2A-C2Z	Nauru	H3A-H3Z	Panama	S6A-S6Z	Singapore
C3A-C3Z	Andorra	H4A-H4Z	Solomon Islands	S7A-S7Z	Seychelles
C4A-C4Z	Cyprus	H6A-H7Z	Nicaragua	S8A-S8Z	South Africa
C5A-C5Z	Gambia	H8A-H9Z	Panama	S9A-S9Z	Sao Tome and Principe
* C7A-C7Z	World Meteorological Organization	IAA-IZZ	Italy	TAA-TCZ	Turkey
		JAA-JSZ	Japan	TDA-TDZ	Guatemala
		JTA-JVZ	Mongolia	TEA-TEZ	Costa Rica
		JWA-JXZ	Norway	TFA-TFZ	Iceland
C8A-C9Z	Mozambique	JYA-JYZ	Jordan	TGA-TGZ	Guatemala
DAA-DRZ	Germany	JZA-JZZ	Indonesia	THA-THZ	France
DSA-DTZ	South Korea	J2A-J2Z	Djibouti	TIA-TIZ	Costa Rica
DUA-DZZ	Philippines	J3A-J3Z	Grenada	TJA-TJZ	Cameroon
D2A-D3Z	Angola	J4A-J4Z	Greece	TKA-TKZ	France
D4A-D4Z	Cape Verde	J5A-J5Z	Guinea-Bissau	TLA-TLZ	Central African Republic
D5A-D5Z	Liberia	J6A-J6Z	Saint Lucia		
D6A-D6Z	Comoros	J7A-J7Z	Dominica	TMA-TMZ	France
D7A-D9Z	South Korea	J8A-J8Z	St. Vincent and the Grenadines	TNA-TNZ	Congo Republic
EAA-EHZ	Spain		United States of America	TOA-TQZ	France
EIA-EJZ	Ireland	KAA-KZZ	Norway	TRA-TRZ	Gabon
EKA-EKZ	Armenia		Argentina	TSA-TSZ	Tunisia
ELA-ELZ	Liberia	LAA-LNZ	Luxembourg	TTA-TTZ	Chad
EMA-EOZ	Ukraine	LOA-LWZ	Lithuania	TUA-TUZ	Ivory Coast
EPA-EQZ	Iran	LXA-LXZ	Bulgaria	TVA-TXZ	France
ERA-ERZ	Moldova	LYA-LYZ	Argentina	TYA-TYZ	Benin
ESA-ESZ	Estonia	LZA-LZZ	United Kingdom of Great Britain and Northern Ireland	TZA-TZZ	Mali
ETA-ETZ	Ethiopia	L2A-L9Z	United States of America	T2A-T2Z	Tuvalu
EUA-EWZ	Belarus	MAA-MZZ	Peru	T3A-T3Z	Kiribati
EXA-EXZ	Kyrgyzstan		Lebanon	T4A-T4Z	Cuba
EYA-EYZ	Tajikistan	NAA-NZZ	Austria	T5A-T5Z	Somalia
EZA-EZZ	Turkmenistan			T6A-T6Z	Afghanistan
E2A-E2Z	Thailand	OAA-OCZ		T7A-T7Z	San Marino
E3A-E3Z	Eritrea	ODA-ODZ			
† E4A-E4Z	Palestinian Authority	OEA-OEZ			

Continued on [next page](#).

Allocation of International Call Signs

Continued from [previous page](#).

Call Sign Series	Allocated to	Call Sign Series	Allocated to	Call Sign Series	Allocated to
T8A-T8Z	Palau	ZBA-ZJZ	United Kingdom of Great Britain and Northern Ireland	5VA-5VZ	Togo
T9A-T9Z	Bosnia and Herzegovina			5WA-5WZ	Western Samoa
UAA-UIZ	Russian Federation	ZKA-ZMZ	New Zealand	5XA-5XZ	Uganda
UJA-UMZ	Uzbekistan	ZNA-ZOZ	United Kingdom of Great Britain and Northern Ireland	5YA-5ZZ	Kenya
UNA-UQZ	Kazakhstan			6AA-6BZ	Egypt
URA-UZZ	Ukraine	ZPA-ZPZ	Paraguay	6CA-6CZ	Syria
VAA-VGZ	Canada	ZQA-ZQZ	United Kingdom of Great Britain and Northern Ireland	6DA-6JZ	Mexico
VHA-VNZ	Australia			6KA-6NZ	South Korea
VOA-VOZ	Canada	ZRA-ZUZ	South Africa	6OA-6OZ	Somalia
VPA-VQZ	United Kingdom of Great Britain and Northern Ireland	ZVA-ZZZ	Brazil	6PA-6SZ	Pakistan
† VRA-VRZ	China—Hong Kong	Z2A-Z2Z	Zimbabwe	6TA-6UZ	Sudan
VSA-VSZ	United Kingdom of Great Britain and Northern Ireland	Z3A-Z3Z	Macedonia (Former Yugoslav Republic)	6VA-6WZ	Senegal
		2AA-2ZZ	United Kingdom of Great Britain and Northern Ireland	6XA-6XZ	Madagascar
VTA-VWZ	India			6YA-6YZ	Jamaica
VXA-VYZ	Canada	3AA-3AZ	Monaco	6ZA-6ZZ	Liberia
VZA-VZZ	Australia	3BA-3BZ	Mauritius	7AA-7IZ	Indonesia
V2A-V2Z	Antigua and Barbuda	3CA-3CZ	Equatorial Guinea	7JA-7NZ	Japan
V3A-V3Z	Belize	• 3DA-3DM	Swaziland	7OA-7OZ	Yemen
V4A-V4Z	Saint Kitts and Nevis	• 3DN-3DZ	Fiji	7PA-7PZ	Lesotho
V5A-V5Z	Namibia	3EA-3FZ	Panama	7QA-7QZ	Malawi
V6A-V6Z	Namibia	3GA-3GZ	Chile	7RA-7RZ	Algeria
V7A-V7Z	Micronesia	3HA-3UZ	China	7SA-7SZ	Sweden
V8A-V8Z	Marshall Islands	3VA-3VZ	Tunisia	7TA-7YZ	Algeria
WAA-WZZ	Brunei	3WA-3WZ	Viet Nam	7ZA-7ZZ	Saudi Arabia
	United States of America	3XA-3XZ	Guinea	8AA-8IZ	Indonesia
XAA-XIZ	Mexico	3YA-3YZ	Norway	8JA-8NZ	Japan
XJA-XOZ	Canada	3ZA-3ZZ	Poland	8OA-8OZ	Botswana
XPA-XPZ	Denmark	4AA-4CZ	Mexico	8PA-8PZ	Barbados
XQA-XRZ	Chile	4DA-4IZ	Philippines	8QA-8QZ	Maldives
XSA-XSZ	China	4JA-4KZ	Azerbaijan	8RA-8RZ	Guyana
XTA-XTZ	Burkina Faso	4LA-4LZ	Georgia	8SA-8SZ	Sweden
XUA-XUZ	Cambodia	4MA-4MZ	Venezuela	8TA-8YZ	India
XVA-XVZ	Viet Nam	4NA-4OZ	Yugoslavia	8ZA-8ZZ	Saudi Arabia
XWA-XWZ	Laos	4PA-4SZ	Sri Lanka	9AA-9AZ	Croatia
XXA-XXZ	Portugal	4TA-4TZ	Peru	9BA-9DZ	Iran
XYA-XZZ	Myanmar	* 4UA-4UZ	United Nations	9EA-9FZ	Ethiopia
YAA-YAZ	Afghanistan	4VA-4VZ	Haiti	9GA-9GZ	Ghana
YBA-YHZ	Indonesia	4XA-4XZ	Israel	9HA-9HZ	Malta
YIA-YIZ	Iraq	* 4YA-4YZ	International Civil Aviation Organization	9IA-9JZ	Zambia
YJA-YJZ	Vanuatu			9KA-9KZ	Kuwait
YKA-YKZ	Syria	4ZA-4ZZ	Israel	9LA-9LZ	Sierra Leone
YLA-YLZ	Latvia	5AA-5AZ	Libya	9MA-9MZ	Malaysia
YMA-YMZ	Turkey	5BA-5BZ	Cyprus	9NA-9NZ	Nepal
YNA-YNZ	Nicaragua	5CA-5GZ	Morocco	9OA-9TZ	Democratic Republic of Congo
YOA-YRZ	Romania	5HA-5IZ	Tanzania	9UA-9UZ	Burundi
YSA-YSZ	El Salvador	5JA-5KZ	Colombia	9VA-9VZ	Singapore
YTA-YUZ	Yugoslavia	5LA-5MZ	Liberia	9WA-9WZ	Malaysia
YVA-YYZ	Venezuela	5NA-5OZ	Nigeria	9XA-9XZ	Rwanda
YZA-YZZ	Yugoslavia	5PA-5QZ	Denmark	9YZ-9ZZ	Trinidad and Tobago
Y2A-Y9Z	Germany	5RA-5SZ	Madagascar		
ZAA-ZAZ	Albania	5TA-5TZ	Mauritania		
		5UA-5UZ	Niger		

Notes:

- Half series
- * Series allocated to an international organization
- † Provisional allocation in accordance with S19.33

FCC-Allocated Prefixes for Areas Outside the Continental US

Prefix

AH1, KH1, NH1, WH1
AH2, KH2, NH2, WH2
AH3, KH3, NH3, WH3
AH4, KH4, NH4, WH4
AH5K, KH5K, NH5K, WH5K
AH5, KH5, NH5, WH5 (except K suffix)
AH6-7, KH6-7, NH6-7, WH6-7
AH7K, KH7K, NH7K, WH7K
AH8, KH8, NH8, WH8
AH9, KH9, NH9, WH9
AH0, KH0, NH0, WH0
AL, KL, NL, WL
KP1, NP1, WP1
KP2, NP2, WP2
KP3-4, NP3-4, WP3-4
KP5, NP5, WP5

Location

Baker, Howland Is
Guam
Johnston I
Midway I
Kingman Reef
Palmyra, Jarvis Is
Hawaii
Kure I
American Samoa
Wake, Wilkes, Peale Is
Northern Mariana Is
Alaska
Navassa
Virgin Is
Puerto Rico
Desecheo

DX Operating Code

For W/VE Amateurs

Some DXers have caused considerable confusion and interference in their efforts to work DX stations. The points below, if observed by all W/VE amateurs, will help make DX more enjoyable for all.

- 1) Call DX only after he calls CQ, QRZ? or signs \overline{SK} , or voice equivalents thereof. Make your calls short.
- 2) Do not call a DX station:
 - a) On the frequency of the station he is calling until you are sure the QSO is over (\overline{SK}).
 - b) Because you hear someone else calling him.
 - c) When he signs \overline{KN} , \overline{AR} or CL.
 - d) Exactly on his frequency.
 - e) After he calls a directional CQ, unless of course you are in the right direction or area.
- 3) Keep within frequency band limits. Some DX stations can get away with working outside, but you cannot.
- 4) Observe calling instructions given by DX stations. Example: 15U means "call 15 kHz up from my frequency." 15D means down, etc.
- 5) Give honest reports. Many DX stations depend on W/VE reports for adjustment of station and equipment.
- 6) Keep your signal clean. Key clicks, ripple, feedback or splatter gives you a bad reputation and may get you a citation from the FCC.
- 7) *Listen* and call the station you want. Calling CQ DX is not the best assurance that the rare DX will reply.
- 8) When there are several W or VE stations waiting, avoid asking DX to "listen for a friend." Also avoid engaging him in a ragchew against his wishes.

For Overseas Amateurs

To all overseas amateur stations:

In their eagerness to work you, many W and VE amateurs resort to practices that cause confusion and QRM. Most of this is good-intentioned but ill-advised; some of it is intentional and selfish. The key to the cessation of unethical DX operating practices is in your hands. We believe that your adoption of certain operating habits will increase your enjoyment of Amateur Radio and that of amateurs on this side who are eager to work you. We recommend your adoption of the following principles:

- 1) Do not answer calls on your own frequency.
- 2) Answer calls from W/VE stations only when their signals are of good quality.
- 3) Refuse to answer calls from other stations when you are already in contact with someone, and do not acknowledge calls from amateurs who indicate they wish to be "next."
- 4) Give *everybody* a break. When many W/VE amateurs are patiently and quietly waiting to work you, avoid complying with requests to "listen for a friend."
- 5) Tell listeners where to call you by indicating how many kilohertz up (U) or down (D) from your frequency you are listening.
- 6) Use the ARRL-recommended ending signals, especially \overline{KN} to indicate to impatient listeners the status of the QSO. \overline{KN} means "Go ahead (specific station); all others keep out."
- 7) Let it be known that you avoid working amateurs who are constant violators of these principles.

W1AW's schedule is at the same local time throughout the year. The schedule according to your local time will change if your local time does not have seasonal adjustments that are made at the same time as North American time changes between standard time and daylight time. From the first Sunday in April to the last Sunday in October, UTC = Eastern Time + 4 hours. For the rest of the year, UTC = Eastern Time + 5 hours.

Morse code transmissions:

Frequencies are 1.818, 3.5815, 7.0475, 14.0475, 18.0975, 21.0675, 28.0675 and 147.555 MHz.

Slow Code = practice sent at 5, 7^{1/2}, 10, 13 and 15 wpm.


Fast Code = practice sent at 35, 30, 25, 20, 15, 13 and 10 wpm.

Code practice text is from the pages of QST. The source is given at the beginning of each practice session and alternate speeds within each session. For example, "Text is from July 1992 QST, pages 9 and 81," indicates that the plain text is from the article on page 9 and mixed number/letter groups are from page 81.

Code bulletins are sent at 18 wpm.

W1AW qualifying runs are sent on the same frequencies as the Morse code transmissions. West Coast qualifying runs are transmitted on approximately 3.590 MHz by W6OWP, with K6YR as an alternate. At the beginning of each code practice session, the schedule for the next qualifying run is presented. Underline one minute of the highest speed you copied, certify that your copy was made without aid, and send it to ARRL for grading. Please include your name, call sign (if any) and complete mailing address. Send a 9 x 12-inch SASE for a certificate, or a business-size SASE for an endorsement.

W1AW SCHEDULE								
Pacific	Mtn	Cent	East	Mon	Tue	Wed	Thu	Fri
6 AM	7 AM	8 AM	9 AM		Fast Code	Slow Code	Fast Code	Slow Code
7 AM-1 PM	8 AM-2 PM	9 AM-3 PM	10 AM-4 PM	Visiting Operator Time (12 PM - 1 PM closed for lunch)				
1 PM	2 PM	3 PM	4 PM	Fast Code	Slow Code	Fast Code	Slow Code	Fast Code
2 PM	3 PM	4 PM	5 PM	Code Bulletin				
3 PM	4 PM	5 PM	6 PM	Teleprinter Bulletin				
4 PM	5 PM	6 PM	7 PM	Slow Code	Fast Code	Slow Code	Fast Code	Slow Code
5 PM	6 PM	7 PM	8 PM	Code Bulletin				
6 PM	7 PM	8 PM	9 PM	Teleprinter Bulletin				
6 ⁴⁵ PM	7 ⁴⁵ PM	8 ⁴⁵ PM	9 ⁴⁵ PM	Voice Bulletin				
7 PM	8 PM	9 PM	10 PM	Fast Code	Slow Code	Fast Code	Slow Code	Fast Code
8 PM	9 PM	10 PM	11 PM	Code Bulletin				




Here's a short excerpt from a slow-speed Morse Code-practice transmission.

Teleprinter transmissions:

Frequencies are 3.625, 7.095, 14.095, 18.1025, 21.095, 28.095 and 147.555 MHz.

Bulletins are sent at 45.45-baud Baudot and 100-baud AMTOR, FEC Mode B. 110-baud ASCII will be sent only as time allows.

On Tuesdays and Fridays at 6:30 PM Eastern Time, Keplerian elements for many amateur satellites are sent on the regular teleprinter frequencies.



Listen to a Baudot RTTY transmission from W1AW.

Voice transmissions:

Frequencies are 1.855, 3.99, 7.29, 14.29, 18.16, 21.39, 28.59 and 147.555 MHz.

Miscellanea:

On Fridays, UTC, a DX bulletin replaces the regular bulletins.

W1AW is open to visitors from 10 AM until noon and from 1 PM until 3:45 PM on Monday through Friday. FCC licensed amateurs may operate the station during that time. Be sure to bring your current FCC amateur license or a photocopy.

In a communication emergency, monitor W1AW for special bulletins as follows: voice on the hour, teleprinter at 15 minutes past the hour, and CW on the half hour.

Headquarters and W1AW are closed on New Year's Day, President's Day, Good Friday, Memorial Day, Independence Day, Labor Day, Thanksgiving and the following Friday, and Christmas Day.

ARRL Procedural Signals (Prosigns)

In general, the CW prosigns are used on all data modes as well, although word abbreviations may be spelled out. That is, "CLEAR" might be used rather than "CL" on radioteletype. Additional radioteletype conventions appear at the end of the table.

Situation

check for a clear frequency
seek contact with any station
after a call to a specific named station or to indicate the end of a message
invite any station to transmit
invite a specific named station to transmit
invite receiving station to transmit
all received correctly
please stand by
end of contact (sent before call sign)
going off the air

CW

QRL?
CQ
AR
K
KN
BK
R
AS
SK
CL

Voice

Is the frequency in use?
CQ
over, end of message
go
go only
back to you
received
wait, stand by
clear
closing station

Additional RTTY prosigns

SK QRZ—Ending contact, but listening on frequency.
SK KN—Ending contact, but listening for one last transmission from the other station.
SK SZ—Signing off and listening on the frequency for any other calls.

The RST System

Readability

- 1—Unreadable.
- 2—Barely readable, occasional words distinguishable.
- 3—Readable with considerable difficulty.
- 4—Readable with practically no difficulty.
- 5—Perfectly readable.

Signal Strength

- 1—Faint signals, barely perceptible.
- 2—Very weak signals.
- 3—Weak signals.
- 4—Fair signals.
- 5—Fairly good signals.
- 6—Good signals.
- 7—Moderately strong signals.
- 8—Strong signals.
- 9—Extremely strong signals.

Tone

- 1—Sixty-cycle ac or less, very rough and broad.
- 2—Very rough ac, very harsh and broad.
- 3—Rough ac tone, rectified but not filtered.
- 4—Rough note, some trace of filtering.
- 5—Filtered rectified ac but strongly ripple-modulated.
- 6—Filtered tone, definite trace of ripple modulation.
- 7—Near pure tone, trace of ripple modulation.
- 8—Near perfect tone, slight trace of modulation.
- 9—Perfect tone, no trace of ripple of modulation of any kind.

If the signal has the characteristic steadiness of crystal control, add the letter X to the RST report. If there is a chirp, add the letter C. Similarly for a click, add K. (See FCC Regulations §97.307, Emissions Standards.) The above reporting system is used on both CW and voice; leave out the "tone" report on voice.

Q Signals

These Q signals most often need to be expressed with brevity and clarity in amateur work. (Q abbreviations take the form of questions only when each is sent followed by a question mark.)

- QRA What is the name of your station? The name of your station is _____.
- QRG Will you tell me my exact frequency (or that of _____)?
Your exact frequency (or that of _____) is _____ kHz.
- QRH Does my frequency vary? Your frequency varies.
- QRI How is the tone of my transmission? The tone of your transmission is _____ (1. Good; 2. Variable; 3. Bad).
- QRJ Are you receiving me badly? I cannot receive you. Your signals are too weak.
- QRK What is the intelligibility of my signals (or those of _____)? The intelligibility of your signals (or those of _____) is _____ (1. Bad; 2. Poor; 3. Fair; 4. Good; 5. Excellent).
- QRL Are you busy? I am busy (or I am busy with _____). Please do not interfere.
- QRM Is my transmission being interfered with? Your transmission is being interfered with (1. Nil; 2. Slightly; 3. Moderately; 4. Severely; 5. Extremely.)
- QRN Are you troubled by static? I am troubled by static _____ (1-5 as under QRM).
- QRO Shall I increase power? Increase power.
- QRP Shall I decrease power? Decrease power.
- QRQ Shall I send faster? Send faster (_____ WPM).
- QRS Shall I send more slowly? Send more slowly
(_____ WPM).
- QRT Shall I stop sending? Stop sending.
- QRU Have you anything for me? I have nothing for you.
- QRV Are you ready? I am ready.
- QRW Shall I inform _____ that you are calling on _____ kHz? Please inform _____ that I am calling on _____ kHz.
- QRX When will you call me again? I will call you again at _____ hours (on _____ kHz).
- QRY What is my turn? Your turn is numbered _____
- QRZ Who is calling me? You are being called by _____ (on _____ kHz).
- QSA What is the strength of my signals (or those of _____)?
The strength of your signals (or those of _____) is _____ (1. Scarcely perceptible; 2. Weak; 3. Fairly good; 4. Good; 5. Very good).
- QSB Are my signals fading? Your signals are fading.
- QSD Is my keying defective? Your keying is defective.
- QSG Shall I send _____ messages at a time? Send _____ messages at a time.
- QSK Can you hear me between your signals and if so can I break in on your transmission? I can hear you between my signals; break in on my transmission.
- QSL Can you acknowledge receipt? I am acknowledging receipt.
- QSM Shall I repeat the last message which I sent you, or some previous message? Repeat the last message which you sent me [or message(s) number(s) _____].
- QSN Did you hear me (or _____) on _____ kHz? I did hear you (or _____) on _____ kHz.
- QSO Can you communicate with _____ direct or by relay? I can communicate with _____ direct (or by relay through _____).
- QSP Will you relay to _____? I will relay to _____
- QST General call preceding a message addressed to all amateurs and ARRL members. This is in effect "CQ ARRL."
- QSU Shall I send or reply on this frequency (or on _____ kHz)? Send or reply on this frequency (or _____ kHz).
- QSV Shall I send a series of Vs on this frequency (or on _____ kHz)? Send a series of Vs on this frequency (or on _____ kHz).
- QSW Will you send on this frequency (or on _____ kHz)? I am going to send on this frequency (or on _____ kHz).

Continued on [next page](#).

Q Signals

Continued from [previous page](#).

- QSX Will you listen to _____ on _____ kHz? I am listening to _____ on _____ kHz.
- QSY Shall I change to transmission on another frequency? Change to transmission on another frequency (or on _____ kHz).
- QSZ Shall I send each word or group more than once? Send each word or group twice (or _____ times).
- QTA Shall I cancel message number _____? Cancel message number _____
- QTB Do you agree with my counting of words? I do not agree with your counting of words. I will repeat the first letter or digit of each word or group.
- QTC How many messages have you to send? I have _____ messages for you (or for _____).
- QTH What is your location? My location is _____
- QTR What is the correct time? The correct time is _____
- QTV Shall I stand guard for you? Stand guard for me.
- QTX Will you keep your station open for further communication with me? Keep your station open for me.
- QUA Have you news of _____? I have news of _____.

ARRL QN Signals

- QNA* Answer in prearranged order.
- QNB Act as relay between _____ and _____.
- QNC All net stations copy. I have a message for all net stations.
- QND* Net is Directed (Controlled by net control station.)
- QNE* Entire net stand by.
- QNF Net is Free (not controlled).
- QNG Take over as net control station
- QNH Your net frequency is High.
- QNI Net stations report in. I am reporting into the net. (Follow with a list of traffic or QRU.)
- QNJ Can you copy me?
- QNK* Transmit messages for _____ to _____.
- QNL Your net frequency is Low.
- QNM* You are QRMing the net. Stand by.
- QNN Net control station is _____. What station has net control?
- QNO Station is leaving the net.
- QNP Unable to copy you. Unable to copy _____.
- QNQ* Move frequency to _____ and wait for _____ to finish handling traffic. Then send him traffic for _____.
- QNR* Answer _____ and Receive traffic.
- QNS Following Stations are in the net.* (follow with list.) Request list of stations in the net.
- QNT I request permission to leave the net for _____ minutes.
- QNU* The net has traffic for *you*. Stand by.
- QNV* Establish contact with _____ on this frequency. If successful, move to _____ and send him traffic for _____.
- QNW How do I route messages for _____?
- QNX You are excused from the net.*
- QNY* Shift to another frequency (or to _____ kHz) to clear traffic with _____.
- QNZ Zero beat your signal with mine.

***For use only by the Net Control Station.**

Notes on Use of QN Signals

These QN signals are special ARRL signals for use in amateur CW nets *only*. They are not for use in casual amateur conversation. Other meanings that may be used in other services do not apply. Do not use QN signals on phone nets. *Say it with words*. QN signals need not be followed by a question mark, even though the meaning may be interrogatory.

CW Abbreviations

Although abbreviations help to cut down unnecessary transmission, make it a rule not to abbreviate unnecessarily when working an operator of unknown experience.

AA	All after	GN	Good night	RTTY	Radioteletype
AB	All before	GND	Ground	RX	Receiver
AB	About	GUD	Good	SASE	Self-addressed, stamped envelope
ADR	Address	HI	The telegraphic		
AGN	Again		laugh; high	SED	Said
ANT	Antenna	HR	Here, hear	SIG	Signature; signal
BCI	Broadcast interference	HV	Have	SINE	Operator's personal initials or nickname
BCL	Broadcast listener	HW	How		
BK	Break; break me; break in	LID	A poor operator	SKED	Schedule
		MA, MILS	Milliamperes	SRI	Sorry
BN	All between; been	MSG	Message; prefix to radiogram	SSB	Single sideband
BUG	Semi-automatic key	N	No	SVC	Service; prefix to service message
B4	Before	NCS	Net control station	T	Zero
C	Yes	ND	Nothing doing	TFC	Traffic
CFM	Confirm; I confirm	NIL	Nothing; I have nothing for you	TMW	Tomorrow
CK	Check			TNX-TKS	Thanks
CL	I am closing my station; call	NM	No more	TT	That
CLD-CLG	Called; calling	NR	Number	TU	Thank you
CQ	Calling any station	NW	Now; I resume transmission	TVI	Television interference
CUD	Could	OB	Old boy	TX	Transmitter
CUL	See you later	OC	Old chap	TXT	Text
CW	Continuous wave (i.e., radiotelegraph)	OM	Old man	UR-URS	Your; you're; yours
		OP-OPR	Operator	VFO	Variable-frequency oscillator
DE	From	OT	Old timer; old top		
DLD-DLVD	Delivered	PBL	Preamble	VY	Very
DR	Dear	PSE	Please	WA	Word after
DX	Distance, foreign countries	PWR	Power	WB	Word before
		PX	Press	WD-WDS	Word; words
ES	And, &	R	Received as transmitted; are	WKD-WKG	Worked; working
FB	Fine business, excellent	RCD	Received	WL	Well; will
FM	Frequency modulation	RCVR (RX)	Receiver	WUD	Would
		REF	Refer to; referring to; reference	WX	Weather
GA	Go ahead (or resume sending)	RFI	Radio Frequency Interference	XCVR	Transceiver
GB	Good-by			XMTR (TX)	Transmitter
GBA	Give better address	RIG	Station equipment	XTAL	Crystal
GE	Good evening	RPT	Repeat; I repeat; report	XYL (YF)	Wife
GG	Going			YL	Young lady
GM	Good morning			73	Best regards
				88	Love and Kisses

ITU Recommended Phonetics

- A — Alfa (**AL** FAH)
- B — Bravo (**BRAH** VOH)
- C — Charlie (**CHAR** LEE OR **SHAR** LEE)
- D — Delta (**DELL** TAH)
- E — Echo (**ECK** OH)
- F — Foxtrot (**FOKS** TROT)
- G — Golf (GOLF)
- H — Hotel (HOH **TELL**)
- I — India (**IN** DEE AH)
- J — Juliet (**JEW** LEE ETT)
- K — Kilo (**KEY** LOH)
- L — Lima (**LEE** MAH)
- M — Mike (MIKE)
- N — November (NO **VEM** BER)
- O — Oscar (**OSS** CAH)
- P — Papa (PAH **PAH**)
- Q — Quebec (KEH **BECK**)
- R — Romeo (**ROW** ME OH)
- S — Sierra (SEE **AIR** RAH)
- T — Tango (**TANG** GO)
- U — Uniform (**YOU** NEE FORM or **OO** NEE FORM)
- V — Victor (**VIK** TAH)
- W — Whiskey (**WISS** KEY)
- X — X-Ray (**ECKS** RAY)
- Y — Yankee (**YANG** KEY)
- Z — Zulu (**ZOO** LOO)

Note: The **Boldfaced** syllables are emphasized. The pronunciations shown in the table were designed for speakers from all international languages. The pronunciations given for "Oscar" and "Victor" may seem awkward to English-speaking people in the U.S.

ARRL Log

See inside front cover. Output in Watts. UTC recommended. RST. See back inside cover. This column may also be used for contest-exchange info received.

FIXED				VARIABLE									
DATE	FREQ.	MODE	POWER	TIME	STATION WORKED	REPORT SENT	REC'D	TIME OFF	QTH	COMMENTS NAME	QSL VIA	QSL S	R
28 Jul	14.6.52	FM	10	0430	WA1CCR				Wallingford	Eric			
3 Oct	7.0	CW	150	2319	WA6VEF	001	322	CALIF CA	CALIFORNIA	QSO PARTY			
				22	N6OJ	002	157		SONO				
				24	K6NA	003	331		SD				
				31	N6OP/M	004	117		CALAV				
9 Oct	28.6	SSB	1 kW	0301	JA10CA	59	57		Tokyo	Isao	BUR0	✓	
	21	CW		1545	EA9GD	559	579		Melilla	Jose	Box 348	✓	✓
				56	G0BDX	599	599		SOMALIA		I2YAE	✓	
5 Nov	3.810.2	SSB	150	0030	W9NA	59+	59+	0117	Wausau, WI	Reno			
9 Nov	21	CW	10	1642	G4BUE	339	449	1657		1 watt+!			

The ARRL Log is adaptable for all types of operating—ragchewing, contesting, DXing. References are to pages in the ARRL Log.

ARRL Operating Awards


Award

Friendship Award
 Rag Chewer's Club
 Worked All States (WAS)
 Worked All Continents (WAC)
 DX Century Club (DXCC)
 VHF/UHF Century Club (VUCC)
 A-1 Operator Club
 Code Proficiency
 Old Timers Club
 ARRL Membership

Qualification

Contact 26 stations with calls ending A through Z.
 A single contact 1/2 hour or longer
 QSLs from all 50 US states
 QSLs from all six continents
 QSLs from at least 100 different countries
 QSLs from many grid squares
 Recommendation by two A-1 operators
 One minute of perfect copy from W1AW qualifying run
 Held an Amateur Radio license at least 20 years prior
 ARRL membership for 25, 40, 50, 60 or 70 years

ARRL Membership QSL Card



The ARRL membership QSL card. This example is from Harris Ruben, N2ERN, who designed the card. Your card would reflect your own call sign and address; awards and VUCC grid-square are optional. ARRL does not print or sell the cards. Inquire with printers who advertise in the *QST* Ham Ads.


Mode Abbreviations for QSL Cards

Abbreviation Explanation

CW	Telegraphy
DATA	Telemetry, telecommand and computer communications (includes packet radio)
IMAGE	Facsimile and television
MCW	Tone-modulated telegraphy
PHONE	Speech and other sound
PULSE	Modulated main carrier
RTTY	Direct-printing telegraphy (includes AMTOR)
SS	Spread Spectrum
TEST	Emissions containing no information

Note: For additional information on emission types refer to latest edition of *The FCC Rule Book*.


US/Canada Map



A map showing US states, Canadian provinces and ARRL/RAC Sections.

ARRL Grid Locator Map for North America

This and a World Grid Locator Map are available from ARRL.



Operating Aids for Public Service

ARRL HQ makes available the following free operating aids for public service communications:

<i>Public Service Communications Manual</i>	FSD-235
ARRL numbered radiograms	FSD-3
Sample emergency plan	FSD-27
ARES registration form	FSD-98
Amateur message form	FSD-218
Emergency Reference information	FSD-255
Field Organization Brochure	FSD-300

This entire Public Service Package can be obtained by sending a large (9 × 12-inch) envelope with First-Class postage for 6 ounces.

Principles of Emergency Communication

- 1) *Keep the QRM level down:* Remain silent unless called upon. There are only two reasons to check into an emergency net: (1) You have a bona fide emergency; (2) the Net Control Station (NCS) is requesting help that only you can provide.
- 2) *Monitor established emergency frequencies:* Many areas have established emergency frequencies that should be monitored for possible distress calls.
- 3) *Avoid spreading rumors:* Transmit only facts, not speculation. Do not repeat messages unless so authorized by the originator, and then only word for word.
- 4) *Authenticate all messages:* Any messages of an official nature should be written and signed.
- 5) *Strive for efficiency:* You are more effective as part of a team than as a lone individual.
- 6) *Select the mode and band to suit the need:* Advantages of several modes are listed below.
- 7) *Use all communications channels intelligently:* The object is to protect lives and property. Use emergency or normal communications channels where available.
- 8) *Don't broadcast:* Our job is to communicate for, not with, the general public. See §97.113 of *The FCC Rule Book* for details.

Advantages of Various Amateur Modes for Emergency Communications

CW

- 1) Less QRM in most amateur bands.
- 2) Privacy of communications (less easily understood by the public).
- 3) Simpler transmitting equipment.
- 4) Greater accuracy than voice in record communications.
- 5) Longer range for a given transmitter power level.

Voice

- 1) More practical for portable and mobile work.
- 2) More widespread availability of operators.
- 3) Faster communication for tactical or "command" purposes.
- 4) More readily appreciated and understood by the public.
- 5) Official-to-official and phone-patch communication.

Packet/AMTOR/PACTOR/CLOVER

- 1) Less QRM in most amateur bands.
- 2) Privacy of communications (less easily understood by the public).
- 3) More widespread availability of operators.
- 4) Greater speed and accuracy of record communication than any other modes.

ARES Personal Checklist

The following represents recommendations of equipment and supplies ARES members should consider having available for use during an emergency or public-service activity.

- 1) ARES Identification Card
- 2) FCC Amateur Radio License
- 3) Radio Gear
 - rig (2 meters)
 - microphone
 - headphones
 - power supply/extra batteries
 - antennas with mounts
 - spare fuses
 - patch cords/adapters (BNC to PL259/RCA phono to PL259)
 - SWR meter
 - extra coax
- 4) Writing Gear
 - pen/pencil/eraser
 - clipboard
 - message forms
 - logbook
 - note paper
- 5) Personal Gear (short duration)
 - snacks
 - liquid refreshments
 - throat lozenges
 - personal medicine
 - aspirin
 - extra pair of prescription glasses
- 6) Personal Gear (72-hour duration)
 - foul-weather gear
 - three-day supply of drinking water
 - cooler with three-day supply of food
 - mess kit with cleaning supplies
 - first-aid kit
 - personal medicine
 - aspirin
 - throat lozenges
 - sleeping bag
 - toilet articles
 - mechanical alarm clock
 - flashlight with batteries/lantern
 - candles
 - waterproof matches
 - extra pair of prescription glasses
- 7) Tool Box (72-hour duration)
 - screwdrivers
 - pliers
 - socket wrenches
 - electrical tape
 - 12/120-V soldering iron
 - solder
 - volt-ohm meter
- 8) Other (72-hour duration)
 - hatchet/ax
 - saw
 - pick
 - shovel
 - siphon
 - jumper cables
 - $\frac{3}{8}$ -inch rope
 - highway flares
 - extra gasoline and oil

ARES/RACES

The Amateur Radio Emergency Service (ARES) and the Radio Amateur Civil Emergency Service (RACES) are the umbrella organizations of Amateur Radio public services. ARES is sponsored by ARRL (although ARRL membership is not required for participation) and handles all kinds of public-service activities. RACES is administered by the Federal Emergency Management Agency (FEMA) and operates only for civil preparedness and in times of civil emergency. RACES is activated at the request of a state or federal official.

The ARRL advocates dual membership and cooperative efforts between ARES and RACES whenever possible. RACES rules now make it possible for ARES and RACES to use the same frequencies, so that an ARES group also enrolled as RACES can “switch hats” from ARES to RACES and RACES to ARES as the situation develops. In many areas, however, the two organizations exist separately. Contact local ARRL Leadership Officials to determine the situation in your area.

ARES officials operate under the ARRL Section Manager. **Figs A and B** show the Section and the local ARES structures, respectively.

The Radio Amateur Civil Emergency Services (RACES) comprises certain Amateur Radio operators and stations that are registered with civil defense organizations or licensed as RACES stations by the FCC. RACES frequencies are normally shared with the Amateur Radio Service, but in times of civil emergency and for limited periods of testing and practice RACES operation is limited to the frequencies shown below. During times of official RACES operation, RACES stations may only contact other RACES stations and certain other stations as listed in §97.407(c). Official RACES operation does not allow radio contact with the general amateur population.




Fig A—Section-level ARES structure.

Dedicated RACES Operating Frequencies

RACES frequencies are shared with amateurs except in certain emergencies. See *The FCC Rule Book* (§97.407) for details on RACES operation.

<i>kHz</i>	<i>MHz</i>	<i>MHz</i>
1800-1825	10.100-10.150	50.350-50.750
1975-2000	14.047-14.053	52.000-54.000
3500-3550	14.220-14.230	144.50-145.71
3930-3980	14.331-14.350	146.00-148.00
3984-4000	21.047-21.053	222.00-225.00
7079-7125	21.228-21.267	420.00-450.00
7245-7255	28.550-28.750	1240.00-1300.00
	29.237-29.273	2390.00-2450.00
		29.450-29.650






Fig B—Local ARES structure for a county, city or other area of coverage.


The Interaction Between the EOC/NCS and the Command Post(s) in a Local Emergency




Organization and Interaction of ARES and NTS



Typical Station Deployment for Local ARES Net Coverage in an Emergency



Typical Structure of an HF Network for Emergency Communication



Amateur Message Form

Every formal radiogram message originated and handled should contain the following component parts in the order given.

<p>I PREAMBLE</p> <p>a. Number (begin with 1 each month or year)</p> <p>b. Precedence (R, W, P or EMERGENCY)</p> <p>c. Handling Instructions (optional, see text)</p> <p>d. Station of Origin (first amateur handler)</p> <p>e. Check (number of words/groups in text only)</p> <p>f. Place of Origin (not necessarily location of station of origin)</p> <p>g. Time Filed (optional with originating station)</p> <p>h. Date (must agree with date of time filed)</p> <p>II ADDRESS (as complete as possible, include zip code and telephone number)</p> <p>III TEXT (limit to 25 words or less, if possible)</p> <p>IV SIGNATURE</p>	<p style="text-align: center;">CW MESSAGE EXAMPLE</p> <p>I NR 1 R HXG WIAW 8 NEWINGTON CONN 1830Z JULY 1 <i>a b c d e f g h</i></p> <p>II DONALD SMITH \overline{AA} 164 EAST SIXTH AVE \overline{AA} NORTH RIVER CITY MO 00789 \overline{AA} 733 4968 \overline{BT}</p> <p>III HAPPY BIRTHDAY X SEE YOU SOON X LOVE \overline{BT}</p> <p>IV DIANA \overline{AR}</p> <p>Note that X, when used in the text as punctuation, counts as a word.</p>
--	---

CW: The prosign \overline{AA} separates the parts of the address. \overline{BT} separates the address from the text and the text from the signature. \overline{AR} marks end of message; this is followed by B if there is another message to follow, by N if this is the only or last message. It is customary to copy the preamble, parts of the address, text and signature on separate lines.

RTTY: Same as cw procedure above, except (1) use extra space between parts of address, instead of \overline{AA} ; (2) omit cw procedure sign \overline{BT} to separate text from address and signature, using line spaces instead; (3) add a CFM line under the signature, consisting of all names, numerals and unusual words in the message in the order transmitted.

PACKET/AMTOR BBS: Same format as shown in the cw message example above, except that the \overline{AA} and \overline{AR} prosigns may be omitted. Most amtor and packet BBS software in use today allows formal message traffic to be sent with the "ST" command. Always avoid the use of spectrum-wasting multiple line feeds and indentations.

PHONE: Use *prowords* instead of prosigns, but it is not necessary to name each part of the message as you send it. For example, the above message would be sent on phone as follows: "Number one routine HX Golf W1AW eight Newington Connecticut one eight three zero zulu July one Donald Smith Figures one six four East Sixth Avenue North River City Missouri zero zero seven eight nine Telephone seven three three four nine six eight Break Happy birthday X-ray see you soon X-ray love Break Diana End of Message Over. "End of Message" is followed by "More" if there is another message to follow, "No More" if it is the only or last message. Speak clearly using VOX (or pause frequently on push-to-talk) so that the receiving station can get fills. Spell phonetically all difficult or unusual words—do not spell out common words. Do not use cw abbreviations or Q-signals in phone traffic handling.

PRECEDENCES

The precedence will follow the message number. For example, on cw 207 R or 207 EMERGENCY. On phone, "Two Zero Seven, Routine (or Emergency)."

EMERGENCY—Any message having life and death urgency to any person or group of persons, which is transmitted by Amateur Radio in the absence of regular commercial facilities. This includes official messages of welfare agencies during emergencies requesting supplies, materials or instructions vital to relief of stricken populace in emergency areas. During normal times, it will be *very rare*. On cw, RTTY and other digital modes this designation will always be spelled out. When in doubt, *do not* use it.

PRIORITY—Important messages having a specific time limit. Official messages not covered in the Emergency category. Press dispatches and other emergency-related traffic not of the utmost urgency. Notification of death or injury in a disaster area, personal or official. Use the abbreviation P on cw.

WELFARE—A message that is either a) an inquiry as to the health and welfare of an individual in the disaster area b) an advisory or reply from the disaster area that indicates all is well should carry this precedence, which is abbreviated W on cw. These messages are handled *after* Emergency and Priority traffic but before Routine.

ROUTINE—Most traffic normal times will bear this designation. In disaster situations, traffic labeled Routine (R on cw) should be handled *last*, or not at all when circuits are busy with Emergency, Priority or Welfare traffic.

Handling Instructions (Optional)

HXA—(Followed by number.) Collect landline delivery authorized by addressee within miles. (If no number, authorization is unlimited.)

HXB—(Followed by number.) Cancel message if not delivered within hours of filing time; service originating station.

HXC—Report date and time of delivery (TOD) to originating station.

HXD—Report to originating station the identity of station from which received, plus date and time. Report identity of station to which relayed, plus date and time, or if delivered report date, time and method of delivery.

HXE—Delivering station get reply from addressee, originate message back.

HXF—(Followed by number.) Hold delivery until (date).

HXG—Delivery by mail or landline toll call not required. If toll or other expense involved, cancel message and service originating station.

For further information on traffic handling, consult the Public Service Communications Manual or the ARRL Operating Manual, both published by ARRL.

A Simple NTS Formal Message

THIS IS A FORMAL MESSAGE. FORMAL MEANS THAT THE MESSAGE FOLLOWS A PRE-ESTABLISHED FORM OR CONVENTION. A FORMAL MESSAGE CONTAINS ALL THE NECESSARY "RECORDKEEPING" ELEMENTS THAT ARE REQUIRED TO KEEP A HISTORY OF THE MESSAGE AS IT IS SENT THROUGH THE NTS. ALL FORMAL MESSAGES CONSIST OF FOUR PARTS: THE PREAMBLE, THE ADDRESS, THE TEXT AND THE SIGNATURE.

RADIOGRAM							
NUMBER	PRECEDENCE	HX	STN OF ORIGIN	CHECK	PLACE OF ORIGIN	TIME FILED	DATE
3 4 7	R	E	K7ABT	2 5	PHOENIX AZ		DEC 4
TO: ALBERT M COUSINS 337 W 38TH STREET BRIDGEPORT CT 06645 TELEPHONE NO: 203 334 5678							
DEAR	DAD	ARRIVED	SAFELY	339TH			
COMPOSITE	BOMB	GROUP	FLAGSTAFF	DECEMBER			
2ND	X	TELL	SHERRY	IM			
OK	X	PHONE	6 0 2	3 4 5			
9 8 7 6	SEND	FLAK	JACKET	LOVE			
		BILLY		043 89 9078			

EACH OF THE ELEMENTS OF THE FORMAL MESSAGE HAS CERTAIN FORMAT REQUIREMENTS WHICH MUST BE MET IN ORDER TO AVOID CONFUSION ON THE AIR AS THE MESSAGE IS SENT, AND ALSO TO ASSURE THAT A SENDER-TO-RECEIVER TRACE CAN ALWAYS BE DONE ON THE MESSAGE.

Handling Instructions

- HXA—(Followed by number.) Collect landline delivery authorized by addressee within _____ miles. (If no number, authorization is unlimited.)
- HXB—(Followed by number.) Cancel messages if not delivered within _____ hours of filing time; service originating station.
- HXC—Report date and time of delivery (TOD) to originating station.
- HXD—Report to originating station the identity of station from which received, plus date and time. Report identity of station to which relayed, plus date and time, or if delivered report date, time and method of delivery.
- HXE—Delivering station get reply from addressee, originate message back.
- HXF—(Followed by number.) Hold delivery until _____ (date).
- HXG—Delivery by mail or landline toll call not required. If toll or other expense involved, cancel message and service originating station.

An HX prosign (when used) will be inserted in the message preamble before the station of origin, thus: NR 207 R HXA50 W1AW 12...(etc). If more than one HX prosign is used they can be combined if no numbers are to be inserted; otherwise the HX should be repeated, thus: NR 207 R HXAC W1AW... (etc), but: NR 207 R HXA50 HXC W1AW...(etc). On phone, use phonetics for the letter or letters following the HX, to ensure accuracy.

ARL Numbered Radiograms

The letters ARL are inserted in the preamble in the check and in the text before spelled out numbers, which represent texts from this list. Note that some ARL texts include insertion of numerals. *Example:* NR 1 R W1AW ARL 5 NEWINGTON CONN DEC 25 DONALD R SMITH AA 164 EAST SIXTH AVE AA NORTH RIVER CITY MO AA PHONE 733 3968 BT ARL FIFTY ARL SIXTY ONE BT DIANA AR.

Group One—For possible “Relief Emergency” Use

ONE	Everyone safe here. Please don't worry.
TWO	Coming home as soon as possible.
THREE	Am in _____ hospital. Receiving excellent care and recovering fine.
FOUR	Only slight property damage here. Do not be concerned about disaster reports.
FIVE	Am moving to new location. Send no further mail or communication. Will inform you of new address when relocated.
SIX	Will contact you as soon as possible.
SEVEN	Please reply by Amateur Radio through the amateur delivering this message. This is a free public service.
EIGHT	Need additional _____ mobile or portable equipment for immediate emergency use.
NINE	Additional _____ radio operators needed to assist with emergency at this location.
TEN	Please contact _____. Advise to standby and provide further emergency information, instructions or assistance.
ELEVEN	Establish Amateur Radio emergency communications with _____ on _____ MHz.
TWELVE	Anxious to hear from you. No word in some time. Please contact me as soon as possible.
THIRTEEN	Medical emergency situation exists here.
FOURTEEN	Situation here becoming critical. Losses and damage from _____ increasing.
FIFTEEN	Please advise your condition and what help is needed.
SIXTEEN	Property damage very severe in this area.
SEVENTEEN	REACT communications services also available. Establish REACT communications with _____ on channel _____.
EIGHTEEN	Please contact me as soon as possible at _____.

NINETEEN	Request health and welfare report on _____. (State name, address and telephone number.)
TWENTY	Temporarily stranded. Will need some assistance. Please contact me at _____.
TWENTY ONE	Search and Rescue assistance is needed by local authorities here. Advise availability.
TWENTY TWO	Need accurate information on the extent and type of conditions now existing at your location. Please furnish this information and reply without delay.
TWENTY THREE	Report at once the accessibility and best way to reach your location.
TWENTY FOUR	Evacuation of residents from this area urgently needed. Advise plans for help.
TWENTY FIVE	Furnish as soon as possible the weather conditions at your location.
TWENTY SIX	Help and care for evacuation of sick and injured from this location needed at once.

Emergency/priority messages originating from official sources must carry the signature of the originating official.

Group Two—Routine messages

FORTY SIX	Greetings on your birthday and best wishes for many more to come.
FIFTY	Greetings by Amateur Radio.
FIFTY ONE	Greetings by Amateur Radio. This message is sent as a free public service by ham radio operators here at _____. Am having a wonderful time.
FIFTY TWO	Really enjoyed being with you. Looking forward to getting together again.
FIFTY THREE	Received your _____. It's appreciated; many thanks.
FIFTY FOUR	Many thanks for your good wishes.
FIFTY FIVE	Good news is always welcome. Very delighted to hear about yours.

Continued on [next page](#).

ARL Numbered Radiograms

Continued from [previous page](#).

FIFTY SIX Congratulations on your _____, a most worthy and deserved achievement.

FIFTY SEVEN Wish we could be together.

FIFTY EIGHT Have a wonderful time. Let us know when you return.

FIFTY NINE Congratulations on the new arrival. Hope mother and child are well.

*SIXTY Wishing you the best of everything on _____.

SIXTY ONE Wishing you a very merry Christmas and a happy New Year.

*SIXTY TWO Greetings and best wishes to you for a pleasant _____ holiday season.

SIXTY THREE Victory or defeat, our best wishes are with you. Hope you win.

SIXTY FOUR Arrived safely at _____.

SIXTY FIVE Arriving _____ on _____. Please arrange to meet me there.

SIXTY SIX DX QSLs are on hand for you at the _____ QSL Bureau. Send _____ self-addressed envelopes.

SIXTY SEVEN Your message number _____ undeliverable because of _____. Please advise.

SIXTY EIGHT Sorry to hear you are ill. Best wishes for a speedy recovery.

SIXTY NINE Welcome to the _____. We are glad to have you with us and hope you will enjoy the fun and fellowship of the organization.

* Can be used for all holidays.

Note: ARL numbers should be spelled out at all times.

How to be the Kind of Net Operator the Net Control Station (NCS) Loves

As a net operator, you have a duty to be self-disciplined. A net is only as good as its worst operator. You can be an exemplary net operator by following a few easy guidelines.

1) *Zero beat the NCS.* The NCS doesn't have time to chase all over the band for you. Make sure you're on frequency, and you will never be known at the annual net picnic as "old so-and-so who's always off frequency."

2) *Don't be late.* There's no such thing as "fashionably late" on a net. Liaison stations are on a tight timetable. Don't hold them up by checking in 10 minutes late with three pieces of traffic.

3) *Speak only when spoken to by the NCS.* Unless it is a bona fide emergency situation, you don't need to "help" the NCS unless asked. If you need to contact the NCS, make it brief. Resist the urge to help clear the frequency for the NCS or to "advise" the NCS. The NCS, not you, is boss.

4) Unless otherwise instructed by the NCS, *transmit only to the NCS.* Side comments to another station in the net are out of order.

5) *Stay until you are excused.* If the NCS calls you and you don't respond because you're getting a "cold one" from the fridge, the NCS may assume you've left the net, and net business may be stymied. If you need to leave the net prematurely, contact the NCS and simply ask to be excused (QNX PSE ON CW).

6) *Be brief when transmitting to the NCS.* A simple "yes" (C) or "no" (N) will usually suffice. Shaggy dog tales only waste valuable net time.

7) *Know how the net runs.* The NCS doesn't have time to explain procedure to you. After you have been on the net for a while, you should already know these things.

Checking Your Message

Traffic handlers don't have to dine out to fight over the check! Even good ops find much confusion when counting up the text of a message. You can eliminate some of this confusion by remembering these basic rules:

- 1) Punctuation ("X-rays," "Querys") count separately as a word.
- 2) Mixed letter-number groups (1700Z, for instance) count as one word.
- 3) Initial or number groups count as one word if sent together, two if sent separately.
- 4) The signature does not count as part of the text, but any closing lines, such as "Love" or "Best wishes" do.

Here are some examples:

- Charles J McClain—3 words
- W B Stewart—3 words
- St Louis—2 words
- 3 PM—2 words
- SASE—1 word
- ARL FORTY SIX—3 words
- 2N1601—1 word
- Seventy-three—2 words
- 73—1 word

Telephone numbers count as 3 words (area code, prefix, number), and ZIP codes count as one, ZIP + 4 codes count as two words. Canadian postal codes count as two words (first three characters, last three characters.)

Although, it is improper to change the text of a message, you may change the check. Always do this by following the original check with a slash bar, then the corrected check. On phone, use the words "corrected to."

Tips on Handling NTS Traffic by Packet Radio

Listing Messages

- After logging on to your local NTS-supported bulletin board, type the command LT, meaning List Traffic. The BBS will sort and display an index of all NTSXX traffic awaiting delivery.

Receiving Messages

- To take a message off the Bulletin Board for telephone delivery to the third party, or for relay to a NTS Local or Section Net, type the R command, meaning Read Traffic, and the message number. R 188 will cause the BBS to find the BBS message number 188. This RADIOGRAM will look like any other, with preamble, address, text and signature; only some additional packet-related message header information is added. This information includes the routing path of the message for auditing purposes; e.g., to discern any excessive delays in the system.
- After the message is saved to the printer or disk, the message should be KILLED by using the KT command, meaning Kill Traffic, and the message number. In the above case, at the BBS prompt, type KT 188. This prevents the message from being delivered twice. Some of the newer BBS software requires use of K rather than KT.
- At the time the message is killed, many BBSs will automatically send a message back to the station in the FROM field with information on who took the traffic, and when it was taken!

Delivering or Relaying A Message

- A downloaded RADIOGRAM should, of course, be handled expeditiously in the traditional way: telephone delivery, or relay to another net.

Sending Messages

- To send a RADIOGRAM, use the ST command meaning Send Traffic. The BBS will prompt you for the NTS routing (0611@NTSCT, for example), the message title which should contain the city in the address of the RADIOGRAM (QTC 1 Dayton), and the text of the message in RADIOGRAM format. The BBS, usually within the hour, will check its outgoing mailpouch, find the NTSCT message and automatically forward it to the next packet station in line to the NTSCT node. Note: Some states have more than one ARRL Section. If you do not know the destination ARRL Section ("Is San Angelo in the ARRL North, South or West Texas Section?"), then simply use the state designator NTSTX.

*Note: While NTS/packet radio message forwarding is evolving rapidly, there are still some gaps. When uploading an NTS message destined for a distant state, use handling instruction "HXC" to ask the delivering station to report back to you the date and time of delivery.

We Want You!

Local and Section BBSs need to be checked daily for NTS traffic. SYSOPs and STMs can't do it alone. They need your help to clear NTS RADIOGRAMs every day, seven days a week, for delivery and relay. If you are a traffic handler/packeteer, contact your Section Traffic Manager or Section Manager for information on existing NTS/packet procedures in your Section.

If you are a packeteer, and know nothing of NTS traffic handling, contact ARRL HQ, your Section Manager or Section Traffic Manager for information on how you can put your packet radio gear to use in serving the public in routine times, but especially in time of emergency!

And, if you enjoy phone/CW traffic handling, but aren't on packet yet, discover the incredible speed and accuracy of packet radio traffic handling. You probably already have a small computer and 2-meter rig; all you need is a packet radio "black box" to connect between your 2-meter rig and computer. For more information on packet radio, see *Your Packet Companion* or *Practical Packet Radio*, both published by the ARRL.

Templates

Template packages are available for many ARRL Handbook projects and some text discussions. They may include full-size etching patterns, more-detailed information on the subject, the author's corrections or updates and other useful information. They are updated as new information is received at ARRL Headquarters.

All of these template packages are available on this CD-ROM in the \TEMPLATE directory. With *Acrobat Reader* installed, simply open the \TEMPLATE\INDEX.PDF file on the CD-ROM to read any of the templates. You also can open an individual template file using the file name in the table below. These files are located in the \TEMPLATE\PDF directory of the CD-ROM.

Template packages are also available in hard-copy form from the Technical Secretary, ARRL HQ, 225 Main St, Newington, CT 06111-1494, USA. The minimum handling charge is \$2 for ARRL members and \$4 for nonmembers. The cost is higher for some larger packages. If you live in the US, enclose a check or money order made out to ARRL. A self-addressed 9 x 12 envelope will help expedite your request. For requests from outside the US, call 860-594-0278 (8 AM - 4 PM Eastern time). The fax number is 860-594-0259.

Template Reference Chapter and Topic	Template Name	PDF File Name	Hard-Copy Cost
11—A Series-Regulated 4.5- to 25-V, 2.5-A Power Supply	Sabin Power Supply	SABINPS	\$2/\$4
11—A 13.8-V, 40-A Power Supply	13.8-V, 40-A Power Supply	13V40APS	\$2/\$4
11—28-V, High-Current Power Supply	28-V Power Supply	28VSUP	\$2/\$4
13—A 2-M Brick Amp for Handhelds	2-M Brick Amp for Hand-helds	BRICK	\$2/\$4
13—Pi and Pi-L Network Tables	HBK-Match	HBKMATCH	\$3/\$5
16—Crystal-Filter Evaluation	Crystal Filter Evaluation	XFEVAL	\$2/\$4
16—A Continuously Variable Bandwidth Audio Filter	Bramwell Variable Audio Filter	BRAMWELL	\$2/\$4
17—NB Match Diagrams	NB Match	NBMATCH	\$2/\$4
17—A Rock-Bending Receiver for 7 MHz	Rock Bending Receiver	RBR	\$2/\$4
17—The NorCal Sierra: An 80-15 M CW Transceiver	NorCal Sierra	SIERRA	\$3/\$5
17—A Broadband HF Amplifier	Kossor Amp	KOSSOR	\$2/\$4
20—SWR Analyzer Tips, Tricks and Techniques	Stanley SWR/Z	STANLEY	\$2/\$4
22—Vintage Radio T/R Adapter	T/R Switch	TRSW	\$2/\$4
22—Quick and Easy CW with Your PC	Taggart CW Interface	TAGGART	\$2/\$4
22—An Expandable Headphone Mixer	Headphone Mixer	HEADMIX	\$2/\$4
22—Audio Break-Out Box	Spencer Audio Break-out Box	SPENCEBO	\$2/\$4
22—An SWR Detector Audio Adapter	Spencer Audible SWR Adaptor	SPENCESWR	\$2/\$4
22—Remotely Controlled Antenna Switch	Remotely Controlled Antenna Switch	ANTSW	\$2/\$4
22—A Trio of Transceiver/Computer Interfaces	Interfaces	IFACE	\$2/\$4
22—TR Time-Delay Generator	N6CA TR Time-Delay Generator	N6CA-TR	\$2/\$4
23—Frequency Coordination and Band Plans	Repeaters	RPTRS	\$2/\$4
23—Mode-S Receive Converter	S-Band Converter	S-BAND	\$2/\$4
23—L-Band Satellite Antenna/Amplifier	Krome Amp	KROME	\$2/\$4

Continued on [next page](#).

Templates

Continued from [previous page](#).

Template Reference Chapter and Topic	Template Name	PDF File Name	Hard-Copy Cost
23—Azimuth and Elevation Information	EME	EME	\$2/\$4
23—An Active Attenuator for VHF-FM	Eindhoven Active Attenuator	EEN-ATT	\$2/\$4
26—A Marker Generator with Selectable Output	Marker Generator	MARKGEN	\$2/\$4
26—Measure Inductance and Capacitance with a DVM	Rainbow Inductance Meter	LMETER	\$2/\$4
26—A Six-Digit Programmable Frequency Counter and Digital Dial	Six Digit Programmable Frequency Counter/Digital Dial	COUNTER	\$2/\$4
26—A Calibrated Noise Source	Sabin Noise Source	SABINNS	\$2/\$4
26—A Noise Bridge for 1.8 Through 30 MHz	RX Noise Bridge	RXBRIDGE	\$2/\$4
27—Bench Equipment	Dip Meter Sources	DIPS	\$2/\$4
27—Signal Generator	Crystal Controlled Signal Source	XTALSRC	\$2/\$4
30—Pi-Network Resistive Attenuators (50 Ω)	Step Attenuator	STEPATT	\$2/\$4